
KENWOOD

TYPE SB05 SB050 series

instructions





HEAD OFFICE: Kenwood Limited, 1-3 Kenwood Business Park, New Lane, Havant, Hampshire PO9 2NH

kenwoodworld.com



English



safety

- Read these instructions carefully and retain for future reference.
- Remove all packaging and any labels.
- If the cord is damaged it must, for safety reasons, be replaced by KENWOOD or an authorised KENWOOD repairer.
- Switch off and unplug:
 - o before fitting and removing parts
 - o after use
 - o before cleaning.
- Never let the power unit, cord or plug get wet.
- Never use a damaged appliance. Get it checked or repaired: see 'service and customer care'.
- Never use an unauthorised attachment.
- Never leave the appliance on unattended.
- Always wait until the blades have completely stopped before removing the mug from the power unit.
- SCALD RISK: The unit may also be used for making soups. Liquids should be allowed to cool to room temperature before blending.
- Never drink any hot liquids from the travel mug.
- When drinking through the lid, take care that the drink is smooth. Some experimentation may be necessary to achieve the desired result, particularly when processing firm or unripened foods as you may find that some ingredients remain unprocessed.

- Always take care when handling the blade assembly and avoid touching the cutting edge of the blades when cleaning.
- Only use the blender with the blade assembly supplied.
- Always use the Blender on a secure, dry level surface.
- Never place the appliance on or near a hot gas or electric burner or where it could come into contact with a heated appliance.
- Misuse of your Blender can result in injury.
- This appliance shall not be used by children.
 Keep the appliance and its cord out of reach of children.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- Only use the appliance for its intended domestic use. Kenwood will not accept any liability if the appliance is subject to improper use, or failure to comply with these instructions.

before plugging in

 Make sure your electricity supply is the same as the one shown on the underside of the appliance.

Important - UK only

- The wires in the cord are coloured as follows:
 - Blue = Neutral Brown = Live.
- The appliance must be protected by a 3A approved (BS1362) fuse.

Note:

 For non-rewireable plugs the fuse cover MUST be refitted when

- replacing the fuse. If the fuse cover is lost then the plug must not be used until a replacement can be obtained. The correct fuse cover is identified by colour and a replacement may be obtained from your Kenwood Authorised Repairer (see Service).
- If a non-rewireable plug is cut off it must be DESTROYED IMMEDIATELY. An electric shock hazard may arise if an unwanted non-rewireable plug is inadvertently inserted into a 13A socket outlet.

 This appliance conforms to EC Regulation 1935/2004 on materials and articles intended to come into contact with food.

You can use your blender for making delicious and nutritious cold drinks. The dispensing lid means that it can easily be converted into a travel mug.

A selection of recipes can be found at the back of the instructions, and the handy markings on the mug allow you to mix ingredients of your choice. Combinations of fruit and yoghurt (both fresh and frozen), ice cream, ice cubes, juice and milk can be used.

before using for the first time

Wash the parts: see 'care & cleaning'.

key

- (1) blade assembly
- ② dispensing lid x 2
- (3) travel mug x 2
- (4) power unit
- speed control

Note: Model SB054 is only supplied with one travel mug and one dispensing lid.

to use your blender

- 1 Add ice or frozen ingredients to the mug 1.
- This includes frozen fruit, frozen yoghurt, ice cream or ice. These can be added up to the level marked 'max frozen ingredients'.
- 2 Add liquid ingredients to the mug.
- This includes fruit (not frozen), fresh yoghurt, milk and fruit juices. These can be placed into the mug to the level marked 'max capacity'.
- 3 Hold the underside of the blade unit and lower it onto the mug, blades down – turn clockwise to lock 1.
- 4 Shake to disperse the ingredients.
- 5 To fit the assembled mug to the power unit, turn the mug upside down and line up the tabs on the mug with the grooves in the power

- unit and then turn clockwise until a positive click is heard 2.
- 6 Select the required speed.
- When blending recipes that include frozen ingredients turn the speed control to '1' for 5 seconds to start the mixing process, then turn the speed control to '2'.
- Allow the ingredients to blend until smooth.
- 7 When the desired consistency is reached, turn the speed control to the 'off' position. Turn the mug anticlockwise to release it from the power unit.
- 8 Turn the mug the other way up and unscrew the blade assembly.
- 9 Fit and lock the lid by turning clockwise.
- When you want to drink, simply flip open the lid cover and clip into position 3. The drink can be consumed straight from the mug.

hints & tips

- Note that when the mug is filled to max capacity (500ml), this is approximately two servings.
- If you do not intend to consume your drink immediately, keep it refrigerated.
- Ensure your drink is thin enough to be able to drink from the dispensing lid. To make a thinner drink add more liquid.
- Once your drink has reached the desired consistency, you can use the pulse 'P' to ensure all ingredients are thoroughly blended. Use the pulse 'P' to operate the power unit in a start stop action to control the texture of your drink.
- After blending, some drinks may not be completely smooth due to seeds or the fibrous nature of ingredients.
- Some drinks may separate on standing, therefore it is best to drink them straight away. Separated drinks should be stirred before drinking.

important

- Never blend dry ingredients (e.g. spices, nuts) or run the Blender empty.
- Do not use the Blender as a storage container whilst on the power unit.

- Some liquids increase in volume and froth during blending e.g. milk, so do not overfill and ensure the blade assembly is correctly fitted.
- To ensure long life of your Blender, never run it continuously for longer than 30 seconds.
- Never blend food that has formed a solid mass during freezing, break it up before adding to the mug.
- Never blend more than the max capacities marked on the mug.
- When the dispensing lid is fitted always keep the travel mug upright.

care & cleaning

- Always switch off, unplug and dismantle before cleaning.
- Never let the power unit, cord or plug get wet.
- Always wash immediately after use.
 Do not let food dry onto the mug assembly as this will make cleaning difficult.
- Do not wash any part in the dishwasher.

power unit

Wipe with a damp cloth, then dry.

blade unit

- 1 Do not touch the sharp blades brush them clean using hot soapy water, then rinse thoroughly under the tap. Do not immerse the blade assembly in water.
- 2 Leave to dry upside down away from children

mug and dispensing lid

Wash by hand, rinse with clean water then dry.

service and customer care

UK

If you need help with:

- using your appliance
- servicing or repairs (in or out of guarantee)
- a call Kenwood Customer Care on 023 9239 2333 or visit www. kenwoodworld.com. Have your model number (e.g. SB050) and date code (5 digit code e.g. 13L35) ready. They are located on the underside of the power unit.

other countries

- If you experience any problems with the operation of your appliance, before requesting assistance visit www.kenwoodworld.com.
- Please note that your product is covered by a warranty, which complies with all legal provisions concerning any existing warranty and consumer rights in the country where the product was purchased.
- If your Kenwood product malfunctions or you find any defects, please send it or bring it to an authorised KENWOOD Service Centre. To find up to date details of your nearest authorised KENWOOD Service centre visit www.kenwoodworld.com or the website specific to your Country.
- Designed and engineered by Kenwood in the UK.
- Made in China.



IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH THE EUROPEAN DIRECTIVE ON WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT (WEEE)

At the end of its working life, the product must not be disposed of as urban waste.

It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.

guarantee (UK only)

If your appliance goes wrong within one year from the date you bought it, we will repair or replace it free of charge provided:

- you have not misused, neglected or damaged it;
- it has not been modified (unless by Kenwood):
- it is not second-hand:
- it has not been used commercially;
- you have not fitted a plug incorrectly; and
- you supply your receipt to show when you bought it.

This guarantee does not affect your statutory rights.

recipes

Breakfast Smoothies

breakfast 2GO

1 serving (300ml)

2 ice cubes 60ml skimmed milk 50g low fat yoghurt 50g banana cut into 2cm slices 75g apple, chopped into 2cm chunks 5ml wheatqerm

- 5ml runny clear honey
- 1 Place the ice cubes, milk and yoghurt in the mug. Then add the banana, apple and wheatgerm. Shake well before blending.
- 2 Switch to '1' for 5 seconds, then '2' for 20 seconds. Check the sweetness and add the Honey if required.

ruby grapefruit oatie

1 serving (250ml)

150ml ruby grapefruit juice 50ml natural wholemilk yoghurt 50g banana cut into 2cm slices 1tbsp porridge oats 1tbsp clear runny honey

- 1 Add the grapefruit juice and yoghurt to the mug. Then add the banana and porridge. Shake well before blending.
- 2 Switch to '2' for 15 seconds. Check the sweetness and add the Honey if required.

nutty banana boost

1 serving (250ml)

75ml semi-skimmed milk 115g low fat hazelnut yoghurt 50g banana cut into 2cm slices 3 ready to eat dried apricot, chopped into 1cm pieces

- 1 Add the milk and yoghurt to the mug. Then add the banana and apricot. Shake well before blending.
- 2 Switch to '1' for 5 seconds, then '2' for 25 seconds.

Fruity Smoothies

iced strawberry sensation

1 serving (250ml)

2 Ice cubes 70ml apple juice 60g strawberries, hulled and halved 80g cantaloupe melon, seeded and cut into 2cm chunks

5ml runny clear honey

- 1 Add the ice cubes and apple juice to the mug. Then add the strawberries and melon.
- 2 Switch to '1' for 5 seconds, then '2' for 20 seconds. Check the sweetness and add the Honey if required.

mango, pineapple, passion fruit juice smoothie

1 serving (300ml)

150ml freshly squeezed orange juice 85g ripe mango cut into 2cm chunks 65g pineapple chopped into 2cm chunks

½ passion fruit

- Add the orange juice to the mug.
 Then add the mango, pineapple and passion fruit.
- 2 Switch to '2' for 20 seconds.

papaya & peach nectar

1 serving (250ml)

iuice/drained

100ml grapefruit juice100g canned peach slices in fruit

70g papaya, seeded and cut into 2cm chunks

- 1 Add the grapefruit juice, peach and papaya to the mug.
- 2 Switch to '2' for 15 seconds.

berry smoothie

1 serving (250ml)

100ml cranberry juice 25ml apple juice 75g raspberries 40g blackberries

- 1 Add the cranberry and apple juice to the mug. Then add the berries.
- 2 Switch to '2' for 20 seconds.

ice cool fruity

1 serving (300ml)

2 ice cubes 100ml orange Juice 50g ½ kiwi fruit cut into 2cm pieces 75g strawberries, hulled and halved

- 1 Add the ice cubes and orange juice to the mug. Then add the kiwi fruit and strawberries.
- 2 Switch to '1' for 5 seconds, then '2' for 20 seconds.

summer fruit smoothie

1 serving (250ml)

50g frozen summer fruit mix 200ml semi-skimmed milk

- 1 Add the fruit and milk to the mug.
- 2 Switch to '1' for 5 seconds, then '2' for 25 seconds.

Vegetable Smoothies

minted lassi cooler

1 Serving (250ml)

2 ice cubes 150ml natural wholemilk yoghurt 90g ½ cucumber peeled, deseeded and chopped into 2cm slices 4 mint leaves

- 1 Place the ice cubes, yoghurt, cucumber and mint into the mug.
- 2 Switch to '1' for 5 seconds, then '2' for 25 seconds.

avocado smoothie

1 serving (300ml)

200ml white grape juice
10ml lemon juice
50g ½ small avocado, stoned,
peeled and chopped into 6 pieces.
60g ½ ripe pear, peeled, cored &
chopped into 2cm chunks.
few drops of Tabasco, optional

- Place the grape and lemon juice, avocado and pear into the mug
- 2 Switch to '2' for 20 seconds.

beetroot buzz

1 serving (250ml)

50ml freshly squeezed orange juice 100ml apple juice 15g carrot, grated. 5g fresh root ginger, peeled & grated. 50g cooked fresh baby beetroot, cut

- into 2cm chunks.1 Add the orange and apple juice to
- the mug. Then add the carrot, ginger and beetroot.
- 2 Switch to '1' for 5 seconds, then '2' for 25 seconds.

carrot and coriander soup

200g carrot cut into 12mm cubes 300ml water small knob of butter 1 small onion finely chopped 5ml ground coriander salt and pepper stock

- 1 Place the carrot and water into the travel mug.
- 2 Fit the blade assembly and then process for 20 seconds on '2'.
- 3 Melt the knob of butter in a pan, add the onion and fry until soft.
- 4 Add the carrot/water mixture, coriander and seasoning. Simmer the soup until cooked. Adjust the seasoning as necessary and add extra stock if required.