

ECAM350.20- 全自動義式咖啡機

使用說明書


BEAN TO CUP ESPRESSO AND
CAPPUCCINO MACHINE
Instructions for Use




DeLonghi



B



C



CONTENTS

1. 基本安全警告	5	18.4 清潔滴水盤和冷凝水盤	16
2. 一般資訊	6	18.5 清潔設備內部	16
2.1 使用說明	6	18.6 清潔水箱	17
3. 介紹	7	18.7 清潔咖啡出水孔	17
3.1 括號內字母	7	18.8 清潔預磨咖啡粉槽	17
3.2 故障排除和維修	7	18.9 清潔沖煮器	17
4. 說明	7	19. 除鈣	18
4.1 設備說明	7	20. 設定水質硬度	19
4.2 觸控螢幕說明	7	20.1 測量水質硬度	19
4.3 配件說明	7	20.2 設定水質硬度	19
5. 使用前	8	21. 軟水過濾器	19
5.1 檢查設備	8	21.1 安裝軟水過濾器	19
5.2 安裝設備	8	21.2 更換軟水過濾器	20
5.3 連接設備	8	22. 技術數據	20
5.4 設置設備	8	23. 燈號說明	21
5.5 清潔和維護與液體接觸的零件	9	24. 故障排除	23
5.6 製作卡布奇諾與牛奶為主的咖啡	9	25. 保固說明及保固書	25
6. 啟動設備	9		
7. 關閉設備	9		
8. 設定溫度	10		
9. AUTO-OFF(自動關閉)	10		
10. 節能	10		
11. 提示音	11		
12. 預設值(重置)	11		
13. 沖洗	11		
14. 製作咖啡	11		
14.1 調整咖啡研磨	11		
14.2 製作更熱的咖啡技巧	11		
14.3 使用咖啡豆製作飲品	12		
14.4 暫時改變咖啡濃度	13		
14.5 使用預磨咖啡粉製作咖啡	13		
14.6 客製化咖啡濃度與杯量	13		
15. TRUEBREW OVER ICE™ COFFEE純萃冷冽	14		
15.1 客製純萃冷冽濃度與杯量	14		
16. 製作卡布奇諾	14		
16.1 蒸汽管使用後清潔	15		
17. 提供熱水	15		
18. 清潔	15		
18.1 清潔設備	15		
18.2 清設備內部管道	16		
18.3 清潔咖啡渣盒	16		

1. 基本安全警告

- 本設備並無意讓肢體、感官或精神上有障礙或缺乏經驗和知識的人士（包括兒童）使用，除非獲得由負責其安全的人員在使用本產品上進行指導監督。
- 應監督兒童確保他們不可將產品當成玩具。
- 指定用途：本設備的設計和製造以製作咖啡、牛奶和熱水為底的飲品。水箱中僅能使用飲用水。切勿使用配件去製作使用說明書中未描述的飲品。任何其他用途都被認為是不當的，因此很危險。製造商不對因使用不當造成的損壞負責。
- 加熱元件的表面在使用後仍然很熱，根據使用情形，設備的外部可能在使用後數分鐘仍有餘熱。
- 徹底清潔所有零組件，特別注意與牛奶接觸的部分。
- 兒童不得在無人監督之下進行清潔和維護。
- 切勿將產品浸入水中清洗。
- 重要：為防止損壞設備，請勿使用鹼性清潔劑清潔；可使用軟布，並在適用的情況下使用中性清潔劑。
- 此設備僅為家電。並不設計為以下場合中使用：在商店、辦公室和其他工作環境的員工廚房區；農莊、旅館、飯店和其他住宅類型的客戶；食宿B&B類型的環境。
- 如果插頭或電源線損壞，必須由本公司客戶服務單位更換，以避免涉及任何風險。
- 具有可拆式電源線的電器：避免水濺到電器背面的電源線接頭或插座上。
- 重要：帶有玻璃面板的機型：如果表面有裂痕，請勿繼續使用該產品。
- 設備在使用過程中不得放在櫥櫃或廚房收納櫃內。

這是電器因此可能導致觸電。

您應該遵循以下的安全警告：

- 不要用濕手或腳接觸設備。
- 不要用濕手觸摸插頭。
- 確保電源插座所在位置是任何時候都容易碰到，使設備在必要拔掉插頭時無障礙。
- 只可直接抓緊插頭拔下，切勿拉扯電源線，可能會造成設備損壞。
- 要完全切斷本設備，必須從電源插座拔下插頭。
- 如果設備發生故障時，請勿自行嘗試修理。先關閉設備、拔掉電源插座，並聯繫客戶服務單位。
- 在清潔設備之前，請先關閉設備，從電源插座上拔下插頭，冷卻設備。

重要！

所有包裝請放置於遠離兒童之處（塑膠袋，聚苯乙烯泡綿）。

窒息危險。設備可能包含小零件，在清潔和維護操作時需要拆卸其中一些小零件，請小心拿取，並將小零件放在兒童接觸不到的地方。

燙傷危險！

此設備在作業時，可能產生熱水和蒸汽。

在操作過程中（自動沖洗、熱飲輸送、蒸汽輸送、清潔），避免接觸濺出的熱水或蒸汽。避免與飛濺熱水或蒸汽接觸。

設備在操作中時，溫杯架會變得非常熱。

2. 一般資訊

2.1 使用說明

使用設備前，請仔細閱讀此使用說明書。不按照使用說明書操作，可能會導致燙傷或損壞設備。

不按照使用說明書所導致的損害，製造商不承擔責任。

請注意：

這些安全警告適用於所有迪朗奇全自動義式咖啡機。

將產品隨附的使用說明書與設備一起保存。

3. 介紹

感謝您選擇迪朗奇全自動義式咖啡機。
我們希望您盡情享用新設備。請多花幾分鐘時間閱讀此使用說明書。以避免損壞設備及其他風險。

3.1 括號內字母

有關括號中的字母請參考在2-3頁設備描述圖例。

3.2 故障排除和維修

出現問題時，請先利用此使用說明書提供的資訊嘗試解決，請參考章節“23. 燈號說明”和“24. 故障排除”。

如果無法解決問題，或者您需要進一步的資訊，您可以撥打“客戶服務”手冊中客戶服務專線。

如果您的國家不在服務清單之中，請撥打當地客戶服務電話號碼。如果需要維修，請您僅限與迪朗奇客戶服務單位聯繫，聯繫方式已附在設備保固卡、設備包裝或設備標籤上。


4. 說明

4.1 設備說明

(page 3 - A)

- A1. 咖啡豆槽上蓋
- A2. 預磨咖啡粉槽上蓋
- A3. 咖啡豆槽
- A4. 預磨咖啡粉槽
- A5. 咖啡研磨調節旋鈕
- A6. 主開關
- A7. 沖煮器門
- A8. 沖煮器
- A9. 電源線
- A10. 冷凝水盤
- A11. 咖啡渣盒
- A12. 杯托
- A13. 滴水盤水位指示器
- A14. 滴水盤網格蓋板
- A15. 滴水盤
- A16. 水箱上蓋
- A17. 水箱
- A18. 軟水過濾器卡榫
- A19. 咖啡出水孔(可調節高度)
- A20. 蒸汽管(可拆卸)
- A21. 蒸汽/熱水噴嘴
















A22. 蒸汽/熱水旋鈕

A23.  按鈕: 開啟與關閉(待機)設備

4.2 觸控螢幕說明

(page 2 - B)

面板上有多個按鈕具有雙重功能，說明標注在描述中的括號中。

- B1.  燈閃爍: 設備正在加熱
- B2.  燈:
 - 恆亮: 將咖啡渣盒 (A11) 放回原處
 - 閃爍: 咖啡渣容器需要清空
- B3.  燈:
 - 恆亮: 插入水箱 (A17)
 - 閃爍: 水箱內水量不足
- B4.  燈: 一般警示(參考章節“24. 燈號說明”)
- B5.  燈:
 - 恆亮: 除鈣程序正在進行中
 - 閃爍: 機器需要除鈣
- B6.  : 預磨功能
- B7.  : 咖啡濃度
- B8.  : 濃度選擇
- B9.  : 提供2杯“espresso(濃縮咖啡)”或“espresso lungo(長濃縮咖啡)”
- B10.  : “espresso(濃縮咖啡)”
- B11.  : “espresso lungo(長濃縮咖啡)”
- B12.  : TrueBrew Over Ice™ Coffee 純萃冷冽
- B13.  : “Long(長萃咖啡)”
- B14.  ESC鍵:
 - 恆亮: 按下啟動蒸汽功能(在設定選單中: 按下以退出目前設定)
 - 閃爍: 蒸汽/熱水旋鈕 (A22) 必須啟動或關閉
- B15.  OK: 執行沖洗循環。
(在設定選單中: 按下以確認目前設定)

4.3 配件說明

(page 2 - C)

- C1. 水質硬度試紙
- C2. 預磨咖啡粉量匙
- C3. 除鈣劑
- C4. 軟水器過濾器(只限於某些機型)
- C5. 清潔毛刷

5. 使用前

5.1 檢查設備

拆除包裝後，確認產品完好無損，所有配件都齊全。如果有明顯損壞，不要使用設備。聯繫迪朗奇客戶服務單位。

5.2 安裝設備



重要！

當您安裝設備時，應該遵循以下安全警告：

- 設備會散發熱。將設備定位在檯面後，預留與設備表面距離-側方和後面牆壁至少3公分，上方至少15公分的空間。
- 水滲透設備可能造成損害。不要將設備放在靠近水龍頭或者水槽。
- 如果設備內含水凍結可能會造成損壞。不要將設備安裝在溫度可能降至冰點以下的房間裡。
- 妥善放好電線，使其不會與銳邊或熱表面（例如電加熱板）接觸而受損壞。

5.3 連接設備



重要！

檢查主電源電壓對應於對設備機身上銘牌所示資料。

將設備連接到一個有效接地並正確安裝的插座，最小額定電流為10A。

如果電源插座不與設備插頭匹配，需請具資格的專業人員將插座轉換為合適的類型。

5.4 設置設備




請注意：


- 第一次使用設備時，水管線迴路是空的，設備可能會很吵。隨著管線的填充，噪音將會越來越小。
- 咖啡研磨器內含有咖啡殘留屬正常，這是出廠前品管單位對設備進行操作測試的結果。機器保證為全新的設備。
- 您應盡快按照說明來設定水質硬度，參見章節：“20. 設定水質硬度”。

按照以下描述進行：


1. 將設備插入電源插座，並確認設備背面的主開關(A6)已按下(圖1)。



2. 觸控螢幕(B)上的燈(B3)閃爍：移除水箱(A17-圖2)，將清水(圖3A)到入到最高水位 MAX 水位，然後放回設備中(圖3B)。




3. 圖標(B14-圖5)在觸控螢幕上閃爍。
4. 放置一個最小容量為 100ml 的容器在蒸汽管下(A20)(圖4)。



5. 將蒸汽/熱水旋鈕(A22)轉到“I”位置(圖6)並按 OK (B15)。從蒸汽管中送出水。
6. 當自動停止製作時，觸控螢幕上的閃爍表示必須將蒸汽旋鈕轉回“0”位置。

設備關機

若需使用，請按  按鈕 (A23-圖7)。



請注意:

- 當您首次使用設備時，需要做4-5杯卡布奇諾，才能開始產生令人滿意的結果。
- 為了更加享受您的咖啡並改善設備的性能，我們建議安裝軟水過濾器(C4)，說明請參考章節“21.軟水過濾器”。如果您的型號沒有內含軟水過濾器，可向迪朗奇客戶服務單位購買。

5.5 清潔和維護與液體接觸的零件

- 首次使用或3-4天未使用後，請參考使用說明清潔與水、咖啡和牛奶接觸的零件和可拆卸配件。請參考使用說明書指示哪些配件是洗碗機適用的。
- 如果設備超過3-4天沒有使用，在製作第一杯飲品之前，請按照此使用說明書中的說明沖洗內部管道。
- 在執行使用說明書中描述的內容，和/或設備本身的顯示或警告燈提示的所有清潔和維護操作時，請務必格外小心。

5.6 製作卡布奇諾與牛奶為主的咖啡

- 該設備已經過測試，可用於牛奶和以下植物性產品：大豆、米和杏仁奶。不得使用其他類型的牛奶或植物性產品。
- 在使用任何類型的牛奶後，要清潔系統，請參考使用說明書中描述的標準程序進行。
- 製造商提供的和使用說明書中描述的清潔方法不能保證完全去除過敏原。
- 若有確認或懷疑的過敏原和不耐症，請確保您的設備之前沒有使用過任何含有造成您過敏的過敏原，或您不耐受的物質如牛奶或植物性產品。

6. 啟動設備



請注意:

在接通設備之前，請確保主開關(A6)已按下(圖1)。


每次設備被接通時，會執行一系列不能中斷的自動預熱和沖洗循環。設備只能在此週期完成後才準備就緒可以使用。

燙傷危險!

在沖洗過程中，會從咖啡出水孔(A19)流出一點熱水，並收集在下方的滴水盤(A15)。避免接觸飛濺熱水。

- 要打開設備，按下  按鈕(A23)(圖7)。觸控螢幕(B)上的  閃爍，表示機器正在加熱。

加熱時，設備會執行沖洗循環。除了加熱渦輪外，也透過熱水循環加熱內部管道。



設備達到適當溫度時，觸控螢幕上的  燈熄滅且咖啡圖示亮起。

7. 關閉設備

每當設備在製作咖啡後關閉時，會執行一個自動沖洗循環。

燙傷危險!

在沖洗過程中，咖啡出水孔(A19)會有一點點熱水噴出。避免接觸飛濺熱水。

- 要關閉設備，按下  按鈕(A23，圖7)。
- 觸控螢幕上的  指示燈(B1)閃爍，設備執行沖洗循環，然後關閉(待機)。

請注意:

如果您將在一段時間內不使用本產品，請從電源插座上拔下插頭：



- 首先按下  按鈕關閉設備。
- 關閉主開關(A6)(圖1)。





















重要!



切勿在設備開啟時關閉主開關。

8. 設定溫度

如果要調整用於製作咖啡的水溫(低、中、高、最高)，請執行以下操作：

1. 設備關閉(待機)，但按下主開關 (A6) (圖 1)。
2. 按住 **2x** 圖示 (B9) 直到觸控螢幕 (B) 上的燈亮起。
3. 按下  圖示 (B10)。
4. 再次按  圖示選擇所需溫度：



    	低
    	中
    	高
    	最高

5. 按  **OK** 圖示 (B15) 確認(或按  **ESC** (B14) 退出而不進行修改)。
燈熄滅。
設備返回“待機”狀態，溫度現在已重新設定。



9. AUTO-OFF (自動關閉)

設備閒置時自動關機的時間可以改變，可設定15、30分鐘或1、2或3小時後關閉。

要更改自動關閉設置，步驟如下：

1. 設備關閉(待機)，但按下主開關 (A6) (圖 1)。
2. 按住 **2x** 圖示 (B9) 直到觸控螢幕 (B) 上的圖示亮起。
3. 按下  圖示 (B11)。
4. 再次按下  圖示選擇所需的時間間隔：















    	15 分鐘
    	30 分鐘
    	1 小時
    	2 小時
    	3 小時

5. 按  **OK** 圖示 (B15) 確認(或按  **ESC** (B14) 退出而不進行修改)。
燈熄滅。

10. 節能

使用此功能啟用或停用節能模式。設備預設為啟用節能功能，可在設備啟動時降低能耗，符合當前的歐洲法規。

要更改設定，請執行以下操作：

1. 設備關閉(待機)，但按下主開關 (A6) (圖 1)。
2. 按住 **2x** (圖示) (B9) 直到觸控螢幕 (B) 上的圖示亮起。
3. 按下  圖示 (B13)。
4. 再次按  圖標啟用/停用該功能：
 -      功能停用
 -      功能啟用
5. 按  **OK** 圖示 (B15) 確認(或按  **ESC** (B14) 退出而不進行修改)。燈熄滅。
節能模式現已設定。



請注意:

- 在節能模式中時，在沖泡第一杯咖啡，必須多等秒鐘，因設備必須再次加熱。

11. 提示音

此功能啟用或停用提示音。進行如下操作：

- 設備關閉(待機)，但按下主開關(圖 1)。
- 按住 **2x** (圖示) (B9) 直到觸控螢幕 (B) 上的圖示亮起。
- 按 **2x** 圖示啟用/停用該功能：
 - 功能停用
 - 功能啟用
- 按 **OK** 圖示 (B15) 確認(或按 **ESC** (B14) 退出而不進行修改)。燈熄滅。提示音已設定。

12. 預設值(重置)

此功能可重置所有設備設定，包含溫度、自動關閉、水質硬度、節能 and 所有杯量設定均重置為預設值。

- 設備關閉(待機)，但按下主開關(圖 1)。
- 按住 **2x** 圖示 (B9) 直到觸控螢幕 (B) 上的燈亮起。
- 按下 圖示 (B12)。觸控螢幕上的咖啡豆圖示 (B7) 閃爍。
- 按 **OK** 圖示 (B15) 確認(或按 **ESC** (B14) 退出而不進行修改)。燈熄滅。飲品的設定和杯量已重置為預設值。

13. 沖洗

使用此功能從咖啡出水孔 (A19) 提供熱水，以清潔和加熱設備的內部管道。

在咖啡和熱水出水孔下方放置一個容量至少為 100ml 的容器。



重要! 燙傷危險。

輸送熱水時，請勿讓設備無人看管。

- 要啟用該功能，請按 **OK**(B15)。
- 幾秒鐘後，熱水首先從咖啡出水嘴流出，清潔和加熱設備的內部管道。
- 要手動中斷該功能，請再次按 **OK**。



請注意:


- 如果設備超過3-4天不使用，我們強烈建議在使用前先開啟設備後進行2-3次沖洗。
- 清洗後，咖啡渣盒 (A11) 內有水是正常的。

14. 製作咖啡

14.1 調整咖啡研磨

咖啡研磨已預設能正確準備咖啡，因此一開始不應有調節必要。

但是如果在製作幾杯咖啡後，發現咖啡口味太淡、不夠細膩或製作速度太慢(一次一滴)，可以透過研磨調節旋鈕調整 (A5)(圖8)。



請注意:

只能在咖啡研磨正在進行時，才能轉動研磨調節旋鈕。



如果咖啡給出速度過慢或根本沒有送出，向“7”的方向轉動一格。如需更醇厚的咖啡，請向“1”的方向轉動一格(不要一次轉動超過一格)。

調整後，至少必須製作2杯咖啡後，此調整才會明顯。如果這次調整無法獲得期望的結果，將旋鈕再轉動一格。

14.2 製作更熱的咖啡技巧

要製作更熱的咖啡，您應該：

- 按 **OK** (B15) 執行沖洗循環。
- 使用熱水功能用熱水溫杯(參見“19. 提供熱水”部分)。

- 提高咖啡溫度(參見章節“8. 設定溫度”)。



14.3 使用咖啡豆製作飲品



重要!

請勿使用生的、有調味的、焦糖或糖漬過的咖啡豆,因為會黏在咖啡研磨器上,造成設備損害。

1. 將咖啡豆裝入咖啡豆槽(A3,圖9)。



2. 置於咖啡出水孔下(A19):
 - 1個杯子,如果您想沖1份咖啡(圖10)。
 - 2個杯子,如果您想沖2份咖啡。
3. 將咖啡出水孔盡可能降低接近杯子,可讓咖啡口感更細膩(圖11)。
4. 選擇所需的咖啡:

飲品	杯量	可設定杯量	預設濃度
----	----	-------	------

Espresso 濃縮咖啡 (B10)	約 40 ml	約 20- 80ml	
Espresso 長濃縮咖啡 (B11)	約 120 ml	約 80- 180ml	
Long 長萃咖啡(B13)	約 160 ml	約 115 -250ml	
2x (B9) + Espresso濃縮咖啡 (B10)	約 40ml x 2 cups	--	
2x (B9) + Espresso 長濃縮咖啡(B11)	約 120 ml x 2 cups	--	

5. 準備開始。當咖啡完成後,觸控螢幕 (B) 上與所選圖示相對應的燈會閃爍,表示可以通過按下圖示在 3 秒內增加杯量。



請注意:

- 同時製作2杯“**espresso(濃縮咖啡)**”或“**espresso lungo(長濃縮咖啡)**”:
 - 按“2X”圖示 (B9)。與可供選擇的飲品對應的圖示亮起,“2X”圖示閃爍。按 或 :準備開始。
 - 或者,請執行以下操作:
 - 按 或 :準備開始,“2X”圖示閃爍幾秒鐘。在閃爍時按“2X”圖示。
- 設備製作咖啡時,可隨時按下咖啡圖示暫停製作。

一旦咖啡完成,設備已準備好製作下一杯飲品。





請注意:

- 使用過程中,觸控螢幕(B)上可能會顯示燈號。它們的含義在“23. 燈號說明”。
- 如需更熱的咖啡,請參考章節“14.2製作更熱的咖啡技巧”。

- 如果咖啡製作過程一次一滴、太淡、不夠細膩或溫度太低，請參考章節“24. 故障排除”。
- 若想根據個人口味客製飲料，請參考章節“14.6 客製化咖啡濃度與杯量”。

14.4 暫時改變咖啡濃度

如需要暫時改變咖啡濃度，請按  (B8):

	極淡
	淡
	中等
	濃
	極濃
	(參考章節“14.5使用預磨咖啡粉製作咖啡”)

請注意:

- 口味變化不會被保存，下次製作飲品時，設備會選擇預設定。
- 如果在暫時設定口味和製作飲料之間經過幾秒鐘，口味將恢復為預設定。

14.5 使用預磨咖啡粉製作咖啡



重要!


- 請勿在設備關機時添加預磨咖啡粉，否則會散佈在設備內並弄髒內部，這可能會損壞設備。
- 請勿使用大於一量匙(C2)的份量，這可能會弄髒設備內部或阻塞粉槽(A4)。

請注意:

當您使用預磨咖啡粉，一次只能沖煮一杯咖啡。






1. 重複按下  按鈕 (B8)，直到  燈號出現。
2. 確認粉槽是乾淨的後，加入一量匙預磨咖啡粉 (圖12)。



12



3. 將一個杯子置於咖啡出水孔(A19)(圖10)下。
4. 選擇您需要的咖啡:

飲品	杯量
 Espresso 濃縮咖啡(B10)	約 40 ml
 Espresso Lungo 長濃縮咖啡(B11)	約 120 ml
 Long 長萃咖啡(B13)	約 160 ml

5. 準備開始。製作完成後，觸控螢幕 (B) 上與所選圖示相對應的燈會閃爍，表示可以通過按下圖示在 3 秒內增加杯量。

重要! 使用預磨咖啡粉製作 LONG 長萃

咖啡 :

準備工作進行到一半時， 燈光閃爍。添加一量匙的預磨咖啡粉，然後按  OK (B15)。


請注意:

如果啟用“節能”模式，您可能需要等待幾秒鐘才能製作第一杯咖啡。

14.6 客製化咖啡濃度與杯量

設備會以預設定製作標準濃度與份量的咖啡 (參考章節“14.3使用咖啡豆製作飲品”中的表格)。


要客製化您的咖啡，請執行以下操作:


1. 將足夠大的杯子或玻璃杯放在咖啡出水孔 (A19) 下方。
2. 按  (B8) 選擇所需濃度 (參考章節“14.4 暫時改變咖啡濃度”)。


3. 長按要客製化的咖啡對應的圖示，圖示閃爍與所有警示燈閃爍4次。
 4. 鬆開圖示。圖示閃爍，設備開始製作咖啡。
 5. 一旦杯中的咖啡達到所需份量，再次按下咖啡圖示。
- 杯中咖啡的濃度和杯量現在已經被設定。

飲品	杯量	可設定杯量
 TrueBrew Over Ice™ Coffee 純萃冷冽(B12)	約 100 ml	約 40 ml - 240ml

15. Truebrew Over ICE™ Coffee 純萃冷冽

1. 加 3 個冰塊於一個大玻璃杯中(圖 13)，按下濃度選擇器  (B8) 選擇濃度(推薦濃或特濃)，然後放置玻璃杯在咖啡出水孔下。




2. 然後，按下  TrueBrew Over Ice™ 純萃冷冽按鈕製作咖啡(圖 14)。
3. 再加入 3 個冰塊在玻璃杯/咖啡中，以及任何所需的糖漿、糖或牛奶後，即可享用。

重要!

務必使用可以抵擋溫度急速變化的玻璃杯。

15.1 客製TrueBrew Over Ice™ 純萃冷冽濃度與杯量

1. 按  TrueBrew Over Ice™ 純萃冷冽按鈕(B12)， (B8) 閃爍表示需要選擇濃度。
2. 按  (B8) 選擇所需的強度(參考章節“14.4 暫時改變咖啡濃度”)。
3. 按住  TrueBrew Over Ice™ 純萃冷冽按鈕(B12) 直到按鈕和觸控螢幕(B)上的燈閃爍。
4. 達到所需杯量後，再次按  TrueBrew Over Ice™ 純萃冷冽按鈕(B12) 以保存新的杯量。

16. 製作卡布奇諾



燙傷危險!

準備當中會有蒸汽冒出。請小心避免燙傷。


1. 製作卡布奇諾時，需使用較大的咖啡杯。
2. 將牛奶倒入容器(最好帶手柄)以避免燙傷，每杯卡布奇諾約需要100ml。在選擇容器大小時，請注意牛奶體積將變至兩到三倍大。



請注意:


若想獲得更濃密的泡沫，必須使用冷藏(約5°C)的牛奶。為了避免泡沫不佳或有大型泡泡，必須經常清潔蒸汽管(A20)，參考章節“16. 蒸汽管使用後清潔”。




3. 確保蒸汽管選擇環(A21) 向下位於“CAPPUCCINO(卡布奇諾)”位置。
4. 蒸汽管(A20)可以稍微向外轉動，以便使用任何尺寸的容器。
5. 將蒸汽管放入牛奶容器中。切勿將黑色環浸入。



重要!

切勿用力轉動蒸汽管(圖15)。它可能會破裂!

6. 按下  圖示(B14)。ⓘ 指示燈(B1) 閃爍表示設備正在加熱。

- 設備已加熱完成， 指示燈熄滅， 圖示閃爍。
- 將蒸汽/熱水旋鈕  (A22) 轉到 I 位置。幾秒鐘後，蒸汽從蒸汽管中送出，使牛奶呈綿密泡沫狀與更加蓬鬆。如需更綿密的奶泡，將裝牛奶的容器向上方緩慢旋轉。
- 當您獲得所需的奶泡，將蒸汽旋鈕轉回到 0 位置，停止蒸汽送出。

燙傷危險！

在取出裝有奶泡的容器之前中斷蒸汽輸送，以免沸騰的牛奶飛濺造成燙傷。

- 將奶泡加入事先準備好的咖啡。卡布奇諾已準備就緒。依喜好加糖，如果需要可在奶泡上撒少量的可可粉。

請注意：


如果啟用“節能”功能，您可能需要等待幾秒鐘才能輸送蒸汽。



16.1 蒸汽管使用後清潔

在每次使用後都須清洗蒸汽管 (A20)，以避免牛奶殘留物的堆積或堵塞。


燙傷危險！

清潔蒸汽管時，會輸送少量熱水。避免接觸飛濺的水。

- 將蒸汽/熱水旋鈕  (A22) 轉到 I 位置，輸送少量水。然後將旋鈕轉回 0 位置停止輸送。
- 等待幾分鐘讓蒸汽管冷卻，然後逆時針旋轉蒸汽管並向下拉動移除 (圖 16)。



- 向下拆下噴嘴 (A21 - 圖 17)。
- 確保圖 18 中箭頭所示的兩個孔未被阻塞。如有必要，用牙籤清潔。





- 重新插入噴嘴並套上蒸汽管，將其向上推並轉動直至其連接。

17. 提供熱水

重要！燙傷危險

送出熱水時不可讓設備處於無人看顧的狀態。蒸汽管 (A20) 的出水嘴在輸送過程中變熱。

- 在蒸汽管 (A20) 下方放置一個容器 (盡可能靠近以避免濺出)
- 將蒸汽/熱水旋鈕  (A22) 轉到 I 位置。
- 要手動停止熱水輸送，請將蒸汽/熱水旋鈕  轉到 0 位置。

請注意：

如果“節能”模式開啟，您可能需要等待幾秒鐘才能提供熱水。

18. 清潔

18.1 清潔設備

以下零件必須定期清潔：

- 設備的內部管道；
- 咖啡渣盒 (A11)；
- 滴水盤 (A15) 和冷凝水盤 (A10)；
- 水箱 (A17)；
- 咖啡出水孔 (A19)；
- 蒸汽管 (A20 - “16.1 蒸汽管使用後清潔”)；
- 預磨咖啡粉槽 (A4)；
- 沖煮器 (A8)，打開沖煮器門 (A7) 可取得；
- 觸控螢幕 (B)


重要！

- 請勿使用溶劑、研磨性清潔劑或酒精清潔咖啡機。使用迪朗奇全自動義式咖啡機，您無需使用化學產品清潔機器。

- 除了滴水盤網格蓋板(A14)外，所有零件都不可在洗碗機中清洗。
- 不要用金屬物體去除硬垢或咖啡的殘留，否則可能會劃傷金屬或塑膠表面。

18.2 清潔設備內部管道


如果設備已有超過 3-4 天不使用，在使用前我們強烈建議將其打開，並且：

- 按  (B15) 執行 2-3 次沖洗循環。
- 提供熱水幾秒鐘(參考章節“17.提供熱水”)。

請注意：


清潔後，發現咖啡渣盒 (A11) 中有水是正常現象。

18.3 清潔咖啡渣盒

當  指示燈 (B2) 閃爍時，必須清空並清潔咖啡渣盒 (A11)。在清潔咖啡渣盒後，才能使用設備製作咖啡。即使沒有裝滿，在準備第一杯咖啡 72 小時後也會顯示清空咖啡渣盒訊息。為了正確計算 72 小時，切勿使用主開關 (A6) 關閉設備。

重要!燙傷危險

如果您連續製作多杯卡布奇諾，金屬杯托 (A12)會變熱。等待它冷卻後再觸摸它，並且只能從前面拿取它。




清潔時：

- 取出滴水盤 (A15) (圖19)，清空並清潔。
- 清空咖啡渣盒(A11)，並徹底清洗以消除底部所有殘留物。
- 檢查冷凝水盤 (A10) (紅色)，如果必要請一併清空。

18.4 清潔滴水盤和冷凝水盤

重要!

滴水盤 (A15) 配有液位指示器 (A13) (紅色)，顯示其所含的水位 (圖20)。在水位指示器從杯托(A12)凸出之前，必須清空並清潔滴水盤，否則水可能會溢出邊緣並損壞設備、其放置的表面或周圍區域。



要卸下滴水盤：

- 取出滴水盤及咖啡渣盒(A11)(圖19)。
- 移除杯架 (A12) 和滴水盤網格蓋板(A14)，並清空和清洗滴水盤和咖啡渣盒並清洗所有零件。
- 檢查紅色冷凝水盤(A10)，如有必要請一併清空。
- 重新裝上滴水盤與網格蓋板和咖啡渣盒。

重要!

卸下滴水盤時務必清空咖啡渣盒，即使裡面只有少量咖啡渣。


如果不這樣做，在接下來製作咖啡時，咖啡渣盒可能會裝得比預期還滿，造成機器堵塞。

18.5 清潔設備內部

觸電危險!

清潔內部零件之前，必須將設備關機 (參考章節“7. 關閉設備”)，並將插頭從電源插座拔掉。切勿將設備浸入水中。

- 定期檢查 (約每月一次) 設備內部，卸下滴水盤(A15)後可碰觸到的部分是否乾淨。如果有必要，請以隨附的刷子(C5)和海綿清除咖啡沈積物。
- 用吸塵器 (圖21) 去除所有殘留物。



18.6 清潔水箱

1. 定期清潔水箱(A17) (大約每月一次)，並在更換軟水器過濾器(C4) (若有) 時用濕布和少許溫和的洗滌液清潔。
2. 取下軟水過濾器(C4) (若有) 並用流水沖洗。
3. 更換軟水過濾器 (若有)，將水箱注滿清水並更換水箱。
4. (僅限帶軟水器過濾器的型號) 輸送約 100 毫升水以重新使用軟水過濾器。

18.7 清潔咖啡出水孔

1. 用海綿或布 (圖22A) 定期清潔咖啡出水孔 (A19)。



2. 檢查咖啡出水嘴孔是否堵塞。如果有必要，請用牙籤 (圖22B) 去除咖啡沉積物。

18.8 清潔預磨咖啡粉槽

定期 (約每月一次) 檢查預磨咖啡粉槽 (A4) 是否堵塞。如果有必要，請用隨附的刷子 (C5) 清除咖啡沉積物。

18.9 清潔沖煮器



咖啡沖煮器 (A8) 必須每月至少清潔一次。



重要!

當設備啟動時，不可拿出沖煮器。

1. 確保設備已正確關閉 (參考章節“7. 關閉設備”)。
2. 卸下水箱 (A17)。
3. 打開位於設備右側 (A7) (圖23) 的沖煮器門。



4. 向內按壓兩個帶顏色的按鈕，即可將沖煮器向外拉出 (圖24)。
5. 將沖煮器浸泡在水中約5分鐘，然後在水龍頭下沖洗乾淨。



重要!


僅用水沖洗

勿用洗碗精

勿用洗碗機

請勿用洗碗精清潔沖煮器，可能會損壞沖煮器。

6. 使用刷子 (C5) 清除任何留在沖煮器放置空間裡的咖啡殘渣。
7. 清潔後，將沖煮器重新推入設備內部，然後按下 PUSH 標誌，直到確實固定。



請注意：



如果沖煮器很難插入，在插入之前，輕壓兩個把手(圖 25)使其適應正確的大小。

- 一旦插入，確認兩個帶顏色的按鈕已經彈出。
- 關閉沖煮器門。
- 放回水箱。

19. 除鈣

當觸控螢幕 (B) 上的  燈 (B5) 閃爍並且只有  OK (B15) 和  ESC 圖標 (B14) 保持亮起時，為設備除鈣。






要立即除鈣，請按  OK 並按照第 4 點的說明進行操作。



要稍後為設備除鈣，請按  ESC。觸控螢幕上的  指示燈閃爍，提醒您設備需要除鈣。

重要！

- 使用前，閱讀除鈣劑包裝說明及標籤。
- 您只應使用迪朗奇除鈣劑。使用不適合的除鈣劑和/或除鈣執行不正確可能導致不包括在製造商保證內的故障。

要為機器除鈣，請執行以下操作：













- 按下  按鈕 (A23 - 圖 7) 關閉設備 (待機) (參考章節“7. 關閉設備”)；
- 清空滴水盤 (A15) 和咖啡渣盒 (A11)，並將兩者放回設備中。
- 按住  圖示 (B8) 直到  燈 (B5) 和  ESC 和  OK 圖示亮起。
- 完全清空水箱 (A17) 並卸下水過濾濾器 (C4) (如果有)。




- 將 100 毫升除鈣劑 (C3) 倒入水箱中，直至水箱標記 A 的位置，然後加入一公升水至水位 B (圖 26)，並把水箱放回設備內。
- 在蒸汽管 (A20) 和咖啡出水孔 (A19) 下方放置一個容量至少為 1.8 升的容器 (圖 27)。

重要！燙傷危險

含有酸的熱水從起泡器和咖啡噴口流出。注意避免接觸該溶液的飛濺物。


- 按  OK 圖示確認您已添加除鈣劑。除鈣程序開始。
- 幾分鐘後， ESC 圖示 (B14) 閃爍，表示蒸汽/熱水旋鈕  (A22) 必須轉到 I 位置。
- 當旋鈕轉到 I 位置時，除鈣程序啟動，除鈣劑液體從蒸汽管中流出。自動執行一系列沖洗和暫停，以清除設備內的所有水垢殘留物。
- 約 35 分鐘後，機器中斷除鈣， 指示燈 (B3) 閃爍。
- 設備現在已準備好可用清水沖洗。將之前用來收集除鈣劑溶液的容器清空，卸下水箱並倒空，用流動的清水將水箱沖洗乾淨，再將清水填滿到最高 MAX 水位後，把水箱放回設備內。
- 將收集除鈣劑溶液的空容器置於咖啡出水嘴和蒸汽管之下 (圖 27)。
- 按  OK 圖示： ESC 閃爍表示必須將  蒸汽/熱水旋鈕轉到 O 位置。
- 將  蒸汽/熱水旋鈕轉到 O 位置開始沖洗。熱水從咖啡出水嘴流出。
- 預設時間後， ESC 閃爍。將旋鈕轉到 I 位置。從蒸汽管繼續送出。當水箱中的水用完時， 燈 (B3) 亮。
- 設備現在準備好用清水進行第二次沖洗。清空用於收集沖洗水的容器。取出水箱，清空，在流水下沖洗，注入清水至最高 MAX 水位，更換軟水過濾濾器 (如果之前已卸下) 並放回設備中。
- 將用於收集沖洗水的容器空置在蒸汽管下方。
- 按  OK 圖示。設備僅從蒸汽管開始再次沖洗。
- 當水箱內的水用完時， 指示燈閃爍。

19. 清空用於收集沖洗水的容器，取出水箱並注入清水至最高MAX水位，並放回設備中。 ESC 圖標閃爍。
20. 將蒸汽/熱水旋鈕轉到 O 位置。
21. 清空並更換滴水盤(A15)和咖啡渣盒 (A11)。除鈣完成。

請注意!

- 如果除鈣週期沒有正確完成 (例如斷電)，建議重複週期。
- 除鈣後，咖啡渣盒含有水 (A11) 是正常的。
- 如果水箱未加至MAX水位，則在除鈣結束時，設備會要求進行第三次沖洗，以確保除鈣劑溶液已從機器內部管道中完全清除。









20. 設定水質硬度

經過一段時間的運作後，根據水質硬度  指示燈 (B5) 亮起。


設備預設的水質硬度值為 4。也可以根據各個地區的水質硬度，減少除鈣頻率。





20.1 測量水質硬度

1. 從包裝內拿出水質硬度試紙 (C1) (附於使用說明書)。
2. 將試紙完全浸入一杯水內一秒鐘。
3. 將試紙從水中取出後輕甩。約一分鐘後根據水質硬度會顯示 1、2、3 或 4 圖示的紅色方塊，每個方塊代表一個級別。

指示紙	水質硬度	相對應的設定
	低	
	中	
	高	
	極高	

20.2 設定水質硬度

1. 設備關閉 (待機)，但按下主開關 (A6) (圖 1)。
2. 按住  圖示 (B9) 直到觸控螢幕 (B) 上的圖標亮起。

3. 按下  圖示 (B8)。
 4. 再次按  圖示選擇水質硬度等級。
 5. 按  OK 圖示 (B15) 確認 (或  ESC (B14) 退出而不進行更改)。燈熄滅。
- 設備現在已重新設定新的水質硬度。

21. 軟水過濾器

如果您的型號沒有配備，建議您向迪朗奇客戶服務單位購買。

為了正確使用軟水過濾器，請遵循以下說明。


21.1 安裝軟水過濾器

1. 將軟水過濾器 (C4) 從包裝中取出。日期指示盤根據提供的過濾器而有所不同 (圖 28)。
2. 轉動日期指示盤，直到顯示未來兩個月的使用期間；



請注意!

如果正常使用設備，軟水過濾器約可維持兩個月。如果安裝了軟水過濾器的設備閒置，軟水過濾器最多可維持三個星期。


3. 如要啟動軟水過濾器，如圖所示將自來水從軟水過濾器的孔中流過，直到水從側面的開口流出一分鐘以上 (圖 29)。



4. 取出水箱 (A17) 並裝滿水。
5. 將軟水過濾器置入水箱並完全沉浸，讓它傾斜使氣泡釋出 (圖 30)。



6. 將軟水過濾器插入卡棒 (A18) (圖31) 並儘量推到底。
7. 放回水箱上蓋 (A16) (圖32)，且將水箱放回設備中。



8. 在蒸汽管下放置一個最小容量為500毫升的容器。
9. 轉動蒸汽/熱水旋鈕 (A22) 以提供熱水到 I 位置。
10. 輸送至少 500 毫升熱水後，再將蒸汽/熱水旋鈕轉到 O 位置。

軟水過濾器已啟用，您可以使用設備。

21.2 更換軟水過濾器

兩個月後 (見日期指示器) 或設備有3週未使用，應更換軟水過濾器：

1. 取出水箱 (A17) 和舊的軟水過濾器 (C4)。
2. 將新的軟水過濾器從其包裝中取出，並按照上一節說明進行操作。

新的軟水過濾器現已啟用，您可以使用設備。

22. 技術數據

電壓：	見產品銘牌標示
功率：	見產品銘牌標示
壓力：	1.5MPa (15 bars)
最大水箱容量：	60.86 fl oz (1.8 L)
尺寸長x寬x高：	(240x440x360 mm)
電線長度：	45.27 in (1150 mm)
重量：	20 lb (9.2 kg)
最大咖啡豆盒容量：	10.58 oz (300 g)















限用物質含有情況標示聲明





設備名稱:迪朗奇全自動義式咖啡機				型號:ECAM350.20.W		
單元	限用物質及其化學符號					
	鉛 (Pb)	汞 (Hg)	鎘 (Cd)	六價鉻 (Cr ⁺⁶)	多溴聯苯: (PBB)	多溴二苯醚: (PBDE)
塑料外殼和底盤	○	○	○	○	○	○
印刷電路板組裝	○	○	○	○	○	○
電機,閥門	○	○	○	○	○	○
電纜,接線,連接器	○	○	○	○	○	○
金屬零件 (包含加熱元件)	-	○	○	○	○	○
備考1. `超出0.1 wt %`及`超出0.01 wt %`係指限用物質之百分比含量超出百分比含量基準值。						
備考2. `○`係指該項限用物質之百分比含量未超出百分比含量基準值。						
備考3. `-`係指該項限用物質為排除項目。						

23. 燈號說明

顯示燈號	可能原因	處理方式
 閃爍	水箱內水量不足(A17)。	將水箱裝滿水和/或正確放入水箱，將水箱推到底直到卡入就定位。
 恆亮	水箱 (A17) 未正確放入。	將水箱正確放入並推到底。
 閃爍	咖啡渣盒 (A11) 已滿。	清空咖啡渣盒和滴水盤 (A15)，清潔並放回。重要：卸下滴水盤時務必清空咖啡渣盒，即使裡面只有少量咖啡渣。如果不這樣做，在接下來製作咖啡時，咖啡渣盒可能會裝得比預期還滿，造成設備堵塞。
 恆亮	清洗後，咖啡渣盒未正確放回 (A11)。	卸下滴水盤 (A15)，並放入咖啡渣盒。
 恆亮  閃爍	咖啡豆已用完。	補充咖啡豆槽 (A3) (圖 9)。
 恆亮  閃爍	已選“預磨咖啡”功能，咖啡粉槽沒有放置任何預磨咖啡粉 (A4)。	將預磨咖啡粉放置在粉槽內 (圖12)或取消“預磨咖啡”功能選擇。
	預磨咖啡粉槽 (A4) 堵塞。	以刷子 (C5) 輔助清空粉槽，參考章節“18.8清潔預磨咖啡粉槽”。
 閃爍  閃爍	預磨咖啡過細，造成咖啡製作過慢或根本沒有送出。	重複製作咖啡，在咖啡研磨機運作過程中，向“7”的方向轉動研磨調節旋鈕 (A5，圖8) 一格。如果至少製作2次咖啡後速度仍然太慢，重複矯正程序，把咖啡磨調節再轉一格，直到咖啡送出正確 (參考章節“14.1 調整咖啡研磨”)。如果問題沒有改善，請確認水箱 (A17) 已放入，將蒸汽/熱水旋鈕 (A22) 轉到 I 位置，釋放出一些水，直至水流正常。
	如果裝有軟水過濾器 (C4)，可能有氣泡進入內部而阻礙咖啡送出。	轉動蒸汽/熱水旋鈕 (A22) 至 I 位置排出少許水，直到水流量正常。




顯示燈號	可能原因	處理方式
 閃爍  閃爍	<p>預磨咖啡過細導致咖啡送出過慢或沒有送出。</p> <p>如果裝有軟水過濾器 (C4)，設備的內部迴路可能有氣泡進入，阻礙咖啡的送出。</p>	<p>減少使用預磨咖啡的量或使用不同類型的咖啡重複製作咖啡。如果問題仍然存在，請確保水箱 (A17) 已完全插入，將蒸汽/熱水撥盤 (A23) 轉到 I 位置並註入少量水，直到水流正常。</p> <p>轉動蒸汽/熱水旋鈕 (A22) 至 I 位置排出少許水，直到水流量正常。</p>
 閃爍  恆亮	<p>已要求預磨咖啡粉製成的長萃咖啡。</p>	<p>將一量匙 (C2) 的預磨咖啡粉放入預磨咖啡粉槽 (A4)，然後按  OK (B15) 繼續並完成準備工作。</p>
 恆亮  閃爍	<p>咖啡用量過多。</p>	<p>按  (B8) 選擇較淡的口味或減少預磨咖啡粉的量。</p>
 閃爍	<p>按下  TrueBrew Over Ice™ Coffee (純萃冷冽) 按鈕，但未選擇咖啡濃度。</p>	<p>選擇濃度，然後按下  TrueBrew Over Ice™ (純萃冷冽) 按鈕。</p>
 閃爍+閃爍  閃爍	<p>內部管道是空的。</p>	<p>將蒸汽/熱水旋鈕 (A22) 轉到 I 位置，直到停止輸送，將其轉回 0 位置。如果是在輸送熱水或蒸汽時出現警示，請將旋鈕轉到 0 位置。將蒸汽/熱水旋鈕轉到 I 位置，直到停止輸送，然後將其放回 0 位置。如果問題仍然存在，請確保水箱 (A17) 已完全放入。</p>
 恆亮	<p>設備內部很髒。</p>	<p>徹底清潔設備內部，參考章節“18. 清潔”。如果清洗後仍然顯示該信息，請聯繫客戶服務單位。</p>
→		



顯示燈號	可能原因	處理方式
 閃爍	沖煮器 (A8) 清洗後未放回。	重新放回沖煮器，參考章節“18.9 清潔沖煮器”單元。
 閃爍	指示蒸汽/熱水旋鈕 (A22) 必須打開或關閉。	如果蒸汽/熱水旋鈕打開，請將其關閉至 0 位置。 如果蒸汽/熱水旋鈕關閉，請將其打開至 1 位置以輸送蒸汽。
 閃爍 	機器必須除鈣。	除鈣流程說明請參考章節“19. 除鈣”。

24. 故障排除

以下列表是一些可能發生的故障。

如果依照這些描述仍無法解決問題，請聯絡客戶服務。

疑難問題	可能原因	解決方法
咖啡不熱。	沒有預熱咖啡杯。	利用熱水溫杯。請注意：可使用熱水功能。
	距離上次咖啡製成已過2-3分鐘，設備內部管道已經冷卻。	在製作咖啡之前，按下  圖示 (B15) 沖洗內部管道。
	咖啡溫度設定太低。	設定更高的咖啡溫度(參考章節“8.設定溫度”)。
咖啡味太弱或不夠細緻。	咖啡磨粉過於粗糙。	咖啡研磨運轉時，將研磨調節旋鈕 (A5)向“1”的方向轉動一格(圖8)。繼續轉一格，直到咖啡粉令人滿意。該效果僅在提供 2 杯咖啡後可見(參考章節“14.1 調整咖啡研磨”)。
咖啡送出太慢或一次一滴。	咖啡磨粉過於細密。	研磨機運轉時，將研磨調節旋鈕 (A5) 順時針向“7”轉動一格(圖 8)。繼續轉一格，直到送出的咖啡品質令人滿意。其效果僅在提供 2 杯咖啡後可見(參見章節“14.1 調整咖啡研磨”)。
		→

疑難問題	可能原因	解決方法
設備無法製作咖啡。	設備檢測到內部管道不乾淨，  燈 (B1) 閃爍。	等待設備再次準備好製作飲品，並重新選擇所需的飲品。如果問題仍然存在，請聯繫客戶服務單位。
無法取出沖煮器。	設備未正確關閉。	透過按下  按鈕 (A23) 將設備關閉 (參考章節“7.關閉設備”)。
除鈣結束時，設備要求進行第三次沖洗。	在兩個沖洗週期中，水箱尚未加注到最高水位 MAX 水位。	按照設備顯示的說明進行操作，但首先清空滴水盤 (A15) 以避免水溢出。
牛奶並未起泡。	蒸汽管 (A22) 和蒸汽/熱水噴嘴 (A21) 髒了。	請參考章節“16.1 蒸汽管使用後清潔”。
蒸汽送出停止。	安全設定，蒸汽管在3分鐘後會自動停止送出蒸汽。	等候，然後再次啟動蒸汽功能。
設備無法啟動。	設備沒有插到電源插座上。	將設備插頭插到電源插座上 (圖1)。
	主開關 (A6) 沒開。	按下主開關 (圖1)。
咖啡無法從一個或兩個出水孔送出。	咖啡出水孔 (A19) 阻塞。	參考章節“18.7 清洗咖啡出水孔”。

25. 保固說明及保固書

為保障消費者權益，針對台灣總代理天工生技股份有限公司售出，且於保固期間內正常使用下發生之故障，提供自購買日起算一年免費維修服務。保固書須具備購買日期資料，並加蓋授權銷售通路店章，才可享受有一年免費保固服務。

保固書若有遺失，亦可憑購買憑證(如發票或出貨單，需明確列出產品型號、購買通路、購買/出貨日期) 做替代。若無法出示保固書或有效購買憑證，將依設備機身號碼，以本代理商出貨日期作為保固起算日。

若有下列情形，即使於保固期間內，仍需酌收維修費用：

1. 因不可抗力之天災(水災、火災、地震、雷擊、颱風等)所造成設備損傷。
2. 因人為疏失(刮傷、摔壞、敲打、破裂、重擊、遺失、未妥善保管)所造成設備損傷。
3. 設備使用在非原始使用設計之目的所造成設備損傷。
4. 自行或經由非授權之第三方改裝、修改、維修等所造成設備損傷。
5. 使用非授權之零件與配件所造成設備損傷。
6. 使用延長線或轉接頭所造成設備損傷。
7. 設備配件如蒸汽管、濾水器、牛奶壺、上蓋等屬消耗品，不在保固範圍內。
8. 保固書內容與實際不符或未填寫。
9. 保固書內容無法辨識或經塗改。

保期期間外之維修服務，將酌收維修服務與零件費用。

保 固 書

為保障消費者權益，針對台灣總代理天工生技股份有限公司售出之迪朗奇全自動義式咖啡機，於保固期間內正常使用下發生之故障，提供自購買日起算一年免費維修服務。保固書需填妥以下內容，並加蓋授權銷售通路店章方可生效。

產品型號：

機身號碼：

購買通路：

購買日期：

授權通路店章

台灣總代理：天工生技股份有限公司
地址：台北市中山區南京東路三段70號4樓
消費者免付費電話：0809-099-905

CONTENTS

1. FUNDAMENTAL SAFETY WARNINGS.....	27
2. GENERAL INFORMATION.....	28
2.1 Instruction for Use.....	28
3. BEFORE USE.....	28
3.1 Checking the appliance	28
3.2 Installing the appliance.....	28
3.3 Connecting the appliance.....	29
3.4 Setting up the appliance.....	29
3.5 Cleaning and maintenance of materials in contact with food	29
3.6 Making cappuccinos and milk-based coffees...	29
4. INTRODUCTION.....	29
4.1 Letters in brackets	29
4.2 Troubleshooting and repairs.....	29
5. DESCRIPTION.....	29
5.1 Description of the machine	29
5.2 Description of the touch screen	30
6. BEFORE USE.....	30
6.1 Checking the machine.....	30
6.2 Installing the machine	30
6.3 Connecting the machine	30
6.4 Setting up the machine.....	30
7. TURNING THE MACHINE ON	31
8. TURNING THE MACHINE OFF	31
9. SETTING WATER HARDNESS	32
10. SETTING TEMPERATURE	32
11. AUTO-OFF.....	32
12. ENERGY SAVING.....	32
13. BEEP.....	33
14. DEFAULT VALUES (RESET)	33
15. RINSING.....	33
16. MAKING COFFEE.....	33
16.1 Adjusting the coffee grinder.....	33
16.2 Tips for a hotter coffee.....	33
16.3 Making coffee using coffee beans	34
16.4 Temporarily varying the coffee strength.....	35
16.5 Making coffee using pre-ground coffee.....	35
16.6 Customising strength and quantity	35
17. TRUEBREW OVER ICE™ COFFEE.....	36
17.1 Programming over ice lenght.....	36
18. MAKING CAPPUCCINO	36
18.1 Cleaning the frother after use.....	37
19. DELIVERING HOT WATER	37
20. CLEANING.....	37
20.1 Cleaning the machine	37
20.2 Cleaning the machine's internal circuit	38
20.3 Cleaning the coffee grounds container	38
20.4 Cleaning the drip tray and condensate tray.....	38
20.5 Cleaning the inside of the coffee machine.....	38
20.6 Cleaning the water tank.....	39
20.7 Cleaning the coffee spouts	39
20.8 Cleaning the pre-ground coffee funnel	39
20.9 Cleaning the infuser	39
21. DESCALING.....	40
22. SETTING WATER HARDNESS	41
22.1 Measuring water hardness	41
22.2 Setting water hardness	41
23. WATER SOFTENER FILTER	41
23.1 Installing the filter	41
23.2 Replacing the filter.....	42
24. TECHNICAL DATA.....	42
25. EXPLANATION OF LIGHTS.....	42
26. TROUBLESHOOTING	45

1. FUNDAMENTAL SAFETY WARNINGS

- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Designated use: this appliance is designed and made to prepare beverages based on coffee, milk and hot water. Use drinking water only in the tank. Never use the accessories to make beverages other than those described in these instructions. Any other use is considered improper and thus dangerous. The manufacturer is not liable for damage deriving from improper use of the appliance.
- The surface of the heating element remains hot after use and the outside of the appliance may retain the heat for several minutes depending on use.
- Clean all the components thoroughly, taking particular care with parts in contact with the milk.
- Cleaning and user maintenance shall not be made by children without supervision.
- Never clean by immersing the appliance in water.
- IMPORTANT: to prevent damage to the appliance, do not clean with alkaline detergents; use a soft cloth and, where applicable, neutral detergent.
- This is an household appliance only. It is not intended to be used in: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.
- If the plug or power cord is damaged, it must be replaced by customer services only to avoid all risk.
- Appliances with removable cord: avoid splashes of water on the power cord connector or socket at the back of the appliance.
- IMPORTANT: Models with glass surfaces: do not use the appliance if the surface is cracked.
- The coffee maker must not be placed inside a cabinet or kitchen unit during use

FOR EUROPEAN MARKETS ONLY:

- This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are above 8 years old and supervised. Keep the appliance and power cord away from children under 8 years of age.

- The appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they are supervised or have been given instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- Children shall not play with the appliance.
- Always unplug the appliance when left unattended and before assembly, taking apart or cleaning.



Surfaces marked with this symbol become hot during use (the symbol is present in certain models only).

This is an electrical appliance and may cause electric shock.

You should therefore follow these safety warnings:

- Never touch the appliance with damp hands or feet.
- Never touch the plug with damp hands.
- Make sure the socket used is freely accessible at all times, enabling the appliance to be unplugged when necessary.
- Unplug directly from the plug only. Never pull the cord as you could damage it.
- To disconnect the appliance completely you must unplug it from the mains socket.
- If the appliance is faulty, do not attempt to repair. Turn it off, unplug from the mains socket and contact Customer Services.
- Before cleaning the appliance, turn it off, unplug from the mains socket and allow to cool.

Important!

Keep all packaging (plastic bags, polystyrene foam) away from children.

CHOKING HAZARD. The appliance might contain small parts. Some of those small parts might be required to get disassembled during cleaning and maintenance operations. Handle with care and keep small parts out of reach of children.

Danger of burns!

This appliance produces hot water and steam may form while it is in operation.

During operation (automatic rinsing, hot beverage delivery, steam delivery, cleaning), avoid contact with splashes of hot water or steam.

When the appliance is in operation, the cup shelf could become very hot.

2. GENERAL INFORMATION

2.1 Instruction for Use

Read all the Instruction for Use carefully before using the appliance. Failure to follow this Instruction for Use may result in burns or damage to the appliance.

The manufacturer is not liable for damage deriving from failure to respect this Instruction for Use.

Please note:

These safety warnings are valid for all De'Longhi coffee machines.

Keep this leaflet together with the instructions accompanying the appliance.

If the appliance is passed to other persons, they must also be provided with this Instruction for Use.

3. BEFORE USE

3.1 Checking the appliance

After removing the packaging, make sure the product is complete and undamaged and that all accessories are present. Do not use the appliance if it is visibly damaged. Contact De'Longhi Customer Services.

3.2 Installing the appliance

When you install the appliance, you should respect the following safety warnings:

- The appliance gives off heat. After positioning the appliance on the worktop, leave a space of at least 3 cm between the surfaces of the appliance and the side and rear walls and at least 15 cm above the coffee maker.
- Water penetrating the appliance could cause damage. Do not place the appliance near taps or sinks.
- The appliance could be damaged if the water it contains freezes. Do not install the appliance in a room where the temperature could drop below freezing point.

- Arrange the power cord in such a way that it cannot be damaged by sharp edges or contact with hot surfaces (e.g. electric hot plates).

3.3 Connecting the appliance

Check that the mains power supply voltage corresponds to that indicated on the rating plate on the bottom of the appliance.

Connect the appliance to an efficiently earthed and correctly installed socket with a minimum current rating of 10A only.

If the power socket does not match the plug on the appliance, have the socket replaced with a suitable type by a qualified professional.

3.4 Setting up the appliance

The first time you use the machine, the water circuit is empty and the appliance could be very noisy. The noise becomes less as the circuit fills.

3.5 Cleaning and maintenance of materials in contact with food

- When used for the first time, or after 3 or 4 days without use, clean the appliance and the removable accessories that come into contact with water, coffee and milk, as indicated in the instructions for use. Check in the instructions which accessories are dishwasher safe.
- If the appliance is not used for more than 3 or 4 days, before making the first beverage, rinse the water circuit as described in this Instruction for Use.
- Be certain to take maximum care when carrying out all cleaning and maintenance operations described in the instructions for use and/or prompted by the display or warning lights of the appliance itself.

3.6 Making cappuccinos and milk-based coffees

- The appliance has been tested for use with cow's milk and the following products of plant origin: soya, rice and almond. No other type of milk or product of plant origin may be used.
- To clean the system, following use with any type of milk, please follow the standard procedures described in the instruction manual
- The cleaning methods provided by the manufacturer and described in the instructions do not guarantee the complete removal of allergens.
- In the case of confirmed or suspected allergies and intolerances, make sure that your machine has not been previously used with any milk or product of plant origin containing the allergens you are allergic or the substances you are intolerant to.

4. INTRODUCTION

Thank you for choosing this bean to cup espresso and cappuccino machine.

We hope you enjoy using your new appliance. Take a few minutes to read this Instruction for Use. This will avoid all risks and damage to the appliance.

4.1 Letters in brackets

The letters in brackets refer to the legend in the description of the appliance on pages 2-3.

4.2 Troubleshooting and repairs

In the event of problems, first try and resolve them by reading the information given in sections "20. meaning of the alarm indicators" and "21. Troubleshooting".


If this does not resolve the problem or you require further information, you should consult customer services by calling the number given on the annexed "Customer Service" sheet.

If your country is not among those listed on the sheet, call the number given in the guarantee. If repairs are required, contact De'Longhi customer services only. The addresses are given in the guarantee certificate provided with the machine.

5. DESCRIPTION

5.1 Description of the machine

(page 3 - A)

- A1. Beans container lid
- A2. Pre-ground coffee funnel lid
- A3. Beans container
- A4. Pre-ground coffee funnel
- A5. Grinding adjustment dial
- A6. Main switch
- A7. Infuser door
- A8. Infuser
- A9. Power cord
- A10. Condensate tray
- A11. Coffee grounds container
- A12. Cup tray
- A13. Drip tray water level indicator
- A14. Drip tray grille
- A15. Drip tray
- A16. Water tank lid
- A17. Water tank
- A18. Water softener filter housing
- A19. Coffee spouts (adjustable height)
- A20. Frother (removable)
- A21. Hot water and steam connection nozzle (removable)
- A22. Steam/hot water dial
- A23.  button: to turn the machine on and off (standby)

5.2 Description of the touch screen

(page 2 - B)

A number of icons on the touch screen have a double function. This is indicated in brackets in the description.

- B1. light flashing: the machine is heating up
- B2. light:
- on steadily: put the grounds container (A11) back
- flashing: the grounds container needs to be emptied
- B3. light:
- on steadily: insert the water tank (A17)
- flashing: insufficient water in the tank
- B4. light: general alarm (see section "25. Explanation of lights")
- B5. light:
- on steadily: descaling programme underway
- flashing: the machine needs descaling
- B6. : pre-ground function
- B7. : coffee strength
- B8. : strength selection
- B9. : to deliver 2 cups of "espresso" or "espresso lungo"
- B10. : "Espresso"
- B11. : "Espresso Lungo"
- B12. : TrueBrew Over Ice (TM) Coffee
- B13. : "Long"
- B14. **ESC**:
- on steadily: press to turn the steam function on (*when in the settings menu: press to exit the current programming*)
- flashing: the steam/hot water dial (A22) must be turned on or off
- B15. **OK**: to perform a rinse cycle.
(*When in the settings menu: press to confirm the current programming*)

Description of the accessories

(page 2 - C)

- C1. "Total hardness test" Indicator paper
- C2. Pre-ground coffee measuring scoop
- C3. Descaler
- C4. Water softener filter (certain models only)
- C5. Cleaning brush

6. BEFORE USE

6.1 Checking the machine

After removing the packaging, make sure the product is complete and undamaged and that all accessories (C) are present. Do not use the machine if it is visibly damaged. Contact De'Longhi Customer Services.

6.2 Installing the machine



Important!

When you install the machine, you should respect the following safety warnings:

- The machine gives off heat. After positioning the machine on the worktop, leave a space of at least 1.18 in / 3 cm between the surfaces of the machine and the side and rear walls and at least 5.9 in/15 above the coffee maker.
- Water penetrating the coffee machine could cause damage.
Do not place the machine near taps or sinks.
- The machine could be damaged if the water it contains freezes.
Do not install the machine in a room where the temperature could drop below freezing point.
- Arrange the power cord (A9) in such a way that it cannot be damaged by sharp edges or contact with hot surfaces (e.g. electric hot plates).

6.3 Connecting the machine



Important!

Check that the main power supply voltage corresponds to that indicated on the rating plate on the bottom of the machine. Connect the machine to an efficiently earthed and correctly installed socket with a minimum current rating of 10A only. If the power socket does not match the plug on the machine, have the socket replaced with a suitable type by a qualified professional.

6.4 Setting up the machine




Please note:


- Coffee has been used to factory test the machine and it is therefore completely normal for there to be traces of coffee in the grinder. The machine is, however, guaranteed to be new.
- You should customise water hardness as soon as possible following the instructions in section "22. Setting water hardness".

Proceed as described:


- Plug the machine into the mains socket and press the main switch (A6) on the back of the machine (fig. 1).



2. The light (B3) flashes on the touch screen (B): Remove the water tank (A17 - fig. 2), fill to the MAX line with fresh water (fig. 3A) then put back in the machine (fig. 3B).




3. The icon (B14 - fig. 5) flashes on the touch screen.
4. Place a container with a minimum capacity of 3.38 fl oz/100 ml under the frother (A20) (fig. 4).



5. Turn the steam/hot water dial (A22) to the "I" position (fig. 6) and press the OK icon (B15). Water is delivered from the frother.
6. When delivery stops automatically, the icon flashes on the touch screen to indicate that the steam dial must be turned back to the "O" position.

The machine goes off.

To use it, press the button (A23 - fig. 7).



Please note:

- The first time you use the machine, you need to make 4-5 cups of coffee before it starts to give satisfactory results.
- To enjoy your coffee even more and improve the performance of your machine, we recommend installing a water softener filter (C4) as described in section "23. Water softener filter". If your model is not provided with a filter, you can request one from De'Longhi Customer Services.

7. TURNING THE MACHINE ON

Please note:

Before turning the machine on, make sure the main switch (A6) on the back of the machine is pressed (fig. 1).

Each time the machine is turned on, it performs an automatic preheat and rinse cycle which cannot be interrupted. The machine is ready for use only after completion of this cycle.

Danger of burns!

During rinsing, a little hot water comes out of the coffee spouts (A19) and is collected in the drip tray (A15) underneath. Avoid contact with splashes of water.

- To turn the machine on, press the button (A23) (fig. 7). The light (B1) flashes on the touch screen (B) to indicate the machine is heating up.

While heating up, the machine performs a rinse cycle. As well as heating the boiler, this also heats the internal circuits by circulating hot water.



The machine is at temperature when the light on the touch screen goes off and the coffee icons come on.

8. TURNING THE MACHINE OFF

Whenever the coffee machine is turned off after being used to make coffee, it performs an automatic rinse cycle.

Danger of burns!


During rinsing, a little hot water flows from the coffee spouts (A19). Avoid contact with splashes of water.

- To turn the machine off, press the  button (A23 - fig. 7);
- the  light (B1) flashes on the touch screen and (if provided for) the machine performs a rinse cycle then goes off (standby).



Please note:

If you will not be using the machine for some time, unplug from the mains socket:

- first turn the machine off by pressing the  button;
- release the main switch (A6) (fig. 1).

Important!



Never press the main switch while the machine is on.





9. SETTING WATER HARDNESS



For instructions on setting water hardness, see section "22. Setting water hardness".

10. SETTING TEMPERATURE

If you want to modify the temperature of the water used to make the coffee (low, medium, high, maximum), proceed as follows:

1. With the machine off (standby), but the main switch pressed on (A6) (fig. 1);
2. Press and hold the **2x** icon (B9) until the lights on the touch screen (B) come on;
3. Press the  icon (B10);
4. Press the  icon again to select the required temperature:

	low
	medium
	high
	maximum

5. Press the  **OK** icon (B15) to confirm (or  **ESC** (B14) to exit without making the change).



The lights go off.






The machine returns to "standby" and the temperature is now programmed.



11. AUTO-OFF

The time can be changed so that the machine switches off after being idle for 15 or 30 minutes, or after 1, 2 or 3 hours.

To change the Auto-off setting, proceed as follows:







1. With the machine off (standby), but the main switch pressed on (A6) (fig. 1);
2. Press and hold the **2x** icon (B9) until the icons on the touch screen (B) come on;
3. Press the  icon (B11);
4. Select the required time interval by pressing the  icon again:

	15 min.
	30 min.
	1 hour
	2 hours
	3 hours

5. Press the  **OK** icon (B15) to confirm (or  **ESC** (B14) to exit without making the change). The lights go off. The auto-off time is now programmed.

12. ENERGY SAVING

Use this function to enable or disable energy saving. This mode is active by default, reducing energy consumption while the machine is on in compliance with current European regulations. To change the setting, proceed as follows:

1. With the machine off (standby), but the main switch pressed (A6) (fig. 1);
2. Press and hold the **2x** icon (B9) until the icons on the touch screen (B) come on.
3. Press the  icon (B13);
4. Press the  icon again to enable/disable the function:
 -  function enabled
 -  function disabled
5. Press the  **OK** icon (B15) to confirm (or  **ESC** (B14) to exit without making the change). The lights go off. The energy saving setting is now programmed.

**Please note:**

- When in energy saving mode, a few seconds may elapse before the first coffee is delivered as the machine must heat up again.

13. BEEP

This function enables or disables the beep. Proceed as follows:

1. With the machine off (standby), but the main switch pressed (fig. 1);
2. Press and hold the **2x** icon (B9) until the lights on the touch screen (B) come on.
3. Press the **2x** icon to enable/disable the function:
 - ●●●●● function enabled
 - ●●●●○ function disabled
4. Press the **OK** icon (B15) to confirm (or **ESC** (B14) to exit without making the change). The lights go off. The beep is now programmed.

14. DEFAULT VALUES (RESET)

This function resets all settings (temperature, auto-off, water hardness, energy saving and all quantity settings are reset to the default values).

1. With the machine off (standby), but the main switch pressed (fig. 1);
2. Press and hold the **2x** icon (B9) until the lights on the touch screen (B) come on.
3. Press the icon (B12). The bean icons (B7) on the touch screen flash;
4. Press the **OK** icon (B15) to reset the default values (or **ESC** (B14) to exit without making the change). The lights go off.

The settings and quantities of the beverages have been reset to the default values.

15. RINSING

Use this function to deliver hot water from the coffee spouts (A19) to clean and heat the machine's internal circuit.

Place a container with a minimum capacity of 3.38 fl oz/100ml under the coffee and hot water spouts.

**Important! Danger of burns.**

Do not leave the machine unattended while hot water is being delivered.

- 1) To activate the function, press **OK** (B15);
- 2) After a few seconds, hot water is delivered from the coffee spouts, cleaning and heating the machine's internal circuit.

- 3) To interrupt the function manually, press **OK** again.


**Please note:**

- If the machine is not used for more than 3-4 days, when switched on again, we strongly recommend performing 2/3 rinses before use;
- After cleaning it is normal to have water collected in the coffee ground container (A11).

16. MAKING COFFEE**16.1 Adjusting the coffee grinder**

The coffee grinder is set by default to prepare coffee correctly and should not require regulating initially.

However, if after making the first few coffees you find that the coffee is either too weak and not creamy enough or delivery is too slow (a drop at a time), this can be corrected by calibrating the coffee grinding using the adjusting dial (A5) (fig. 8).

**Please note:**

The grinding adjustment dial must only be turned when the coffee grinder is in operation.



If the coffee is delivered too slowly or not at all, turn one click clockwise towards 7. For fuller bodied creamier coffee, turn one click anticlockwise towards 1 (do not turn more than one click at a time otherwise the coffee could be delivered a drop

at a time).

These adjustments will only be evident after at least 2 cups of coffee have been delivered. If this adjustment does not obtain the desired result, turn the dial another click.

16.2 Tips for a hotter coffee

For hotter coffee, you should:

- perform a rinse cycle by pressing **OK** (B15);

- warm the cups with hot water using the hot water function (see section "19. Delivering hot water");
- increase the coffee temperature (see section "10. Setting temperature").




16.3 Making coffee using coffee beans



Important!

Do not use green, oily, flavored, caramelised or candied coffee beans as they could stick to the coffee grinder and make it unusable.

1. Fill the container (A3) (fig. 9) with coffee beans;



2. Place under the coffee spouts (A19):
 - 1 cup, if you want to make 1 coffee (fig. 10);
 - 2 cups if you want 2 coffees.
3. Lower the spouts as near as possible to the cup. This makes a creamier coffee (fig. 11);
4. Then select the desired coffee:

Recipe	Quantity	Program- mable quantity	Default strength
Espresso (B10)	≈ 1.35 fl oz / 40 ml	from ≈ 0.68 fl oz / 20 to ≈ 2.70 fl oz / 80ml	● ● ● ● ●
Espresso Lungo (B11)	≈ 4.06 fl oz / 120 ml	from ≈ 2.70 fl oz / 80 to ≈ 6.09 fl oz / 180ml	● ● ● ● ●
Long (B13)	≈ 5.41 fl oz / 160 ml	from ≈ 3.89 fl oz / 115 to ≈ 8.45 fl oz / 250ml	● ● ● ● ●
2x (B9) + Espresso (B10)	≈ 1.35 fl oz / 40 ml x 2 cups	--	● ● ● ● ●
2x (B9) + Espresso Lungo (B11)	≈ 4.06 fl oz / 120 ml x 2 cups	--	● ● ● ● ●

5. Preparation begins. When delivery finishes, the light corresponding to the selected icon flashes on the touch screen (B) indicating the possibility to increase the quantity in the cup, within 3 seconds, by pressing the icon.



Please note:

- To make 2 cups of "espresso" or "espresso lungo" at the same time:

- Press the "2X" icon (B9). The icons corresponding to the beverages available for selection light up and the "2X" icon flashes. Press or : Preparation begins.

Alternatively, proceed as follows:

- Press or : preparation begins and the "2X" icon flashes for a few seconds. Press the "2X" icon while it is flashing.

- While the machine is making coffee, delivery can be interrupted at any moment by pressing the coffee icon.

Once the coffee has been made, the machine is ready to make the next beverage.





























Please note:

- Lights may be displayed on the touch screen (B) during use. Their meaning is given in section "25. Explanation of lights".

- For hotter coffee, see section “16.2 Tips for a hotter coffee”.
- If the coffee is delivered a drop at a time, too weak and not creamy enough or too cold, read the tips in section “26. Troubleshooting”.
- To customise the beverages according to personal taste, see section “16.6 Customising strength and quantity”.

16.4 Temporarily varying the coffee strength

To temporarily vary the coffee strength, press  (B8):

    	EXTRA LIGHT
    	LIGHT
    	MEDIUM
    	STRONG
    	X-STRONG
	(see “16.5 Making coffee using pre-ground coffee”)

Please note:

- The variation in aroma is not saved and the next time a beverage is delivered automatically, the machine selects the default value.
- If a few seconds elapse between temporary customising of the aroma and delivery of the beverage, the aroma returns to the default value.

16.5 Making coffee using pre-ground coffee

Important!

- Never add pre-ground coffee when the machine is off or it could spread through the inside of the machine and dirty it. This could damage the machine.
- Never use more than 1 level measure (C2) or it could dirty the inside of the coffee machine or block the funnel (A4).




Please note:




If you use pre-ground coffee, you can only make one cup of coffee at a time.

1. Press the  icon (B8) repeatedly until the  light (B6) comes on.



2. Make sure the funnel is not blocked, then add one level measure of pre-ground coffee (fig. 12).





3. Place a cup under the coffee spouts (A19) (fig. 10).
4. Then select your required coffee:

Recipe	Quantity
 Espresso (B10)	≈ 1.35 fl oz / 40 ml
 Espresso Lungo (B11)	≈ 4.06 fl oz / 120 ml
 Long (B13)	≈ 5.41 fl oz / 160 ml

5. Preparation begins. When delivery finishes, the light corresponding to the selected icon flashes on the touch screen (B) indicating the possibility to increase the quantity in the cup, within 3 seconds, by pressing the icon.

 **Important! Making LONG coffee  using pre-ground coffee:**

Halfway through preparation, the  light flashes. Add one level measure of pre-ground coffee and press  OK (B15).


Please note:

If "Energy Saving" mode is active, you may have to wait a few seconds before the first coffee is delivered.

16.6 Customising strength and quantity

The machine is set by default to make coffee with a standard strength and quantity (see table in section “16.3 Making coffee using coffee beans”).

To customise the coffee, proceed as follows:


1. Place a sufficiently large cup or glass under the coffee spouts (A19);
2. Press  (B8) to select the required strength (see section “16.4 Temporarily varying the coffee strength”);

- Press and hold the icon corresponding to the coffee to be customised. The icon flashes and all the alarm lights flash 4 times;
- Release the icon. The icon flashes and the machine starts delivering coffee;
- As soon as the coffee in the cup reaches the required level, press the coffee icon again.

The strength and quantity of coffee in the cup has now been programmed.

17. TRUEBREW OVER ICE™ COFFEE

- Place 3 ice cubes in a large glass (fig. 13), press the strength selector  (B8) to choose a strength (strong or extra strong recommended), and place the glass under the brewing unit;









- Then, press the  TrueBrew Over Ice™ button to brew the coffee (fig. 14);
- Add 3 more ice cubes to the glass/coffee plus any syrup, sweetener or milk desired and enjoy

Important!

Always use glasses resistant to thermal shock.

17.1 Programming over ice length

- Press the  TrueBrew Over Ice™ button (B12):  (B8) flashes indicating that it is necessary to select the strength;
- Press  (B8) to select the required strength (see section "16.4 Temporarily varying the coffee strength") ;
- Press and hold the  over ice button (B12) until the button and the lights on the touch screen (B) flash;
- When the desired quantity is reached, press again the  over ice button to save new quantity.

Recipe	Quantity	Programmable quantity
 TrueBrew Over Ice™ Coffee (B12)	≈ 3.38 fl oz / 100 ml	from ≈ 1.35 fl oz / 40 ml to ≈ 8.11 fl oz / 240ml

18. MAKING CAPPUCCINO

Danger of burns!


During preparation steam is delivered. Take care to avoid burns.

- When preparing cappuccino, make the coffee in a large cup.
- Fill a container (preferably one with a handle to avoid burning) with about 100 grams/3.53 oz. of milk for each cappuccino. In choosing the size of the container, bear in mind that the milk doubles or triples in volume.

Please note:






For a richer denser froth, use milk at refrigerator temperature (about 5°C). To avoid milk with poor froth or large bubbles, always clean the frother (A20) as described in section "18.1 Cleaning the frother after use".

- Make sure the frother selection ring (A21) is positioned downwards in the "CAPPUCCINO" position;
- The frother can be turned slightly outwards to allow containers of any size to be used.
- The frother (A20) can be turned slightly outwards to allow containers of any size to be used.
- Immerse the frother in the milk container. Never immerse the black ring.



Important!

Never use force to turn the frother (fig. 15). It could break!

- Press the  icon (B14). The  light (B1) flashes to indicate the machine is heating up.
- When the machine is at temperature, the  light goes off and the  icon flashes.
- Turn the steam/hot water dial  (A22) to the I position. After a few seconds, steam is delivered from the frother, giving the milk a creamy frothy appearance and making it

more voluminous. For a thicker froth, rotate the container with slow movements in an upward direction.

8. When you have obtained the desired froth, stop steam delivery by turning the dial to the "0" position.

Danger of burns!

Interrupt steam delivery before removing the container with the frothed milk to avoid burns caused by splashes of boiling milk.

9. Add the frothed milk to the coffee prepared previously. The cappuccino is ready. Sweeten to taste and, if desired, sprinkle the froth with a little cocoa powder.

Please note:


If "Energy saving" is active, you may have to wait a few seconds before steam is delivered.



18.1 Cleaning the frother after use

Clean the frother (A20) each time you use it to avoid the build-up of milk residues or blockages.


Danger of burns!

When cleaning the frother, a little hot water is delivered. Avoid contact with splashes of water.

1. Deliver a little water by turning the steam/hot water dial  (A22) to the I position. Then stop delivery by turning the dial back to the 0 position.
2. Wait a few minutes for the frother to cool down, then rotate the frother anticlockwise and extract downwards (fig. 16).



3. Remove the connection nozzle downwards (A21 - fig. 17).
4. Make sure the two holes shown by the arrow in fig. 18 are not blocked. If necessary, clean with a pin.





5. Reinsert the connection nozzle and replace the frother on the nozzle, pushing it upwards and turning it until it is attached.

19. DELIVERING HOT WATER

Important! Danger of burns.

Never leave the machine unattended while delivering hot water. The spout of the frother (A20) becomes hot during delivery.

1. Place a container under the frother (A20) (as close as possible to avoid splashes).
2. Turn the steam/hot water dial  (A22) to the I position.
3. To stop hot water delivery manually, turn the steam/hot water dial  to the 0 position.

Please note!

If "Energy Saving" is active, you may have to wait a few seconds before hot water and steam are delivered.

20. CLEANING

20.1 Cleaning the machine

The following parts of the machine must be cleaned regularly:

- the internal circuit;
- coffee grounds container (A11);
- drip tray (A15) and condensate tray (A10);
- water tank (A17);
- coffee spouts (A19);
- frother (A20 - "18.1 Cleaning the frother after use");
- pre-ground coffee funnel (A4);
- infuser (A8), accessible after opening the infuser door (A7);
- touch screen (B).


Important!

- Do not use solvents, abrasive detergents or alcohol to clean the coffee machine. With De'Longhi superautomatic coffee machines, you don't need to use chemical products to clean the machine.

- None of the components of the machine can be washed in a dishwasher with the exception of the drip tray grille (A14).
- Do not use metal objects to remove encrustations or coffee deposits as they could scratch metal or plastic surfaces.

20.2 Cleaning the machine's internal circuit

If the machine is not used for more than 3/4 days, before using it again, we strongly recommend switching it on and:


- performing 2/3 rinse cycles by pressing  (B15);
- delivering hot water for a few seconds (section "19. Delivering hot water").



Please note:

After cleaning, it is normal to find water in the coffee ground container (A11).


20.3 Cleaning the coffee grounds container

When the  light (B2) flashes, the coffee grounds container (A11) must be emptied and cleaned. The machine cannot be used to make coffee until you have cleaned the grounds container. Even if not full, the empty grounds container message appears on the display 72 hours after the first coffee has been prepared. For the 72 hours to be calculated correctly, the machine must never be turned off with the main switch (A6).



Important! Danger of burns

If you make a number of cappuccinos one after the other, the metal cup tray (A12) becomes hot. Wait for it to cool down before touching it and handle it from the front only.



To clean (with the machine on):


- Remove the drip tray (A15) (fig. 19), empty and clean.
- Empty the grounds container (A11) and clean thoroughly to remove all residues left on the bottom.
- Check the condensate tray (A10) (red) and empty if necessary.

20.4 Cleaning the drip tray and condensate tray



Important!

The drip tray (A15) is fitted with a level indicator (A13) (red) showing the level of water it contains (fig. 20).



Before the indicator protrudes from the cup tray (A12), the drip tray must be emptied and cleaned otherwise the water may overflow the edge and damage the machine, the surface it rests on or the surrounding area.

To remove the drip tray:

1. Remove the drip tray and the coffee grounds container (A11) (fig. 19);
2. Remove the cup tray (A12) and drip tray grille (A14), then empty the drip tray and grounds container and wash all components;
3. Check the red condensate tray (A10) and empty if necessary;
4. Replace the drip tray complete with grille and grounds container.



Important!

When removing the drip tray, the grounds container must be emptied, even if it contains few grounds.

If this is not done, when you make the next coffees, the grounds container may fill up more than expected and clog the machine.

20.5 Cleaning the inside of the coffee machine




Danger of electric shock!

Before cleaning internal parts, the machine must be turned off (see section "8. Turning the machine off") and unplugged from the mains power supply. Never immerse the coffee machine in water.

1. Check regularly (about once a month) that the inside of the machine (accessible after removing the drip tray (A15)) is not dirty. If necessary, remove coffee deposits with the brush (C5) and a sponge;

2. Remove all the residues with a vacuum cleaner (fig. 21).




20.6 Cleaning the water tank

1. Clean the water tank (A17) regularly (about once a month) and whenever you replace the water softener filter (C4) (if provided) with a damp cloth and a little mild washing detergent;
2. Remove the filter (C4) (if present) and rinse with running water;
3. Replace the filter (if provided), fill the tank with fresh water and replace the tank;
4. (Models with water softener filter only) Deliver about 3.38 floz/100ml of water.

20.7 Cleaning the coffee spouts

1. Clean the coffee spouts (A19) regularly with a sponge or cloth (fig. 22A);



2. Check that the holes in the coffee spouts are not blocked. If necessary, remove coffee deposits with a toothpick (fig. 22B).

20.8 Cleaning the pre-ground coffee funnel

Check regularly (about once a month) that the pre-ground coffee funnel (A4) is not blocked. If necessary, remove coffee deposits with the brush (C5).



20.9 Cleaning the infuser

The infuser (A8) must be cleaned at least once a month.



The infuser may not be extracted when the machine is on.

1. Make sure the machine is correctly turned off (see section "8. Turning the machine off");
2. Remove the water tank (A17);
3. Open the infuser door (A7) (fig. 23) on the right side of the machine;



4. Press the two coloured release buttons inwards and at the same time pull the infuser outwards (fig. 24);
5. Soak the infuser in water for about 5 minutes, then rinse under the tap;




RINSE WITH WATER ONLY

NO WASHING DETERGENT - NOT DISHWASHER SAFE

Clean the infuser without using washing detergent as it could be damaged.

6. Use the brush (C5) to remove any coffee residues left in the infuser housing, visible through the infuser door;
7. After cleaning, replace the infuser by sliding it onto the internal support, then push the PUSH symbol fully in until it clicks into place;





Please note:

If the infuser is difficult to insert, before insertion, adapt it to the right size by pressing the two levers (fig. 25).

- Once inserted, make sure the two coloured buttons have snapped out;
- Close the infuser door;
- Put the water tank back.

21. DESCALING

Descalc the machine when the light (B5) on the touch screen (B) flashes and only the OK (B15) and ESC icons (B14) remain on.

To descale immediately, press OK and follow the instructions from point 4.

To descale the machine later, press ESC. The light flashes on the touch screen to remind you that the machine needs descaling.





Important!

- Before use, read the instructions and the labelling on the descaler pack.
- You should use De'Longhi descaler only. Using unsuitable descaler and/or performing descaling incorrectly may result in faults not covered by the manufacturer's guarantee.

To descale the machine, proceed as follows:

- Turn the machine off (standby) by pressing the button (A23 - fig. 7) (see section "8. Turning the machine off");
- Empty the drip tray (A15) and grounds container (A11) and put both back in the machine;
- Press and hold the icon (B8) until the light (B5) and the ESC and OK icons light up;
- Empty the water tank (A17) completely and remove the water softener filter (C4), if present;



- Pour the descaler (C3) into the tank up to level A (corresponding to a 3.38 fl oz / 100ml pack) marked on the inner surface of the tank, then add a litre of water up to level B (fig. 26) and put the water tank back in the machine;
- Place a container with a minimum capacity of 1.8 litres under the frother (A20) and coffee spouts (A19) (fig. 27);





Important! Danger of burns

Hot water containing acid flows from the frother and coffee spouts. Take care to avoid contact with splashes of this solution.

- Press the OK icon to confirm that you have added the descaler solution. The descaling procedure begins;
- After a few minutes, the ESC icon (B14) flashes to indicate the steam/hot water dial (A22) must be turned to the I position;
- When the dial has been turned to the I position, the descale programme starts and the descaler liquid comes out of the frother. A series of rinses and pauses are performed automatically to remove all the scale residues inside the coffee machine;

After about 35 minutes, the machine interrupts descaling and the light (B3) flashes.

- The machine is now ready for rinsing through with clean water. Empty the container used to collect the descaler solution. Extract the water tank, empty, rinse under running water, fill with fresh water up to the MAX level and put back in the machine;
- Place the container used to collect the descaler solution empty under the coffee spouts and frother (fig. 27);
- Press the OK icon: ESC flashes to indicate the steam/hot water dial must be turned to the O position;
- Turn the steam/hot water dial to the O position to start rinsing. Hot water comes out of the coffee spouts;
- After a preset time, ESC flashes. Turn the dial to the I position. Delivery continues from the frother. When the water in the tank has run out, the light (B3) comes on;
- The machine is now ready for a second rinse with clean water. Empty the container used to collect the rinse water. Extract the water tank, empty, rinse under running water, fill with fresh water up to the MAX level, replace the water softener filter (if previously removed) and put back in the machine;
- Place the container used to collect the rinsing water empty under the frother;
- Press the OK icon. The machine begins rinsing again from the frother only;

18. When the water in the tank has run out, the  light flashes;
 19. Empty the container used to collect the rinse water, remove the water tank and fill with fresh water up to the MAX level, then put back in the machine. The  **ESC** icon flashes;
 20. Turn the dial to the **0** position;
 21. Empty and replace the drip tray (A15) and grounds container (A11).
- Descaling is complete.

Please note!

- If the descaling cycle is not completed correctly (e.g. no electricity) we recommend repeating the cycle;
- After descaling, it is normal for the grounds container (A11) to contain water;
- If the water tank has not been filled to the MAX level, at the end of descaling, the machine requests a third rinse to guarantee that the descaler solution has been completely eliminated from the machine's internal circuits.







22. SETTING WATER HARDNESS



The  light (B5) comes on after a period of time established according to water hardness.

The machine is set by default for a hardness level of 4. The machine can also be programmed according to the hardness of the mains water in the various regions so that the machine needs to be descaled less often.





22.1 Measuring water hardness

1. Remove the "TOTAL HARDNESS TEST" indicator paper (C1) from its pack (attached to the English instructions);
2. Immerse the paper completely in a glass of water for one second;
3. Remove the paper from the water and shake lightly. After about a minute, 1, 2, 3, or 4 red squares form, depending on the hardness of the water. Each square corresponds to 1 level;

Indicator paper	Water hardness	Corresponding setting
	low	
	medium	
	high	

	maximum	
--	---------	---

22.2 Setting water hardness

1. With the machine off (standby), but the main switch (A6) pressed (fig. 1);
2. Press and hold the **2x** icon (B9) until the icons on the touch screen (B) come on;
3. Press the  icon (B8);
4. Select the water hardness level by pressing the  icon again :
5. Press the  **OK** icon (B15) to confirm (or  **ESC** (B14) to exit without making the change). The lights go off. The machine is now reprogrammed with the new water hardness setting.

23. WATER SOFTENER FILTER

Certain models are fitted with a water softener filter (C4). If this is not the case with your model, you are recommended to purchase one from De'Longhi Customer Services.

To use the filter correctly, follow the instructions below.


23.1 Installing the filter

1. Remove the filter (C4) from the packaging. The date indication disk varies according to the filter provided (fig. 28);
2. Turn the date disk to display the next 2 months of use.

Please note


The filter lasts about two months if the machine is used normally. If the coffee machine is left unused with the filter installed, it will last a maximum of 3 weeks.

3. To activate the filter, run tap water through the hole in the filter as shown in fig. 29 until water comes out of the openings at the side for more than a minute;




4. Extract the tank (A17) from the machine and fill with water;

5. Insert the filter in the water tank and immerse it completely for about ten seconds, sloping it and pressing it lightly to enable the air bubbles to escape (fig. 30).



6. Insert the filter in the filter housing (A18) and press as far as it will go (fig.31);
7. Close the tank with the lid (A16 - fig. 32), then replace the tank in the machine;



8. Position a container with a minimum capacity of 16.90 fl oz / 500ml under the frother (A20).
9. Deliver hot water by turning the steam/hot water dial (A22) to the I position.
10. Deliver at least 16.90 fl oz / 500 ml of hot water, then turn the steam/hot water dial to the 0 position.

The filter is now active and you can use the coffee machine.

23.2 Replacing the filter

After two months (see date indicator) or when the machine has not been used for 3 weeks, you should replace the filter:

1. Extract the tank (A17) and exhausted filter (C4);
2. Take the new filter out of its packet and proceed as described in points 2 to 10 in the previous section.

The new filter is now active and you can use the coffee machine.










24. TECHNICAL DATA

Voltage:	See rating label
Absorbed power:	" " "
Pressure:	1.5MPa (15 bars)
Max. water tank capacity:	60.86 fl oz (1.8 L)
Size LxDxH:	9.45x17.32 x 14.17in. (240x440x360 mm)
Cord length:	45.27 in (1150 mm)
Weight:	20 lb (9.2 kg)
Max. beans container capacity:	10.58 oz (300 g)
















25. EXPLANATION OF LIGHTS






LIGHTS DISPLAYED	POSSIBLE CAUSE	REMEDY
<p>FLASHING</p>	Insufficient water in the tank (A17)	Fill the tank with water and/or insert it correctly, pushing it as far as it will go until it clicks into place.
<p>ON STEADILY</p>	The tank (A17) is missing or not correctly in place	Insert the tank correctly, pushing it as far as it will go until it clicks into place.



LIGHTS DISPLAYED	POSSIBLE CAUSE	REMEDY
 <p>FLASHING</p>	The grounds container (A11) is full	Empty the grounds container and drip tray (A15), clean and replace. Important: when removing the drip tray, the grounds container must be emptied, even if it contains few grounds. If this is not done, when you make the next coffees, the grounds container may fill up more than expected and clog the machine.
 <p>ON STEADILY</p>	After cleaning, the grounds container (A11) has not been replaced	Remove the drip tray (A15) and insert the grounds container.
 <p>ON STEADILY</p>  <p>FLASHING</p>	<p>The coffee beans have run out</p> <p>The pre-ground coffee funnel (A4) is clogged</p>	<p>Fill the beans container (A3 - fig. 9).</p> <p>Empty the funnel with the help of the brush (C5) as described in section "20.8 Cleaning the pre-ground coffee funnel".</p>
 <p>ON STEADILY</p>  <p>FLASHING</p>	<p>The pre-ground coffee function has been selected without placing any pre-ground coffee in the funnel (A4)</p> <p>The pre-ground coffee funnel (A4) is clogged</p>	<p>Place pre-ground coffee in the funnel (fig. 12) or deselect the "pre-ground" function.</p> <p>Empty the funnel with the help of the brush (C5) as described in section "20.8 Cleaning the pre-ground coffee funnel".</p>
 <p>FLASHING</p>	The machine must be descaled	The descaling procedure described in section "21. Descaling" needs to be performed.
 <p>FLASHING</p>  <p>FLASHING</p>	<p>The grinding is too fine and the coffee is delivered too slowly or not at all</p> <p>If the water softener filter (C4) is present, an air bubble may have been released inside the circuit, obstructing delivery</p>	<p>Repeat coffee delivery and turn the grinding adjustment dial (A5 - fig. 8) one click clockwise towards "7" while the coffee grinder is in operation. If after making at least 2 coffees delivery is still too slow, repeat the correction procedure, turning the grinding adjustment dial another click until delivery is correct (see section "16.1 Adjusting the coffee grinder"). If the problem persists, make sure the water tank (A17) is fully inserted, turn the steam/hot water dial (A22) to the I position and deliver a little water until the flow is regular.</p> <p>Deliver a little water by turning the steam/hot water dial (A22) to the I position until the flow is regular.</p>





LIGHTS DISPLAYED	POSSIBLE CAUSE	REMEDY
 FLASHING  FLASHING	<p>The pre-ground coffee used is too fine and the coffee is delivered too slowly or not at all</p> <p>If the water softener filter (C4) is present, an air bubble may have been released inside the circuit, obstructing delivery</p>	<p>Repeat coffee delivery using less pre-ground coffee, or a different type. If the problem persists, make sure the water tank (A17) is fully inserted, turn the steam/hot water dial (A22) to the I position and deliver a little water until the flow is regular.</p> <p>Deliver a little water by turning the steam/hot water dial (A22) to the I position until the flow is regular.</p>
 FLASHING  +  OK ON STEADILY	<p>A LONG coffee with pre-ground coffee has been requested</p>	<p>Put one level measure (C2) of pre-ground coffee into the pre-ground coffee funnel (A4) and press  OK (B15) to continue and complete preparation.</p>
 ON STEADILY  FLASHING	<p>Too much coffee has been used</p>	<p>Select a lighter taste by pressing  (B8) or reduce the quantity of pre-ground coffee.</p>
 FLASHING	<p>The  TrueBrew Over Ice™ Coffee button have been pressed without selection the strength</p>	<p>Select the strength and then press the  TrueBrew Over Ice™ button.</p>
 FLASH. + FLASH.  FLASHING	<p>The water circuit is empty</p>	<p>Turn the steam/hot water dial (A22) to the I position until delivery stops, then bring it back to the 0 position. If the alarm occurs while hot water or steam is being delivered, turn the dial to the 0 position. Turn the steam/hot water dial to the I position until delivery stops, then bring it back to the 0 position. If the problem persists, make sure the water tank (A17) is fully inserted.</p>
 ON STEADILY	<p>The inside of the machine is very dirty</p>	<p>Clean the inside of the machine thoroughly, as described in section “20. Cleaning”. If the message is still displayed after cleaning, contact Customer Services.</p>



LIGHTS DISPLAYED	POSSIBLE CAUSE	REMEDY
 FLASHING	The infuser (A8) has not been replaced after cleaning	Insert the infuser as described in section “20.9 Cleaning the infuser”.
 FLASHING	Indicates the steam/hot water dial (A22) must be turned on or off	If steam/hot water dial is on, turn it off to the 0 position. If the steam/hot water dial is off, turn it on to the I position to deliver steam.
 FLASHING  ESC +  OK ON STEADILY	The machine must be descaled	The descaling procedure needs to be performed as soon as possible (see section “21. Descaling”).

26. TROUBLESHOOTING

Below is a list of some of the possible malfunctions.

If the problem cannot be resolved as described, contact Customer Services.

PROBLEM	POSSIBLE CAUSE	REMEDY
The coffee is not hot.	The cups were not preheated.	Warm the cups by rinsing them with hot water (Please note: you can use the hot water function).
	The internal circuits of the machine have cooled down because 2/3 minutes have elapsed since the last coffee was made.	Before making coffee, rinse the internal circuits by pressing the  icon (B15).
	A low coffee temperature is set.	Set a higher coffee temperature in the menu (see section “10. Setting temperature”).
The coffee is weak or not creamy enough.	The coffee is ground too coarsely.	Turn the grinding adjustment dial (A5) one click anticlockwise towards 1 while the coffee grinder is in operation (fig. 8). Continue one click at a time until coffee delivery is satisfactory. The effect is only visible after delivering 2 coffees (see section “16.1 Adjusting the coffee grinder”).
		

PROBLEM	POSSIBLE CAUSE	REMEDY
The coffee is delivered too slowly or a drop at a time.	The coffee is ground too finely.	Turn the grinding adjustment dial (A5) one click clockwise towards 7 while the coffee grinder is in operation (fig. 8). Continue one click at a time until coffee delivery is satisfactory. The effect is only visible after delivering 2 coffees (see section “16.1 Adjusting the coffee grinder”).
The machine will not make coffee	The machine has detected impurities in its internal circuits, the  light (B1) flashes	Wait for the machine to be ready for use again and reselect the required beverage. Contact Customer Services if the problem persists.
The infuser (A8) cannot be extracted	The machine has not been turned off correctly	Turn the machine off by pressing the  button (A23) (see section “8. Turning the machine off”).
At the end of descaling, the machine requests a third rinse	During the two rinse cycles, the water tank has not been filled to the MAX level.	Follow the instructions displayed by the machine, but first empty the drip tray (A15) to avoid the water overflowing.
The frothed milk has large bubbles	The milk is not cold enough or is not semi-skimmed	You should ideally use skimmed or semi-skimmed milk at refrigerator temperature (about 5°C). If the result is not as you wished, try changing brand of milk.
The milk is not frothed	The frother (A22) and steam/hot water connection nozzle (A21) are dirty	Clean as described in section “18.1 Cleaning the frother after use”.
Steam delivery stops	A safety device stops steam delivery	Wait a few minutes and then enable the steam function again.
The machine does not turn on	The machine is not plugged into the mains socket	Plug into the mains socket (fig. 1).
	The main switch (A6) is not turned on	Press the main switch (fig. 1).
Coffee does not come out of one or both of the coffee spouts	The coffee spouts (A19) are blocked	Clean as described in section “20.7 Cleaning the coffee spouts”.

Register Now 
www.delonghi.com/register

