

IMPORTANT SAFEGUARDS



Danger!

- The appliance must not be placed immediately under a fixed power socket.
- Do not use the appliance near showers, bathtubs, sinks, swimming pools, etc.
- If the power cable is damaged, it must be replaced by the manufacturer, an authorised service centre or a qualified electrician in order to eliminate all risk.
- The appliance must be installed with the controls out of reach of someone taking a bath or shower.



Important!

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children of less than 3 years should be kept away unless continuously supervised.
- Children aged from 3 years and less than 8 years shall only switch on/off the appliance provided that it has been placed or installed in its intended normal operating position and they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children aged from 3 years and less than 8 years shall not plug in, regulate and clean the appliance or perform user maintenance.

CAUTION — Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.

ATTENTION: To avoid the safety system resetting accidentally, this appliance must not be powered through an external on/off device such as a timer, or connected to a circuit which is turned off and on regularly by the energy supplier.



Danger of burns!!

- **WARNING:** To avoid overheating, never under any circumstances cover the appliance during operation as this would lead to a dangerous rise in temperature.



Please note:

- The use of extension leads is not recommended. However if they cannot be avoided, follow the instructions accompanying the extension lead and never exceed the power limit marked on the extension.
- The heater must be positioned at least 50 cm from furniture or other objects.
- Do not use the appliance in rooms with a floor area of less than 4m².
- Before putting the appliance away, make sure it is completely off and unplugged from the mains socket. Do not store in dusty atmospheres.
- Do not rest anything on the appliance.
- Do not use the appliance to dry laundry. Do not obstruct the air intake and outlet grilles (danger of overheating).
- Do not use the appliance near walls, furniture, curtains, etc.
- When used for the first time, the appliance gives off an odour due to heating.

Safety functions

- **Safety device:** the appliance is fitted with a safety device which switches it off in the event of accidental overheating (e.g. obstruction of air intake and outlet grilles, motor turning slowly or not at all). To reset, unplug the appliance from the mains socket for a few minutes, re-

move the cause of overheating then plug in again. If the appliance doesn't work please contact the De'Longhi Customer Service.

Disposing of the appliance



In compliance with European directive 2002/96/EC, the appliance must not be disposed of with household waste, but taken to an authorised waste separation and recycling centre.

INTRODUCTION

Thank you for choosing a De'Longhi product.
Please take a few minutes to read these instructions.
This will avoid all risks and damage to the appliance.

Symbols used in these instructions

Important warnings are identified by the symbols below.
It is important to respect the warnings.

Failure to respect the warnings could lead to electric shock, serious injury, burns, fire or damage to the appliance.



Danger!

Failure to observe the warning may result in life threatening injury by electric shock.



Important!

Failure to observe the warning could result in injury or damage to the appliance.



Danger of burns!!

Failure to observe the warning could result in burns or scalds.



Please note:

This symbol indicates recommendations and important information for the user.

DESCRIPTION

(see fig. 1)

- A** Function selector (certain models only)
- B** Room thermostat
- C** Indicator light (certain models only)

USE

Installation


The appliance must be used in the portable configuration only.
This is a household appliance only.
The appliance must not be positioned directly underneath a fixed power point.

Electrical connection


- Before plugging into the mains, make sure the voltage of your mains supply corresponds to the value V indicated on the appliance and that the socket and power line are appropriate for the load required.
- THIS APPLIANCE COMPLIES WITH DIRECTIVE 2004/108/EC ON ELECTROMAGNETIC COMPATIBILITY.

Operation and use

Models with function selector and room thermostat

- Turn the thermostat (if present) clockwise as far as it will go to the maximum position.
- **Summer use (fan only):** turn the function selector to position . (if present, the indicator light comes on)
- **Low power heating:** turn the function selector to "1". (if present, the indicator light is on)
- **Maximum power heating:** turn the function selector to "2". (if present, the indicator light is on)
- **Turning off:** turn the function selector to "0".
You are recommended to unplug the appliance when not in use.


Models with thermostat only

To turn the appliance on, turn the thermostat clockwise as far as it will go to the maximum position. (if present, the indicator light comes on). To turn the appliance off completely, turn the thermostat to minimum  and unplug from the mains.

Adjusting the thermostat

When the room has reached the required temperature, turn the thermostat slowly anticlockwise until the appliance goes off and no further. The thermostat will then keep room temperature at the selected level automatically.

Freeze protection

Turn the function selector to "2" and the thermostat to .
The appliance is set to maintain a temperature of about 5°C in the room with minimum energy consumption.

MAINTENANCE

- Always unplug from the mains socket before cleaning.
- Clean the air intake and output grilles frequently, if necessary using a vacuum cleaner to remove accumulated dirt.
- Never use abrasive powders or solvents.

TECHNICAL CHARACTERISTICS

Power supply	See rating plate
Absorbed power	"