

IMPORTANT SAFEGUARDS

Read all the Instruction for Use carefully before using the appliance. Keep this Instructions for Use.

- If the power cable is damaged, it must be replaced by the manufacturer or the manufacturer's Customer Experience in order to avoid all risk.
- Never immerse the appliance in water.
- When in operation, accessible external surfaces and the lid can become very hot. Always use the handgrip, handles and buttons. Use oven gloves if necessary.
- This electrical appliance operates at high temperatures which could cause burns.
- This appliance shall not be used by children from 0 year to 8 years. This appliance can be used by children aged from 8 years and above if they are continuously supervised. This appliance can be used by people with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Keep the appliance and its cord out of reach of children aged less than 8 years. Cleaning and user maintenance shall not be made by children.
- Do not preheat the appliance when empty.
- Do not use the appliance without food, you might damage it.
- This is household appliance only.

It is not intended to be used in: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.

- The appliance must not be operated by a timer or a separate remote control system.



Danger!

Failure to observe the warning may result in life threatening injury by electric shock.

- Before using the appliance, check that the voltage of the mains power supply corresponds to the value indicated on the appliance rating plate.
- Connect the appliance to an efficiently earthed socket with a minimum current rating of 10A only.
The manufacturer declines all liability in the event that this important accident-prevention rule is not respected.



Danger of burns!

Failure to observe the warnings could result in scalds or burns.

- While in operation, the appliance becomes hot.
DO NOT LEAVE WITHIN REACH OF CHILDREN.
- Move the appliance by the handles only.
Never move the appliance using the bowl handgrip.
- Never leave the power cable hanging from the edge of the surface the appliance is resting on where it could be grasped by a child or get in the way of the user.
- Hot steam may come out of the vents. Take great care!



Important!

Failure to observe the warnings may result in life threatening injury or damage to the appliance.

- Never locate the appliance near sources of heat.
- The bowl fits automatically onto the central pin.
To avoid damage, never rotate it manually to find the right position.
- Never insert anything into the ventilation openings.
Make sure they are unobstructed.
- Do not fill the bowl with liquid above the MAX level (R).
- Do not put more oil in the bowl than the maximum level on the oil measure (level 5)



Please note:

This symbol identifies important advice or information for the user.

- Before using the appliance for the first time, remove any paper and other material inside the oven such as protective cardboard, booklets, plastic bags, etc.
- Before using the appliance for the first time, wash the bowl, paddle and lid in hot water and washing up liquid. At the end of the operation, dry all components thoroughly and remove any water left in the bottom of the bowl.
- It is normal for the appliance to give off a “new” smell when used for the first time. Ventilate the room.
- The appliance must be kept at a distance of at least 20 cm from the mains power socket to which it is connected.

TECHNICAL DATA

size (LxHxD): 395x325x270mm

weight: 5kg

For further information, see the rating plate on the appliance.

CE The appliance complies with the following EU directives:

- Low Voltage Directive 2006/95/EC and subsequent amendments;
- This appliance complies with EC directive 2004/108/EC on electromagnetic compatibility and European regulation no. 1935/2004 of 27/10/2004 on food contact materials.
- European Stand-by Regulation 1275/2008.

DISPOSAL



In compliance with European directive 2002/96/EC, the appliance must not be disposed of with household waste, but taken to an authorised waste separation and recycling centre.

DESCRIPTION OF APPLIANCE

- A Lid
- B Hot air discharge grille
- C Removable section of the lid (with viewing window in certain models only)
- D Maximum level MAX
- E Paddle
- F Ceramic coated bowl
- G Handgrip slide
- H Bowl handgrip
- I Oil measure (level from 1 to 5)
- L Handle for lifting the appliance
- M Appliance body
- N Removable timer (if present)
- O Buttons to release the removable section of the lid
- P ON/OFF button with light
- Q Lid open button
- R Condensate tray

SETTING UP THE APPLIANCE



Please note: Before using the appliance for the first time, wash the bowl (F), paddle (E) and removable section of the lid (C) thoroughly in hot water and washing up liquid.

Proceed as follows:

- Open the lid (A) by pressing button (Q) (fig. 1).
- Release the removable section of the lid (C) by pressing the two buttons (O) (fig. 2).
- Lift the bowl handgrip (H) until you hear a “click” (fig. 3).
- Extract the bowl (F) by pulling upwards (fig. 4).
- Extract the paddle (E) from its housing (fig. 5).
- Wash the bowl (F), paddle (E) and removable section of the lid (C) (fig. 6).
- At the end of the operation, dry all components thoroughly and remove any water left in the bottom of the bowl (F).

COOKING WITH THE PADDLE



Please note: This type of cooking is particularly suitable for cooking potatoes.

- Put the bowl (F) back in the appliance body (M), making sure it is correctly positioned.
- Lower the bowl handgrip (H) using the slide (G) (fig. 7).
- Insert the paddle (E), making sure it is correctly positioned on the pin at the bottom of the bowl.
- Place the ingredients to be cooked in the bowl (F), respecting the quantities given in the cooking tables/recipes.
- If required by the cooking procedure, add oil, referring to the quantities indicated in the cooking tables/recipes and using the measure (I).
- Close the lid (A).
- Plug the appliance into the mains socket.
- Press the ON/OFF button (P). The light in the button comes on.
- Cooking begins.

COOKING WITHOUT THE PADDLE

- Put the bowl (F) back in the appliance (M), making sure it is correctly positioned.
- Lower the bowl handgrip (H) using the slide (G) (fig. 7).
- Place the ingredients to be cooked in the bowl (F), respecting the quantities given in the cooking tables/recipes.
- If required by the cooking procedure, add oil, referring to the quantities indicated in the cooking tables/recipes and using the measure (I).
- Close the lid (A).
- Plug the appliance into the mains socket.
- Press the ON/OFF button (P). The light in the button comes on.

- Cooking begins.

MODELS WHIT TIMER

- Set the cooking time by pressing the button on the timer (N) (fig. 8). The minutes set appear on the display.
- Immediately afterwards, the numbers begin to flash. This means the cooking time has begun. The last minute is displayed in seconds.
- If you make a mistake, you can set the new cooking time by holding the button down for more than two seconds. When the display has reset, repeat the operation.
- The timer indicates the end of cooking time with two series of beeps separated by a 20 second gap.

To turn off the signal, just press the timer button.

 **Please note:** The timer does not turn the appliance off.

 **Please note:** When cooking with the paddle, to guarantee best results, the paddle (E) begins to turn a few minutes after cooking begins.

 **Please note:** When cooking without the paddle, the pin on the bottom of the bowl still turns a few minutes after cooking begins.

 **Please note:** During cooking, you can lift up the lid (A) to add ingredients or check cooking progress. Ventilation stops briefly, then starts again when you close the lid.

 **Please note:** If the ON/OFF button is on, extracting the bowl turns the appliance off. It starts working again when the bowl is reinserted.

- Turn the appliance off by pressing the ON/OFF button (P).

REMOVABLE TIMER (IF PRESENT)

- To extract the timer (N) from its housing, press the left side of the display, then turn (fig. 9) and pull off (fig. 10).
- To put the timer back, thread it onto the pins in the housing and push as far as it will go until it catches (fig. 11), then turn as shown in fig. 12.

 **Please note:** To replace the timer battery, contact the manufacturer's authorised Customer Experience.

CLEANING AND MAINTENANCE

 **Danger!** Before cleaning the appliance, always unplug from the mains socket and allow to cool.

Never immerse the appliance in water and never place under running tap water.

If water gets into the appliance, it could cause electric shock.

- Wash the bowl (F), paddle (E) and removable section of the lid (C) thoroughly in hot water and washing up liquid. The bowl is dishwasher safe. Frequent washing could reduce the properties of the ceramic coating.
- Clean the hot air discharge grille (B) without removing it.

 **Please note:** *Do not use sharp, abrasive or metallic utensils to remove food from the bowl as this can damage the ceramic coating. Clean with a soft cloth and neutral detergent only.*

TROUBLESHOOTING

Fault	Cause/solution
The appliance does not heat up	The thermal cutout may have tripped. Contact the manufacturer's Customer Experience (the device must be replaced).
The bowl is not positioned correctly and the appliance does not work	Position the bowl correctly
The lid is not properly closed and the appliance does not work	Close the lid
The paddle (E) does not turn	Wait for a few minutes after cooking begins

COOKING TABLES

Potatoes

Recipe	Type	Quantity	Oil	Cooking time (min)	Paddle
Standard potatoes cut to 1x1cm thick chips	Fresh	1.5 kg (*)	level 4	40-42	YES
		1.25 kg (*)	level 3	35-37	YES
		1 kg (*)	level 2	30-32	YES
		750 gr (*)	level 1	25-27	YES
	Frozen	1.25 kg	without	36-38	YES
		1 kg	without	30-32	YES
		750 gr	without	26-28	YES
		500 gr	without	20-22	YES
Roast potatoes	Fresh	1 kg	level 3	37	YES
Potato wedges	Frozen	1 kg	without	32	YES
New potatoes	Frozen	1 kg	without	40	YES
Croquettes	Frozen	750 gr	without	26	YES

(*) un-peeled potato weight

Meat - poultry

Recipe	Type	Quantity	Oil	Cooking time (min)	Paddle	Tips
Chicken nuggets	Frozen	750 gr	without	20	YES	-
Chicken drumsticks	Fresh	650 gr	without	35	NO	turn 2-3 times
Chicken breast	Fresh	300 gr	without	20	YES	-
Braised veal	Fresh	600 gr	level 2	27	YES	-
Veal chops	Fresh	3 pcs	without	25	NO	turn over after 15 min
Veal spare ribs	Fresh	1200 gr	without	35	NO	turn 2-3 times
Kebabs	Fresh	800 gr	without	22	NO	turn 2-3 times
Hamburger	Fresh	4 pcs	without	25	NO	turn over after 15 min
Meatballs	Fresh	450 gr	without	27	YES	-

Fish - shellfish

Recipe	Type	Quantity	Oil	Cooking time (min)	Paddle	Tips
Fish fingers	Frozen	18 pz	without	19-22	NO	turn over after 12 min
Salmon steak	Fresh	400 gr	without	17-20	NO	turn over after 11 min
Salmon fillet	Fresh	350 gr	without	12-15	NO	turn over after 9 min
Scallops	Fresh	4 pcs	without	12-15	NO	-
Cuttlefish	Fresh	8 pcs	level 1	17-20	NO	-
Tiger prawns	Fresh	600 gr	level 1	17-20	YES	-
Prawns	Fresh	800 gr	level 1	17-20	YES	-

Vegetables - Fruit

Recipe	Type	Quantity	Oil	Cooking time (min)	Paddle
Courgettes	Fresh	600 gr	level 5	20-25	YES
Aubergines	Fresh	600 gr	level 3	20-25	YES
Mushrooms	Fresh	600 gr	level 2	15-20	YES
Asparagus	Fresh	800 gr	level 5	25-30	YES
Fruit	Fresh	300 gr	without	15-18	NO

Other

Recipe	Type	Quantity	Oil	Cooking time (min)	Paddle	Tips
Paella	Frozen	600 gr	without	15-17	YES	mix once
Gnocchi alla sorrentina	Frozen	550 gr	without	13-15	YES	mix once
Onion rings	Frozen	12/15 pcs	without	15-17	NO	spread evenly on the bottom of the bowl. Turn over after 10 min

For more recipes download the Delonghi fryer app.