

## Slow cooker CKS420



*Living innovation*

De'Longhi quick guide

- **Before use clean ceramic crock pot and lid**
- **Prepare the food prior to using the slow cooker as advised in recipe section**
- **Distribute prepared food evenly in the ceramic pot**
- **Plug in ('Power' indicator flashes)**
- **Press the Cook/Time button to select the appropriate cooking time, either 4/6 or 8/10 hours**
- **Push On/Off button to begin cooking, ('Power' light will stop flashing)**
- **Pressing the On/Off button twice enables you to re-select the cooking time or set the slow cooker to 'Warm' mode**
- **At the end of cooking time, the cooker will switch into 'Warm' mode. Do not leave in 'Warm' setting for more than 4 hours.**