

HOW TO GET THE BEST RESULTS FROM YOUR OVEN

What do I want to do?	What function should I choose?	Use Instr. page	Amt. & time chart page	
• Defrost	Microwave only	⌘	27 28	29
• Melt butter and soften cheese	Microwave only	⌘	27 28	31
• Heat pastry goods		⌘	33	33
• Cook meat		⌘	27	32
• Cook fish		⌘		
• Making boiled vegetables			27 32	32
• Cooking rice, making soup	Microwave only	⌘	33	31
• Heating foods already cooked			30	30
• Cooking fruit			33	33
• Grill hamburgers, chops, frankfurters, sausages, toast, etc. in a "traditional" way	Grill only	▼▼▼	34	35
microwave + grill function				
• Cooking vegetables au gratin	combi - 1			
• Making lasagne or pasta oven dishes	combi - 2		36	37
• Making all types of roasts, poultry, skewered meats, etc.	combi - 3		37	



TECHNICAL DATA

Outer measurements (LxDxH) 455x290x370

Inner measurements (LxDxH) 280x205x270

Approximate weight 14 kg.

Turntable diameter 24,5 cm

Oven light 20 W

Output power 700W (IEC705)





For additional information, refer to the rating plate on the appliance.

This appliance conforms to EC directives 89/336 and 92/31 on Electromagnetic Compatibility and EC directive no. 1935/2004 of 27/10/2004 on materials intended for contact with food.

I M P O R T A N T S A F E G U A R D S

Read carefully these instructions and keep for future reference. This oven has been designed to defrost, heat and cook food in the home. It must never be used for other purposes, modified or tampered with in any way.

- 1) **WARNING:** If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person (trained by the manufacturer or by its Customer Service).
- 2) **WARNING:** It is hazardous for anyone other than a competent person to carry out any service or repair operation which involves the removal of a cover which gives protection against exposure to microwave energy.
- 3) **WARNING:** Liquids and other foods must not be heated in sealed containers since they are liable to explode. Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode even after microwave heating has ended.
- 4) **WARNING:** The appliance is not intended for use by young children or infirm persons. Young children should be supervised to ensure that they do not play with the appliance. Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.
- 5) **IMPORTANT:** when operating in combi mode, the oven becomes extremely hot. Do not allow children to use it without adult supervision.
- 6) Do not attempt to operate the oven with the door open by tampering with the safety devices.
- 7) Do not operate the oven if objects for any kind get stuck between the front panel of the oven and the door. Always keep the inside of the door (E) clean, using a damp cloth and non-abrasive detergents. Do not allow dirt or remains of food to accumulate between the front panel of the oven on the door.
- 8) If the supply cable has been damaged, it must be replaced by the manufacturer or the technical service centre or by a qualified person so as to avoid all risks.
- 9) If smoke is observed, switch off or unplug the appliance and **KEEP THE DOOR CLOSED** in order to stifle any flames.
- 10) Only use utensils that are suitable for use in microwave ovens. In order to avoid overheating and the consequent risk of fire, it is advisable to supervise the oven when cooking food in disposable containers made of plastic, cardboard or other inflammable materials, and when heating small quantities of food.
- 11) Never place the turntable in water after it has been heated for a long time. The high thermal shock resulting would break the turntable.
- 12) When cooking "Only MICROWAVE" and "COMBINED WITH MICROWAVE", you absolutely must not pre-heat the oven (without foodstuffs in it) and you must not operate it when it is empty, because you might cause sparking.
- 13) Before using this oven, check to be certain that the utensil and containers chosen are suitable for microwave oven use (see the section on "Glassware and Similar Items").
- 14) During the use the appliance becomes hot. Do not touch the heating elements inside the oven.
- 15) When heating liquids (water, coffee, milk, etc.) it is possible that the contents may suddenly start to boil and spill violently as a result of delayed boiling, causing scalding. To avoid this happening, you should place a heat-resistant plastic spoon or a glass rod in the container before starting to heat liquids. Anyway, care shall be taken when handling the container.



16) Do not heat spirit with a high alcohol content, nor large quantities of oil, as these could catch fire!

17) The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature shall be checked before consumption in order to avoid burns. It is also advisable to stir or shake the food in order to ensure that it has an even temperature. When using commercially available bottle sterilisers, before turning the oven on, ALWAYS make sure the container is filled with the quantity of water indicated by the manufacturer.



18) Failure to clean the oven properly could result in damage to the surfaces.

This could reduce the working life of the oven and make it hazardous to use.

N.B. When the oven is used for the first time it is possible that, for a period of approx. 10 minutes, it may produce a "new" smell and a small amount of smoke. This is only a result of protective substances applied to the heating element. Ventilate the room during this operation.

E L E C T R I C A L C O N N E C T I O N S

Connect this equipment only to electrical outlets having a capacity of at least 10A.

Before using this oven, check to make certain that the electrical network is the same as that indicated on the equipment's data plate and that the electrical

outlet is connected to an efficient grounding (earth) terminal. **The manufacturer shall not be responsible in any manner whatsoever for harm or damage caused by failure to observe this norm.**

- **Electrical Connection for UK only** see page 39

I N S T A L L A T I O N

1) After having removed the oven from its box, check to make certain that the turntable spindle (D) is correctly fitted into its housing. Place the turntable support (G) in the middle of the cooking chamber and set the turntable (F) on top of it. The spindle (D) must be inserted in the related turntable housing.

2) Check to make certain that this equipment has not been damaged in transport and check especially to see if the door opens and closes correctly.

3) Set the oven on a flat, steady surface **at least 85 cm.** above the floor and out of the reach of small children, because when the oven is operating its door can get very hot.

4) After having placed the oven on its work level, make sure that there is still a free space of at least 5 cm. between the oven's surfaces and the side as well as back walls, and a free space of at least 20 cm. above the oven (see Fig. 1). Also check to make sure the feed cord is not touching the appliance's rear wall, because the wall itself can get very hot while the grill is being used.

5) Do not block the air intake. In particular, do not set anything atop the oven and check to be certain that the air outlet slots (located above, under and in the back of the oven) are ALWAYS FREE from obstruction (see Figs. 2 and 3).

6) **DO NOT** remove the transparent film on the inner surface of the door.

GLASSWARE AND SIMILAR ITEMS

You can make use of all types of containers made of glass (preferably Pyrex), ceramics, porcelain and glazed pottery as long as they do not have decorations or metal parts (gilded borders, handles, feet). Heat resistant plastic containers can also be used, but only for "Microwave Only" cooking. If you are still doubtful about using a particular container, you can perform a simple test. Place the empty container in the oven for 30 seconds at maximum power ("Microwave Only" function). If the container is still cold or only slightly warm, it is suitable for microwave cooking.

If it is very hot or gives out sparks, it is not suitable. For short heating periods, you may use paper napkins, cardboard trays and plastic "throwaway" plates as a base. As far as shape and size are concerned, it is absolutely essential that containers be such as to allow the turntable to rotate. In order to use large-size rectangular

containers (which may not be able to rotate inside the cooking cavity), you can remove the spindle (D) from its housing to prevent the turntable (F) moving. Bear in mind that to be assured of good results when carrying this out you must stir the food and turn the container around several times during the cooking process.

Containers made of metal, wood, recycled kitchen paper, cane and plate glass are not suitable for use in microwave ovens.


The metal rack supplied with your microwave have been fully tested for safe use. You should remember, too, that since microwaves heat the food and not the glassware, earthenware or similar containers for that food, it is possible to cook such foods in the serving dish and thereby avoid the problem of having to clean pans later.

If the oven is used in its **grill only** functions, any type of oven container may be used (see chart).

	Glass	Ceramics	Porcelain	Earthenware	Plastic for microwaves	Paper cups*	Paper plates*	Pyrex	Cardboard*	Metal containers	Glassware with metal parts	Special roasting paper
Microwave only	YES	YES	YES	YES	YES	YES	YES	YES	YES	NO	NO	YES
Grill only	NO	YES	YES	YES	NO	NO	NO	YES	NO	YES	YES	YES
microwave + grill	NO	YES	YES	YES	NO	NO	NO	YES	NO	NO	NO	YES


* If the cooking time required is too long, there is a possibility of fire.

DESCRIPTION OF CONTROLS




ACCESSORIES PROVIDED

WIRE RACK



Grill only function: For all types of grilling.

TURNTABLE



The turntable is used for **all the functions**.

ADVICE ON USING YOUR OVEN CORRECTLY

Microwaves consist of electromagnetic radiation found in nature under the form of light waves (e.g., sunlight). Inside the oven, these waves penetrate food from all directions and heat up the water, fatty and sugar molecules.



Heat is produced very quickly only in the food itself, whereas the container being used warms up indirectly by means of heat given off by the heated food. This prevents food from sticking to its container, so you can use very little fatty sub-

stance or, in some cases, no fat at all during the cooking process.

Therefore cooking in a microwave oven is considered to be healthy and good for one's diet. And in contrast to traditional methods, cooking in a microwave foodstuffs are less dehydrated, lose less of their nutritional value, and retain more of their original flavour.

Basic rules for correct cooking with a microwave oven

- 1) In order to set cooking times correctly, remember (in referring to the charts on the following pages) that when you increase the amount of foodstuffs the cooking temperature must likewise be proportionately increased and vice-versa. It is important to respect the "standing" times: **standing time** means that period during which the food must be left to "rest" after being cooked so as to allow an even greater spreading of the temperature within. The temperature of meat, for example, will rise about 5°-8° C. (approx. 9°-15° F.) during the standing time. Standing times may be observed either inside or outside the oven.
- 2) One of the main things you must do is **stir** the food several times while it is being cooked. This helps make the temperature distribution more uniform and thus shortens the cooking time.
- 3) It is also advisable to **turn** the foodstuff **over** during its cooking process: this applies especially for meat, whether it is in large pieces (roasts, whole chickens, etc.) or small (chicken breasts, etc.).
- 4) **Foods having a skin, shell or peel (e.g., apples, potatoes, tomatoes, frankfurters, fish) must be pierced with a fork in several points so as to permit steam to escape and to prevent those items from exploding (see Fig. 4).**
- 5) If you are preparing a large number of portions of the same food item (e.g., boiled potatoes), **place** those portions in a Pyrex dish in order to have them cook in a uniform manner (see Fig. 5):
- 6) The lower the temperature at which a foodstuff is placed in a microwave oven, the longer the cooking time required. Food having a room temperature will cook more quickly than food having a refrigerator temperature.
- 7) Always do your cooking by placing the food container in the centre of the turntable.
- 8) It is perfectly normal for **condensation to form** inside the oven and near the air outlet. **To reduce such condensation, cover the foodstuffs with clear-sheet, wax paper, a glass lid or simply an overturned plate.** Then, too, foods having a water content (e.g., greens and vegetables) cook better when covered. The covering of food also helps keep the oven clean on the inside. Use clear-sheet made expressly for microwave ovens.



M I C R O W A V E - O N L Y F U N C T I O N



This function is suitable for:


- Defrostingpage 28
- Heatingpage 30
- Cooking stew, white meats, fruit, vegetables, rice, soup and fishpage 32
- To brown the foods, to bake pastry and fruitpage 34

TURNING THE OVEN ON USING ONLY THE MICROWAVE FUNCTION

1

Place the food in a container suitable for microwave cooking and place it in the centre of the turntable


N.B: You do not have to pre-heat the oven.



2


Select the desired power level by turning the function knob to one of the 5 symbols denoting the microwave output power.

N.B.: if the knob is turned to the ▼▼▼ symbol or one of the following 3 symbols, the grill will also operate.




3

Set the cooking time you want by turning the **Time** knob in a clockwise direction.




4


Once the set cooking time has expired, a **buzzer** will sound to signal that your food is ready



You can interrupt operations any time you wish simply by turning the **Time** knob to the "0" position. You can also change the cooking time (while the foodstuff is being cooked) simply by turning this same knob forward or backward. You can check on the situation while the cooking is in progress by opening the door and examining the food. That move will interrupt the oven's operations, but they will begin again once the door has been closed.



USING THE MICROWAVE-ONLY FUNCTION FOR DEFROSTING


- Turn the function knob to the  position and set the desired time on the timer knob.
- Foods frozen in bags or plastic sheeting or in their packaging may be placed directly in the oven, as long as they have no metal parts (e.g., bands or closure rivets).
- Certain foods, such as greens, vegetables and fish, do not generally require defrosting before you begin cooking them.
- Stewed foods and meats as well as meat sauces defrost better and quicker if they are stirred from time to time, turned over or broken up.
- While defrosting, meat and fish lose their liquid content. It is recommended, therefore, that you defrost such items in a tray or basin.
- It is advisable to separate each individual piece of meat from its bag before putting it in the freezer. This will help you save valuable time when preparing foods.
- Be careful about following the timings printed on frozen products, because they are guideline and may not always be correct. It is best to use defrosting times slightly less than those indicated. The time needed for defrosting will vary in terms of the degree to which the food has been frozen.



Defrosting times

Type	Quantity	Function knob	Cooking time	Notes	Standing time (minutes)
MEAT					
• Roasts (pork, beef, veal, etc.)	1 kg	*	25 - 28		20
• Steaks, cutlets, meat slices	200 gr	"	6 - 8		5
• Stew, goulash	500 gr	"	14 - 16		10
• Ground meat	500 gr	"	12 - 14	(*)	15
"	250 gr	"	5 - 7		10
• Hamburger	200 gr	"	7 - 9		10
• Sausages	300 gr	"	9 - 11		10
POULTRY					
• Duck, turkey	1,5 kg	"	35 - 40	At the end of the rest period,	20
• Whole chickens	1,5 kg	"	35 - 40	wash under hot water to	20
• Cut-up chicken	500 gr	"	14 - 16	remove possible ice	10
• Chicken breasts	300 gr	"	13 - 15		10
VEGETABLES					
• Cubed eggplant	500 gr	"	16 - 19		5
• Cut-up peppers	500 gr	"	15 - 18		5
• Shelled peas	500 gr	"	12 - 15		5
• Artichoke hearts	300 gr	"	9 - 11		5
• Pieces of asparagus	500 gr	"	14 - 16		5
• Cut-up green beans	500 gr	"	15 - 18	To assist defrosting, separate	5
• Whole broccoli	500 gr	"	15 - 17	the vegetables every so often.	5
• Brussels sprouts	500 gr	"	15 - 17		5
• Cut-up carrots	500 gr	"	14 - 16		5
• Cauliflower tops	450 gr	"	13 - 15		5
• Mixed vegetables	300 gr	"	8 - 10		5
• Cut-up spinach	300 gr	"	9 - 11		5
FISH					
• Filleted fish	300 gr	"	9 - 11		7
• Cut-up fish	400 gr	"	10 - 12		7
• Whole fish	500 gr	"	13 - 15		7
• Prawn, shrimps	400 gr	"	10 - 12		7
DAIRY PRODUCTS					
• Butter	250 gr	"	5 - 7	Remove the aluminium paper and metal pieces.	10
• Cheese	250 gr	"	6 - 8	Partially defrosted. Needs the standing time.	15
• Cream	200 ml	"	8 - 10	Cream is to be removed from its container and put on a plate.	5
BREAD PRODUCTS					
• 2 average-size rolls	150 gr	"	1 - 2	Put the bread directly on the turntable	3
• 4 average-size rolls	300 gr	"	4 - 6		3
• Sliced home-style bread	250 gr	"	4 - 6		3
• Whole-wheat bread	250 gr	"	4 - 6		3
FRUIT					
• Strawberries, prunes, cherries, currants, apricots	500 gr	"	12 - 14	Mix 2 or 3 times	10
• Raspberries	300 gr	"	8 - 10	Mix 2 or 3 times	10
• Blackberries	250 gr	"	6 - 8	Mix 2 or 3 times	6


(*) These indications are suitable for performing the minced meat defrosting test according to Regulation 60705, Par. 13.3 (see page 2). Turn over halfway through the set time. Place directly on the turntable. Further information, including on other performance tests according to Regulation 60705, is given in the table on page 2.



USING THE MICROWAVE-ONLY FUNCTION FOR RE-HEATING

Heating food in a microwave oven is much quicker and energy efficient than traditional methods.

- We recommend that you heat foodstuffs (especially if they are frozen) to a temperature of at least 70° C. (it must be piping hot!). Leave to stand for a few minutes as you will not be able to eat that food immediately because it will be too hot.
- This will ensure that any possible bacteria present in food will have been killed.
- To heat pre-cooked or frozen foods, follow these rules:
 - remove the food from its metal containers;
 - cover it with plastic wrap (the clear-film type suitable for microwave ovens) or wax paper; in this way, all the food's natural flavour will be preserved and the oven will stay cleaner; you may also cover the food with an upside-down plate;
 - if possible, stir or turn the food over frequently so as to speed up the heating process and keep the heat uniform at the same time;
 - follow the cooking times listed with great caution; remember that under certain conditions the timings given must be lengthened
- Frozen foods must be defrosted before the heating process begins. The lower the food's initial temperature, the longer the time needed for heating.
- Foodstuffs and drinks may be heated briefly in paper or plastic containers. In any event, however, such containers may become misshapen if the heating time is too long.





Heating times

Type	Quantity	Function knob	Cooking time	Notes
SOFTENING FOOD				
<ul style="list-style-type: none"> Chocolate/icing Butter 	100 gr 50 -70 gr		5 - 6 0'.7"-0'.12"	Put on a plate. Mix the icing once.
CHILLED FOOD (INITIAL TEMP. 5/8°C) UP TO 20/30°C				
<ul style="list-style-type: none"> Yoghurt Baby's bottle 	125 gr 240 gr	"	0'.12"-0'.17" 0'.35"-0'.40"	Remove metal foil. Heat the baby's bottle without the teat and mix it immediately after heating to make the temperature uniform. Check the temperature of the contents before use. With milk at room temperature the heating time is lower. To avoid risk of fire when using dried milk please stir evenly. Please use already sterilized milk.
CHILLED PRECOOKED FOOD (INITIAL TEMP. 5/8°C) UP TO APPROX. 70° C				
<ul style="list-style-type: none"> Packet of lasagne or of pasta with filling Packet of meat with and/or vegetables Packet of fish and/or vegetables Plate of meat and/or vegetables plate of pasta, cannelloni or lasagne Plate of fish and/or rice 	400 gr 400 gr 300 gr 400 gr 400 gr 300 gr	"	6 - 8 6 - 8 5 - 7 7 - 8 7 - 8 6 - 8	<p>Packets of any kind of commercially available pre-cooked food, to be heated to a temp. of 70° C. Remove the food from any rice metal packets and put it directly onto the plate from which it is to be eaten. For best results, always cover the food.</p> <p>Portions of any kind of already cooked food, to heat to a temp. of 70°C. The food is placed directly onto the plate from which it is to be eaten and is always covered either with a transparent film or with an upturned plate.</p>
FROZEN FOOD TO REHEAT/COOK (INITIAL TEMP. -18°/-20°C) UP TO APPROX. 70° C				
<ul style="list-style-type: none"> Packet of lasagne or of pasta with filling Packet of meat with rice and/or vegetables Packet of fish and/or pre-cooked vegetables Packet of fish and/or raw vegetables Portion of meat and/or vegetables Portion of pasta, cannelloni or lasagne Portion of fish and/or rice 	400 gr 400 gr 300 gr 300 gr 400 gr 400 gr 300 gr	"	8 - 10 7 - 8 5 - 7 10 - 12 8 - 10 9 - 11 6 - 8	<p>Packets of any kind of commercially available pre-cooked frozen food, to be heated to a temp. of 70° C directly in its packet. Remove the food from any metal containers and put it directly onto the plate from which it is to be eaten, increasing cooking time by a few minutes.</p> <p>Remove the raw food from the packets and place it in a container suitable for microwaves and cover.</p> <p>Portions of any kind of already cooked frozen food, to be heated to a temperature of 70°C. Place the frozen food in the plate from which it is to be eaten and cover it with another upturned plate or pyrex dish. Check that it is hot in the centre; where possible, mix the food.</p>
CHILLED DRINKS (INITIAL TEMP. 5°/8° C) UP TO APPROX. 70°C				
<ul style="list-style-type: none"> 1 cup of water 1 cup of milk 1 cup of coffee 1 plate of broth 	180 cc 150 cc 100 cc 300 cc	"	2 - 2'.30" 1'.30" - 2 1'.30" - 2 4 - 5	All the drinks should be mixed after being heated to make the temperature uniform. For the broth we recommend covering it with an upturned plate.
DRINKS AT ROOM TEMPERATURE (INITIAL TEMP. 20°/30°C) UP TO APPROX. 70° C				
<ul style="list-style-type: none"> 1 cup of water 1 cup of milk 1 cup of coffee 1 plate of broth 	180 cc 150 cc 100 cc 300 cc	"	1'.30" - 2 1 - 1'.30" 1 - 1'.30" 3 - 4	All the drinks should be mixed after being heated to make the temperature uniform. For the broth we recommend covering it with an upturned plate.



USING THE MICROWAVE-ONLY FUNCTION FOR COOKING

MEATS

When using the microwave-only function to cook meat, you should cover the meat with plastic wrap made for microwave oven use; in this way, the heat is distributed better and you will prevent the loss of juices that often leads to dried-up and stringy meat. This oven function is suitable for making stews, goulash, chicken breasts, etc. To prepare roasts and skewered meat dishes (among others), you must use the combined function.

FISH

In a microwave oven, fish can be prepared very quickly and with excellent results. You can season it with a little oil or butter (or not season it at all, if you so prefer). Cover the fish with clear-sheet. The skin is to be slit, of course, and filleted fish must be placed in a uniform fashion. We recommend that you not use this oven to cook fish which has been dipped in egg batter.

GREENS AND VEGETABLES

Greens and vegetables cooked in a microwave oven retain more of their colour and nutritional value than when cooked in traditional ovens. Before cooking greens and vegetables, wash and clean them.

Larger-sized varieties of this category are to be cut up into uniform pieces.

Per every 500 gr. of greens or vegetables add about 5 teaspoons of water (fibre-type vegetables need more water). Greens and vegetables must **always** be covered with plastic wrap.

Stir greens and vegetables at least once at the halfway point. Add a little salt only at the end.

Cooking times

Type	Quantity	Function knob	Cooking time	Notes	Standing time (minutes)
FISH					
• Filleted	300 gr		10 - 12	Cover with plastic wrap	2
• Slices	300 gr	"	12 - 17	Cover with plastic wrap	2
• Whole	500 gr	"	13 - 15	Cover with plastic wrap	2
• Whole	250 gr	"	10 - 12	Cover with plastic wrap	2
• Cut-up fish	400 gr	"	12 - 14	Cover with plastic wrap	2
• Crayfish	500 gr	"	12 - 14	Cover with plastic wrap	2
GREENS AND VEGETABLES					
• Asparagus	500 gr		11 - 12	Cut into 2-cm. pieces	4
• Artichokes	300 gr	"	12 - 13	It would be better to use artichoke bottoms.	4
• Green beans	500 gr	"	13 - 14	Cut into pieces	4
• Broccoli	500 gr	"	9 - 10	Separate into individual "florets"	4
• Brussels sprouts	500 gr	"	9 - 10	Leave whole	4
• White cabbage	500 gr	"	9 - 10	Cut into strips	4
• Red cabbage	500 gr	"	9 - 10	Cut into strips	4
• Carrots	500 gr	"	11 - 12	Cut into same-size pieces	4
• Cauliflower	500 gr	"	13 - 14	Separate into stalks	4
• Celery	500 gr	"	9 - 10	Separate into pieces	4
• Eggplant	500 gr	"	8 - 9	Cut into cubes	4
• Leek	500 gr	"	8 - 9	Cut into strips	4
• Mushrooms	500 gr	"	8 - 9	Leave whole No water is needed.	4
• Onions	250 gr	"	7 - 8	Whole, but of the same size. No water is needed.	4
• Spinach	300 gr	"	8 - 9	Cover after having washed and drained the leaves.	4
• Peas	500 gr	"	12 - 13		4
• Fennel	500 gr	"	14 - 15	Cut into quarters	4
• Peppers	500 gr	"	11 - 12	Cut into pieces	4
• Potatoes	500 gr	"	10 - 11	Cut into same-size pieces	4
• Zucchini	500 gr	"	9 - 10	Cut into slices	4
MEATS					
• Stew	1,5 kg		44 - 47	Cook covered and stir 2 or 3 times.	10
• Chicken breasts	500 gr	"	15 - 20	Turn over at the halfway point	3
• Meat loaf	900 gr	"	22 - 24	(*)	5

(*) These indications are suitable for performing the minced meat cooking test according to Regulation 60705, Para. 12.3.3. Cover the container with clear film for microwave use. Further information, including on other performance tests according to Regulation 60705, is given in the table on page 2.



SOUPS AND RICE

- Soups or broth usually require a smaller amount of liquid because the evaporation in microwave ovens is rather limited. Because it is a dehydrating agent, salt must be added only when the cooking is finished or during the standing time.
- It is correct to say that the temperature required for cooking rice in a microwave oven (as is true also for pasta) is more or less the same as that needed to cook this foodstuff over a burner on a regular stove. The advantage of preparing a risotto dish in a microwave oven lies in the fact that you do not have to stir the rice constantly (two or three times is enough).
The ingredients are placed in a container suitable for microwave ovens and covered with plastic wrap (for about 300 gr. of rice, you need 750 gr. of broth with the oven programmed at top power for about 12 to 15 minutes). In addition, the rice will not stick to the bottom of its container and, since it can be cooked in a tureen or some other such receptacle to be brought to the table, you will not have to transfer that rice to a serving plate.

FRUIT AND BAKED GOODS

Baked goods rise (at lower oven power) much more than then do with regular baking. Since no crust is formed, it is better to garnish the surface portions with cream or icing (e.g., chocolate); in addition, you must keep the item being baked fully covered, because such foodstuffs tend to dry out more quickly than those baked in a regular oven. Fruit is to be pierced if cooked with its peel on and is to be kept covered: it is essential that you adhere to the standing time (3 to 5 minutes).

Cooking times for baked goods and fruit

Type/quantity	Function knob	Cooking time	Standing time (minutes)	Observations and advice
Nut cake (700 gr)		18 - 23	5	May be used in combination with any cream whatsoever
Viennese torte (850 gr)	"	22 - 27	5	To be filled with jam or jelly.
Pineapple cake (800 gr)	"	20 - 25	5	The pineapple slices can be laid on the bottom of the pin plate or cut into pieces and mixed into the dough.
Apple cake (1000 gr)	"	22 - 27	5	The apples are spread on top as a decorative effect.
Coffee cake (750 gr)		18 - 23	5	Excellent when filled with cream.
Zabaione	"	4 - 6	3	Mix with a whisk every 30 seconds
Cooked pears (300 gr)		6 - 8	3	The pears are to be cut into quarters.
Cooked apples (300 gr)	"	7 - 10	3	The apples are to be cut into pieces.
Egg custard (750 gr)	"	14 - 16	5	These indications are suitable for performing the cooking tests according to Regulation 60705, Para. 12.3.1.
Sponge cake (475 gr)	"	6 - 8	5	These indications are suitable for performing the cooking tests according to Regulation 60705, Para. 12.3.2. Further information, including on other performance tests according to Regulation 60705, is given in the table on page 2.



GRILL - ONLY FUNCTION


This function is suitable for:

- All types of traditional grilling (e.g., chops, hamburgers, frankfurters, toast, etc.)pag. 35

TURNING THE OVEN ON WITH THE GRILL-ONLY FUNCTION


1

Turn the function knob to the **▼▼▼** position.




2

Place the food in the oven on the grill, resting it on the turntable. During grilling, the turntable will collect any fat that may drip.




3

Set the desired cooking time by turning the **Time** knob. **The food should be turned over half way through cooking.**



4

Once the set cooking time has expired, a **buzzer** will sound to signal that your food is ready.



You can interrupt operations any time you wish simply by turning the **Time** knob to the "0" position. You can also change the cooking time (while the foodstuff is being cooked) simply by turning this same knob forward or backward. You can check on the situation while the cooking is in progress by opening the door and examining the food. That move will interrupt the oven's operations, but they will begin again once the door has been closed.



USING THE OVEN-GRILL-ONLY FUNCTION FOR GRILLING

By using this function, you can make all kinds of delicious grilled dishes.


Never preheat the oven.

All dishes being prepared must be turned over at the halfway point, to achieve even browning.

When opening the door to check the progress of the cooking, the top part is very hot: always use oven gloves. The door must always be closed again before continuing.

Cooking times

Type	Quantity	Function knob	Cooking time	Notes
• Veal or pork chops	3	▼▼▼	22 - 27	Turn over after 10 minutes.
• Sausages	3	"	28 - 32	Must always be pierced. If particularly fatty, the sausages should be cut in half. Turn over after 15 minutes.
• Hamburger	3	"	28 - 32	Turn over after 15 minutes.
• Toasted bread	4 slices	"	8 - 9	Trim the crusts carefully. Turn over after 4-5 minutes.



MICROWAVE-AND-GRILL SEQUENCE

This function is suitable for:


- Cooking lasagne or pasta oven dishes vegetables au gratin
- Cooking all types of roasts, poultry, skewered meats, etc.

pag. 37

STARTING THE OVEN IN THE COMBINED MICROWAVE + GRILLFUNCTION


1

Put the foodstuff in a container made specially for microwave cooking and place it in the centre of the turntable.




2

Select one of the 3 “combi” positions by turning the function knob.




3

Set the desired cooking time by turning the **Time** knob clockwise.



4

Once the set time has expired, a **beep** will indicate that the coating stage has been completed.



You can interrupt operations any time you wish simply by turning the **Time** knob to the “0” position. You can also change the cooking time (while the foodstuff is being cooked) simply by turning this same knob forward or backward. You can check on the situation while the cooking is in progress by opening the door and examining the food. That move will interrupt the oven’s operations, but they will begin again once the door has been closed.



USING THE MICROWAVE-AND-GRILL SEQUENCE FUNCTION FOR COOKING

This setting is ideal for microwave cooking as well as for browning foodstuffs and giving them an au gratin coating. You must, however, keep the following in mind:

- the oven is never to be pre-heated;
- do not spunkle with seasonings (just use 1/2 glass of water to keep the meat soft);
- turn over roasts and large pieces of meat half way through cooking.
- to check the situation while cooking is in progress, open the oven door. This will stop the microwave and grill functions: in this case, however, oven gloves should be used, as the top surface is very hot. To resume the cooking, simply close the oven door.

Cooking times

Type	Quantity	Function knob	Cooking time	Notes	Standing time (minutes)
• Gnocchi alla romana	600 gr	COMBI 1	15 - 18	Avoid excessive melting.	5
• Lasagne	1100 gr	COMBI 3	20 - 25	Times listed are for uncooked pasta.	5
• Well-seasoned macaronii	1500 gr	COMBI 1	10 - 15	The pasta should first be partly boiled.	5
• Cauliflower in bechamel sauce	1000 gr	COMBI 1	15 - 20	Times listed are for raw cauliflower.	5
• Tomatoes au gratin	800 gr	COMBI 1	20 - 25	The tomatoes should all be of the same size.	5
• Stuffed peppers	1400 gr	COMBI 3	20 - 25	Short wide peppers are best	5
• Aubergine alla parmigiana	1300 gr	COMBI 3	15 - 20	The aubergine may first be fried or grilled.	5
• Potatoes au gratin	1100 gr	COMBI 3	25 - 30	Times listed are for uncooked potatoes. (*)	10
• Roasts (pork, beef)	1000 gr	COMBI 2	60 - 65	Leave a little fat around the meat to keep it moist. Turn at the halfway point	10
• Meat loaf These instructions do not refer to test 12.3.3 of IEC regulation 60705 which is represented in the table on page 2 and 32	800 gr	COMBI 3	25 - 30	Turn at the halfway point	10
• Whole chicken	1200 gr	COMBI 2	60 - 65	Puncture the skin with a fork. Turn at the halfway point (**)	10
• Skewered meat	600 gr	COMBI 2	30 - 35	Turn at the halfway point	10
• Lamb	1000 gr	COMBI 2	50 - 55	Turn at the halfway point	10
• Turkey (pieces)	1000 gr	COMBI 2	60 - 65	Turn at the halfway point	10
• Duck	1000 gr	COMBI 2	70 - 75	Turn at the halfway point.	10

(*) These indications are suitable for performing the cooking test according to Regulation 60705, Para. 12.3.4. Further information, including on other performance tests according to Regulation 60705, is given in the table on page 2.

(**) These indications are suitable for performing the cooking test according to Regulation 60705, Para. 12.3.6. Further information, including on other performance tests according to Regulation 60705, is given in the table on page 2.

C L E A N I N G A N D M A I N T E N A N C E

Before beginning any cleaning or maintenance, always pull this oven's plug from the electrical outlet and wait for the oven itself to cool down completely

Cleaning

To maintain your appliance in the best condition, the door and the inside and outside of the oven should be cleaned regularly, using a soft cloth and neutral soap or liquid detergent. Always keep the microwave outlet cover (C) free of fat or splashed grease.

Never use abrasive detergents, steel wool or sharp metal utensils.

In addition, when cleaning the outside of the oven, be careful **not to let water or liquid detergent seep into the air outlet and steam slots located atop the appliance.**

We likewise recommend that you do not use alcohol, abrasive detergents or ammonia-based detergents to clean the inside and outside door surfaces.

To ensure perfect closing, always keep the inside of the door clean, and do not let dirt and food residue get caught between the door and the oven's façade.

Do not steam clean the inside of the oven.

Clean the air inlet holes located on the back of the oven regularly so that no dust or dirt will build up over time to obstruct those holes.

From time to time, it will be necessary to remove the turntable (H) and its support (I) and clean them, just as it will be necessary to clean the bottom of the oven.

Wash the turntable and its support in warm soapy water with neutral soap. These parts may also be cleaned in a dishwasher.

Do not place the turntable in cold water after the oven has been hot for a long time. The strong thermal shock could cause the turntable to break.

The turntable's motor is sealed tight. When you are cleaning the bottom of the oven, however, be careful not to let water seep under the turntable spindle (D).

IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH EC DIRECTIVE 2002/96/EC.

At the end of its working life, the product must not be disposed of as urban waste.

It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.



If something seems not to be working just right

If you should discover a flaw or defect, contact a Service Centre authorised by the manufacturer. In any case, before calling our technicians, you should carry out the following simple checks:

p r o b l e m	c a u s e / r e m e d y
<ul style="list-style-type: none"> The oven is not working 	<ul style="list-style-type: none"> The door is not properly closed. The plug is not properly inserted in the electric outlet. The outlet is not supplying power (check the building's fuse box). The Time knob has not been set correctly
<ul style="list-style-type: none"> Condensation on the cooking rack and inside the oven. 	<ul style="list-style-type: none"> When foods containing water are being cooked, it is completely normal for the steam generated within the oven to escape and to condense either inside the oven or on the cooking rack.
<ul style="list-style-type: none"> Sparks inside the oven. 	<ul style="list-style-type: none"> When using the microwave-only and combined functions, do not turn the oven on unless there is already food inside it. When cooking by microwaves, do not use metal containers, bags, or packages with metal clips.
<ul style="list-style-type: none"> The food is not heating sufficiently 	<ul style="list-style-type: none"> Select the correct power level or increase the cooking time. The food was not completely defrosted before being cooked.
<ul style="list-style-type: none"> The food is burning 	<ul style="list-style-type: none"> Use the correct cooking method or lower the cooking time.
<ul style="list-style-type: none"> The food is not cooking evenly 	<ul style="list-style-type: none"> Stir the food while it is being cooked. Remember that foodstuffs cook better when cut into uniform pieces. The turntable is blocked (check that the spindle D is correctly positioned).

In case oven-light is burned, you may continue to use the oven anyway. To replace the light, contact authorised Assistance.

ELECTRICAL CONNECTION (U.K. ONLY)

A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below.

WARNING: Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard.

With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse.

WARNING - THIS APPLIANCE MUST BE EARTHED **IMPORTANT**

The wires in the mains lead are coloured in accordance with the following code:


Green and yellow:	Earth
Blue:	Neutral
Brown:	Live



If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.

B) If your appliance is not fitted with a plug, please follow the instructions provided below:

As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The green and yellow wire must be connected to the terminal in the plug marked with the letter E or the earth symbol  or coloured green or green and yellow.

The blue wire must be connected to the terminal marked with the letter N or coloured black.

The brown wire must be connected to the terminal marked with the letter L or coloured red.