

## CONTENTS

<b>INTRODUCTION</b> .....	<b>7</b>
Symbols used in these instructions .....	7
Letters in brackets .....	7
Troubleshooting and repairs .....	7
<b>SAFETY</b> .....	<b>7</b>
Fundamental safety warnings .....	7
<b>DESIGNATED USE</b> .....	<b>8</b>
<b>INSTRUCTIONS</b> .....	<b>8</b>
<b>DESCRIPTION</b> .....	<b>8</b>
Description of the appliance .....	8
Description of the control panel .....	8
Description of the accessories .....	9
<b>PRELIMINARY CHECKS</b> .....	<b>9</b>
Checking the appliance .....	9
Installing the appliance .....	9
Connecting the appliance .....	9
Using the appliance for the first time .....	9
<b>TURNING THE APPLIANCE ON</b> .....	<b>10</b>
<b>TURNING THE APPLIANCE OFF</b> .....	<b>10</b>
<b>MENU SETTINGS</b> .....	<b>10</b>
Descale .....	10
Adjust time .....	10
Auto-off (Stand by) .....	10
Auto-start .....	11
Setting the temperature .....	11
Energy Saving .....	11
Setting water hardness .....	11
Setting the language .....	11
Install filter .....	11
Replacing the filter .....	11
Activate/deactivate the beep .....	11
Default values (reset) .....	12
Statistics function .....	12
<b>MAKING COFFEE</b> .....	<b>12</b>
Selecting the coffee taste .....	12
Selecting the quantity of coffee in the cup .....	12
Selected coffee .....	12
Quantity in cup (ml) .....	12
Customising the "my coffee" quantity .....	12
Adjusting the coffee mill .....	12
Tips for a hotter coffee .....	13
Making coffee using coffee beans .....	13
Making coffee using pre-ground coffee .....	13
<b>MAKING CAPUCCINO AND HOT MILK (NOT FROTHED)</b> .....	<b>14</b>
Making hot milk (without froth) .....	14
Cleaning the cappuccino maker after use .....	14
<b>HEATING WATER</b> .....	<b>14</b>
<b>CLEANING</b> .....	<b>15</b>
Cleaning the coffee maker .....	15
Cleaning the coffee grounds container .....	15
Cleaning the drip tray and condensate tray .....	15
Cleaning the inside of the coffee maker .....	15
Cleaning the water tank .....	16
Cleaning the coffee spouts .....	16
Cleaning the pre-ground coffee funnel .....	16
Cleaning the infuser .....	16
<b>DESCALE</b> .....	<b>16</b>
<b>SETTING WATER HARDNESS</b> .....	<b>17</b>
Measuring water hardness .....	17
Set water hardness .....	17
<b>WATER SOFTENER FILTER</b> .....	<b>18</b>
Installing the filter .....	18
Replacing the filter .....	18
Removing the filter .....	18
<b>TECHNICAL SPECIFICATION</b> .....	<b>19</b>
<b>DISPOSAL</b> .....	<b>19</b>
<b>DISPLAYED MESSAGES</b> .....	<b>20</b>
<b>TROUBLESHOOTING</b> .....	<b>21</b>

## INTRODUCTION

Thank you for choosing the automatic coffee and cappuccino maker.

We hope you enjoy using your new appliance.

Take a few minutes to read these instructions.

This will avoid all risks and damage to the machine.

### Symbols used in these instructions

Important warnings are identified by these symbols.

These warnings must absolutely be respected.



***Danger!***

Failure to observe the warning could result in possibly life threatening injury from electric shock.



***Important!***

Failure to observe the warning could result in injury or damage to the appliance.



***Danger of burns!***

Failure to observe the warning could result in scalds or burns.



***Please note:***

This symbol identifies important advice or information for the user.

### Letters in brackets

The letters in brackets refer to the legend in the Description of the Appliance on page 3.

### Troubleshooting and repairs

In the event of problems, first try and resolve them following the information given in the section “Displayed messages” on page 20 and “Troubleshooting” on page 21.

If this does not resolve the problem or you require further information, you should consult Customer Services by calling the number given on the annexed “Customer Service” sheet.

If your country is not among those listed on the sheet, call the number given in the guarantee.

If repairs are required, contact De’Longhi Customer Services only.

The addresses are given in the guarantee certificate provided with the appliance.

## SAFETY

### Fundamental safety warnings



***Danger!***

This is an electrical appliance and may cause electric shock.

You should therefore respect the following safety warnings:

- Never touch the appliance with damp hands or feet.
- Never touch the plug with damp hands.
- Make sure the socket used is freely accessible at all times, enabling the appliance to be unplugged when necessary.
- Unplug directly from the plug only. Never pull the power cable as you could damage it.
- To disconnect the appliance completely, place the main switch at the back of the appliance in the 0 position (fig. 6).
- If the appliance is faulty, do not attempt to repair.  
Turn it off, unplug from the mains socket and contact Customer Services.
- If the plug or power cable is damaged, it must be replaced by De’Longhi Customer Services only to avoid all risk.



***Important!***

Keep all packaging (plastic bags, polystyrene foam) away from children.



***Important!***

The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children must be supervised to ensure they do not play with the appliance.



***Danger: Risk of burns!***

This appliance produces hot water and steam may form while it is in operation.

Avoid contact with splashes of water or hot steam.

## DESIGNATED USE

This appliance is designed and made to prepare coffee and heat drinks. All other use is considered improper. This appliance is not suitable for commercial use. The manufacturer is not liable for damage deriving from improper use of the appliance.

This is an household appliance only.

It is not intended to be used in:

- staff kitchen areas in shops, offices and other working environments;
- farm houses;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments.

## INSTRUCTIONS

Read these instructions carefully before using the appliance.

- Failure to follow these instructions may result in burns or damage to the appliance. The manufacturer is not liable for damage deriving from failure to respect these instructions.




*Please note:*

Keep these instructions. If the appliance is passed to other persons, they must also be provided with these instructions.


## DESCRIPTION

### Description of the appliance







(page 3 - )

- A1. Control panel
- A2. Grinding adjustment knob
- A3. Cup shelf
- A4. Beans container lid
- A5. Pre-ground coffee funnel lid
- A6. Pre-ground coffee funnel
- A7. Beans container
- A8. Main switch
- A9. Water tank
- A10. Infuser door
- A11. Infuser
- A12. Coffee spout (adjustable height)
- A13. Coffee grounds container
- A14. Condensate tray
- A15. Cup tray
- A16. Drip tray water level indicator
- A17. Drip tray
- A18. Cappuccino maker selection ring
- A19. Cappuccino maker
- A20. Steam/hot water knob


### Description of the control panel

(page 2 - )

*A number of buttons on the panel have a double function. This is indicated in brackets in the description.*

- B1. Display: guides the user in using the appliance.
- B2.  button: turns the appliance on and off.
- B3. P button to access the menu
- B4.  button: to perform a rinse cycle.  
*(When in the settings MENU, it acts as the "ESC" button to exit from the selected function and go back to the main menu).*
- B5. Selection knob: turn to select the required quantity of coffee. *(When in the settings MENU, turn to select the required function).*
- B6.  aroma selection button: to select the coffee taste
- B7.  button: to make 1 cup of coffee with the settings displayed
- B8.  button: to make 2 cups of coffee with the settings displayed
- B9.  button: to deliver steam to make hot drinks with milk.  
*(When you access the MENU: "OK" button to confirm the selection made)*

## Description of the accessories

(page 2 - )

- C1. Measure
- C2. Cleaning brush
- C3. Descaler bottle
- C4. Water softener filter (certain models only)

## PRELIMINARY CHECKS

### Checking the appliance

After removing the packaging, make sure the product is complete and undamaged and that all accessories are present. Do not use the appliance if it is visibly damaged. Contact De'Longhi Customer Services.

### Installing the appliance



#### *Important!*

When installing the appliance, respect the following safety warnings:

- The appliance gives off heat. After positioning the appliance on the worktop, leave a space of at least 3 cm between the surfaces of the appliance and the side and rear walls and at least 15 cm above the coffee maker.
- Water penetrating the coffee maker could cause damage. Do not place the appliance near taps or sinks.
- The appliance could be damaged if the water it contains freezes.  
Do not install the appliance in a room where the temperature could drop below freezing point.
- Arrange the power cable in such a way that it cannot be damaged by sharp edges or contact with hot surfaces (e.g. electric hot plates).

### Connecting the appliance



#### *Important!*

Check that the mains power supply voltage corresponds to the value indicated on the rating plate on the bottom of the appliance.

Connect the appliance to an efficiently earthed and correctly installed socket with a minimum current rating of 10A only.

If the power socket does not match the plug on the appliance, have the socket replaced with a suitable type by a qualified professional.

## Using the appliance for the first time




#### *Please note:*


- Coffee has been used to factory test the appliance and it is therefore completely normal for there to be traces of coffee in the mill. The machine is, however, guaranteed to be new.
- You should customise water hardness as soon as possible following the instructions in the section "Setting water hardness" on page 17.

1. Plug the appliance into the mains socket and place the main switch on the back of the appliance in the I position (fig. 1).

You must first choose the language (the languages scroll through at intervals of about 3 seconds).

2. When "English" appears, press the  button (fig. 2) for a few seconds until "ENGLISH installed" is displayed.

Follow the instructions displayed by the appliance:

3. "FILL TANK!": remove the water tank, fill to the MAX line with fresh water (fig. 3A) then replace in the appliance (fig. 3B).
4. Place a container with a minimum capacity of 100 ml under the cappuccino maker (fig. 4).
5. "TURN STEAM KNOB": turn the knob to the "I" position (fig. 4). "HOT WATER... CONFIRM?" is displayed;
6. Press the  button to confirm. The appliance delivers water from the cappuccino maker then goes off automatically.
7. Turn the steam knob to the "0" position.

The coffee maker is now ready for normal use.



#### *Please note:*

- When using the appliance for the first time, you need to make 4-5 cups of coffee or 4-5 cappuccinos before the appliance starts to give satisfactory results.
- To enjoy your coffee even more and improve the performance of your appliance, we recommend installing a water softener filter as described in the section "WATER SOFTENER FILTER". If your model is not provided with a filter, you can request one from De'Longhi Customer Services.

## TURNING THE APPLIANCE ON



*Please note:*

Before turning the appliance on, make sure the main switch on the back of the appliance is in the I position (fig. 1).

Each time the appliance is turned on, it performs an automatic preheat and rinse cycle which cannot be interrupted.


The appliance is ready for use only after completion of this cycle.



*Danger of burns!*

During rinsing, a little hot water comes out of the coffee spouts and is collected in the drip tray underneath.

Avoid contact with splashes of water.

- To turn the appliance on, press the  button (fig. 5). The message “Heating up... Please wait” is displayed.

After heating, the message “Rinsing...” is displayed. As well as heating the boiler, the appliance also heats the internal circuits by circulating hot water.

The appliance is at temperature when a message indicating the coffee taste and quantity is displayed.

## TURNING THE APPLIANCE OFF


Each time the appliance is turned off, it performs an automatic rinse cycle which cannot be interrupted.



*Danger of burns!*

During rinsing, a little hot water flows from the coffee spouts.

Avoid contact with splashes of water.

To turn the appliance off, press the  button (fig. 5). The appliance performs a rinse cycle, then the message “Turning Off Please Wait...” is displayed and the appliance goes off.



*Please note:*

If the appliance is not used for an extended period, also place the main switch in the 0 position (fig. 6).



*Important!*

To avoid damaging the appliance, never place the

main switch (fig. 6) in the 0 position while the appliance is on.

## MENU SETTINGS




When you access the programming menu by pressing the P button, the following menu items are available: Descale, Adjust time, Auto-off, Auto-start, Set temperature, Energy Saving, Water hardness, Set language, Install filter, Replace filter, Beep, Default values, Statistics.


### Descale

For instructions on descaling, see page 16.

### Adjust time

To adjust the time on the display, proceed as follows:




1. Press the **P** button to enter the menu;
2. Turn the selection knob (fig. 8) until “ADJUST TIME” is displayed;
3. Press the  button (fig. 2);
4. Turn the selection knob (fig. 8) to change the hours;
5. Press the  button to confirm;
6. Turn the selection knob (fig. 8) to change the minutes;
7. Press the  button to confirm.

This sets the time. Press the  button to exit the menu.

### Auto-off (Stand by)

The appliance is set to turn off automatically if not used for 2 hours.

The time can be changed so that the appliance switches off after 15 or 30 minutes, or after 1, 2 or 3 hours.

1. Press the P button to enter the menu;
  2. Turn the selection knob (fig. 8) until “Auto-Off” is displayed;
  3. Press the  button;
  4. Turn the selection knob (fig. 8) until the desired operation time is displayed (15 or 30 minutes, or 1, 2 or 3 hours);
  5. Press the  button to confirm;
  6. Press the  button to exit the menu.
- Auto-off is programmed.



*Please note:*

To disconnect the appliance completely, place the main switch at the back of the appliance in the 0 position (fig. 6).






## Auto-start


You can set the auto-start time in order to have the appliance ready at a certain time (for example in the morning) so you can make coffee immediately.





*Please note:*

To activate this function, the time must already have been set correctly.

1. Press the **P** button to enter the menu;
2. Turn the selection knob (fig. 8) until “Auto-Start” is displayed;
3. Press the  button. “Activate?” is displayed;
4. Press the  button to confirm;
5. Turn the selection knob to choose the hours;
6. Press the  button to confirm;
7. Turn the selection knob (fig. 8) to change the minutes;
8. Press the  button to confirm;
9. Press the  button to exit the menu.




Once the time has been confirmed, activation of auto-start is indicated by the  symbol displayed alongside the time and under the Auto-start item in the menu.

To deactivate the function:

1. select auto-start from the menu;
  2. press the  button. “Deactivate?” is displayed;
  3. press the  button to confirm.
- The  symbol is no longer displayed.

## Setting the temperature

To modify the temperature (low, medium, high) of the water used to make the coffee, proceed as follows:




1. Press the **P** button to enter the menu;
2. Turn the selection knob (fig. 8) until “Set Temperature” is displayed;
3. Press the  button;
4. Turn the selection knob until the required temperature (high, medium, low) is displayed;
5. Press the  button to confirm;
6. Press the  button to exit the menu.

## Energy Saving

Use this function to activate or deactivate energy saving mode. This mode is active by default, re-

ducing energy consumption in compliance with current European regulations.

When energy saving mode is active, an asterisk appears below “Energy Saving” in the menu.

1. Press the **P** button to enter the menu;
2. Turn the selection knob (fig. 8) until “Energy Saving” is displayed;
3. Press the  button. “Deactivate?” is displayed;
4. Press the  button to deactivate energy saving mode;
5. Then press the  button to exit the menu.

When the function is active, if the machine is not used for about 1 minute, “Energy Saving” is displayed.



*Please note:*




A few seconds may elapse between energy saving mode and delivery of the first drink as the appliance must heat up again. A few seconds may elapse between energy saving mode and delivery of the first coffee.

## Setting water hardness

For instructions on setting water hardness, see page 17.

## Setting the language

To change the language on the display, proceed as follows:

1. Press the **P** button to enter the menu;
2. Turn the selection knob (fig. 8) until “Set Language” is displayed;
3. Press the  button;
4. Turn the selection knob until the required language is displayed;
5. Press the  button to confirm;
6. Press the  button to exit the menu.

## Install filter

For instructions on how to install the filter, see the section “Installing the filter” on page 18.





## Replacing the filter

For instructions on how to replace the filter, see the section “Replacing the filter” on page 18.

## Activate/deactivate the beep



This activates or deactivates the beep emitted by

the machine each time the button is pressed or an accessory is inserted/removed. The beep is active by default.

1. Press the **P** button to enter the menu;
2. Turn the selection knob (fig. 8) until “Beep” is displayed;
3. Press the  button. “Deactivate?” or “Activate?” is displayed;
4. Press the  button to activate or deactivate the beep (or the  button to exit);
5. Activation of the beep is indicated by an asterisk after the “Beep” item in the menu. Press the  button to exit the menu.



### Default values (reset)

This resets all menu settings and programmed quantities back to the default values (with the exception of the language which remains as set previously).

1. Press the **P** button to enter the menu;
2. Turn the selection knob (fig. 8) until “DEFAULT VALUES” is displayed;
3. Press the  button;
4. The message “CONFIRM?” is displayed;
5. Press the  button to confirm and exit.

### Statistics function

This displays statistics relating to the machine. To display, proceed as follows:

1. Press the **P** button to enter the menu;
2. Turn the selection knob (fig. 8) until “Statistics” is displayed;
3. Press the  button;
4. Turn the selection knob (fig. 8) to verify:
  - how many coffees have been made;
  - how many times the machine has been descaled;
  - the total number of litres of water delivered;
  - how many times the water filter has been replaced.
5. Press the  button twice to exit the menu.

## MAKING COFFEE

### Selecting the coffee taste

The appliance is set by default to make coffee with a standard taste.

You can also choose one of these tastes:


Extra-mild taste

Mild taste

Standard taste

Strong taste

Extra-strong taste

To change the taste, press the  button (fig. 7) repeatedly until the required taste is displayed.

### Selecting the quantity of coffee in the cup

The appliance is set by default to make a standard quantity of coffee.



To select the quantity of coffee, turn the selection knob (fig. 8) until the message corresponding to the required quantity of coffee is displayed:

Selected coffee	Quantity in cup (ml)
MY COFFEE	Programmable: from ≈20 to ≈180
ESPRESSO	≈40
STANDARD	≈60
LONG	≈90
EXTRA LONG	≈120

### Customising the “my coffee” quantity

The appliance is set by default to automatically deliver 30 ml of “my coffee”.

To modify these settings, proceed as follows:

1. Place a cup under the coffee spouts (fig. 9).
2. Turn the selection knob (fig. 8) until “MY COFFEE” is displayed (fig. 8).
3. Keep the  button (fig. 12) pressed until the message “1 MY COFFEE PROGRAM QUANTITY” is displayed and coffee delivery begins. Release the button.
4. As soon as the coffee in the cup reaches the required level, press the 1 cup button  (fig. 12) again.

The quantity of coffee in the cup has now been programmed.


### Adjusting the coffee mill

The coffee mill is preset in the factory to make coffee correctly and should not require adjusting initially.

However, if after making the first few coffees you find that the coffee is too thin and not creamy enough or that delivery is too slow (a drop at a time), this can be corrected by adjusting the grinding adjustment knob (fig. 10).

**i** Please note:

The grinding adjustment knob must only be turned when the coffee mill is in operation.



If the coffee runs off too slowly or not at all, turn one click clockwise towards “7”. For fuller bodied creamier coffee, turn one click anti-clockwise towards “1” (do not turn more than one click at a time otherwise the coffee


could be delivered a drop at a time).

These adjustments will only be evident after at least 2 cups of coffee have been delivered.

If this adjustment does not obtain the desired result, turn the knob another click.

### Tips for a hotter coffee



For a hotter coffee, before delivery you are recommended to:

- rinse the appliance through by pressing the  button. Hot water flows out of the coffee spouts and heats the internal circuit of the machine so that the coffee delivered will be hotter.
- warm the cups with hot water (using the hot water function);
- select the “high” coffee temperature in the menu.





### Making coffee using coffee beans

**!** Important!

Do not use caramelised or candied coffee beans as they could stick to the coffee mill and make it unusable.

1. Fill the container with coffee beans (fig. 11).
2. Place under the coffee spouts:
  - 1 cup if you want one coffee (fig. 9);
  - 2 cups if you want 2 coffees.
3. Lower the spouts as near as possible to the cup. This makes a creamier coffee (fig. 13).
4. Press the button corresponding to the number of coffees required (1 cup  or 2 cups , figs. 12 and 14).
5. Preparation begins. The amount of coffee selected is displayed together with a progress bar which gradually fills as preparation progresses.

**i** Please note:

- While the coffee maker is making coffee, delivery can be interrupted at any moment by pressing one of the two coffee buttons ( or ).
- At the end of delivery, to increase the quantity of coffee in the cup, just press (within 3 seconds) one of the coffee buttons ( or ).

Once the coffee has been made, the appliance is ready to use again.

**i** Please note:

For hotter coffee, see the section “**Tips for a hotter coffee**” (page 13).

**!** Important!

- If the coffee is delivered a drop at a time, too thin and not creamy enough or too cold, read the tips in the “Troubleshooting” section on page 39.
- Various messages (fill tank, empty grounds container, etc.) could be displayed while using the machine. Their meaning is explained in the section “Displayed messages” (page 38).

### Making coffee using pre-ground coffee


**!** Important!

- Never add pre-ground coffee when the machine is off or it could spread through the inside of the machine and dirty it. This could damage the appliance.
- Never use more than 1 level measure or it could dirty the inside of the coffee maker or block the funnel.




**i** Please note:

If you use pre-ground coffee, you can only make one cup of coffee at a time.

1. Press the  button (fig. 7) until “PRE-GROUND” is displayed.
2. Make sure the funnel is not blocked, then add one level measure of pre-ground coffee (fig. 15).
3. Place a cup under the coffee spouts.



4. Press the 1 cup coffee button  (fig. 12).
5. Preparation begins. The amount of coffee selected is displayed together with a progress bar which gradually fills as preparation progresses.

## MAKING CAPPUCCINO AND HOT MILK (NOT FROTHED)

---



### *Important! Danger of burns*

During preparation, steam is given off. Take care to avoid scalds.


1. When making cappuccino, prepare the coffee in a large cup;
2. Fill a container with about 100 grams of milk for each cappuccino to be made. In choosing the size of the container, bear in mind that the milk doubles or triples in volume.



### *Please note:*

For a richer denser froth, use skimmed or partially skimmed milk at refrigerator temperature (about 5°C).

To avoid milk with poor froth or large bubbles, always clean the cappuccino maker as described in the section “Cleaning the cappuccino maker after use” on page 32.

3. Make sure the ring on the cappuccino maker is positioned downwards in the CAPPUCCINO position (fig. 16).
4. Press the  button. “Heating up... Please wait” is displayed, followed after a few seconds by “TURN STEAM KNOB”.
5. Turn the cappuccino maker outwards, immersing it in the milk container (fig. 17). Take care never to immerse the black ring.
6. Turn the steam knob to the I position (fig. 4) . Steam is delivered from the cappuccino maker, giving the milk a creamy frothy appearance and making it more voluminous.
7. To obtain a creamier froth, rotate the container with slow upward movements.  
You should not deliver steam for more than 3 minutes at a time.
8. When you have obtained the required froth, stop steam delivery by turning the steam knob back to the 0 position.



### *Important! Danger of burns*

Stop steam delivery before removing the container with the frothed milk to avoid burns caused by splashes of boiling milk.

9. Add the frothed milk to the cup of coffee prepared previously.

The cappuccino is ready. Sweeten to taste and, if desired, sprinkle the froth with a little cocoa powder.

### **Making hot milk (without froth)**

To make hot milk without froth, proceed as described in the above section, making sure the ring on the cappuccino maker is positioned upwards in the “HOT MILK” position.

### **Cleaning the cappuccino maker after use.**

Clean the cappuccino maker each time you use it to avoid the build-up of milk residues or blockages.



### *Important! Danger of burns*

When cleaning the cappuccino maker, a little hot water comes out. Avoid contact with splashes of water.

1. Discharge a little water for a few seconds by rotating the steam knob to the I position. Then turn the steam knob to the 0 position to stop the flow of hot water.
2. Wait a few minute for the cappuccino maker to cool down. Turn the cappuccino maker outwards and remove it by pulling it downwards (fig. 18).
3. Move the ring upwards (fig. 19).
4. Remove the nozzle downwards (fig. 20).
5. Make sure the two holes shown by the arrow in fig. 21 are not blocked. If necessary, clean with a pin.
6. Replace the nozzle, move the ring downwards and put the cappuccino maker back on the nozzle (fig. 22), turning it and pushing it upwards until it is attached.

## HEATING WATER

---



### *Important! Danger of burns.*

Never leave the machine unsupervised while delivering hot water. Stop delivery of hot water as described below when the cup is full.

1. Place a container under the cappuccino maker (as close as possible to avoid splashes) (fig. 17).
2. Turn the steam knob to the **I** position (fig. 4). "HOT WATER..." is displayed and delivery begins.
3. Stop by turning the steam knob to the **0** position.



**Please note:**

If "Energy Saving" mode is active, you may have to wait a few seconds before the hot water is delivered.

## CLEANING

### Cleaning the coffee maker

The following parts of the machine must be cleaned regularly:

- coffee grounds container (A13),
- drip tray (A17) and condensate tray (A14),
- water tank (A9),
- coffee spouts (A12),
- pre-ground coffee funnel (A6),
- inside of the machine, accessible after opening the infuser door (A10),
- infuser (A11).



**Important!**

- Do not use solvents, abrasive detergents or alcohol to clean the coffee maker. With De'Longhi superautomatic coffee makers, you need not use chemical products to clean the machine.
- None of the components can be washed in a dishwasher.
- Do not use metal objects to remove encrustations or coffee deposits as they could scratch metal or plastic surfaces.

### Cleaning the coffee grounds container

When "EMPTY GROUNDS CONTAINER" is displayed, the grounds container must be emptied and cleaned.

Until the grounds container has been cleaned, the appliance continues to display the message and coffee cannot be made.

To clean (with the machine on):

- Remove the drip tray (fig. 23), empty and clean.
- Empty the grounds container and clean tho-

roughly to remove all residues left on the bottom. This can be done with the spatula on the brush (C2) provided.

- Check the condensate tray (red) and empty if necessary.



**Important!**

When removing the drip tray, the grounds container **must** be emptied, even if it contains few grounds.

If this is not done, when you make the next coffees, the grounds container may fill up more than expected and clog the machine.

### Cleaning the drip tray and condensate tray



**Important!**

If the drip tray is not emptied regularly, the water could overflow from the edge and seep inside or around the coffee maker.

This could damage the machine, the surface it rests on or the surrounding area.

The drip tray is fitted with a level indicator (red) showing the level of water it contains (fig. 24). Before the indicator protrudes from the cup tray, the drip tray must be emptied and cleaned.

To remove the drip tray:

1. Remove the drip tray and the grounds container (fig. 23);
2. Empty the drip tray and grounds container and wash them;
3. Check the red condensate tray and empty if necessary;
4. Replace the drip tray and grounds container.

### Cleaning the inside of the coffee maker



**Danger of electric shock!**

Before cleaning internal parts, the machine must be turned off (see "Turning off") and unplugged from the mains power supply. Never immerse the coffee maker in water.

1. Check regularly (about once a month) that the inside of the appliance (accessible after removing the drip tray) is not dirty. If necessary, remove coffee deposits with the brush provided or a sponge.

2. Remove the residues with a vacuum cleaner (fig. 25).

### Cleaning the water tank

1. Clean the water tank (A9) regularly (about once a month and whenever you replace the water softener filter (if provided) with a damp cloth and a little mild washing up liquid.
2. Remove the filter (if present) and rinse with running water.
3. Replace the filter (if provided), fill the tank with fresh water and replace the tank.

### Cleaning the coffee spouts

1. Clean the coffee spouts with a sponge or cloth (fig. 26A).
2. Check the holes in the coffee spout are not blocked. If necessary, remove coffee deposits with a toothpick (fig. 26B).

### Cleaning the pre-ground coffee funnel

Check regularly (about once a month ) that the pre-ground coffee funnel (A6) is not blocked. If necessary, remove coffee deposits with the brush (C2) supplied.

### Cleaning the infuser

The infuser (A11) must be cleaned at least once a month.



#### **Important!**

The infuser may not be extracted when the machine is on.

1. Make sure the machine is correctly turned off (see “Turning the appliance off” on page 28).
2. Remove the water tank.
3. Open the infuser door (fig. 27) on the right side.
4. Press the two red release buttons inwards and at the same time pull the infuser outwards (fig. 28).

#### *Important!*


**RINSE WITH WATER ONLY**

**NO WASHING UP LIQUID - NO DISH WASHER**

Clean the infuser without using washing up liquid as it could be damaged.


5. Soak the infuser in water for about 5 minutes, then rinse under the tap.

6. Use the brush (C2) to remove any coffee residues left in the infuser housing, visible through the infuser door.
7. After cleaning, replace the infuser by sliding it onto the internal support, then push the PUSH symbol fully in until it clicks into place.




#### *Please note:*

If the infuser is difficult to insert, before insertion, adapt it to the right size by pressing the two levers shown in the figure.



7. Once inserted, make sure the two red buttons have snapped out.
8. Close the infuser door.
9. Replace the water tank.



## DESCALE

Descal the machine when the message “DESCALE!” flashes on the display.



#### **Important!**

Descaler contains acids which may irritate the skin and eyes.

It is vital to respect the manufacturer's safety warnings given on the descaler pack and the warnings relating to the procedure to follow in the event of contact with the skin and eyes.



*Please note:*

Use De'Longhi descaler only.

Under no circumstances should you use sulphamic or acetic based descalers. Their use invalidates the guarantee.

Failure to descale the appliance as described also invalidates the guarantee.

1. Turn the machine on.
2. Press the **P** button to enter the menu.
3. Turn the selection knob until "Descaling" is displayed.
4. Select by pressing the button: "DESCALING CONFIRM?" is displayed. Press again to activate the function.
5. The message "INSERT DESCALER CONFIRM?" is displayed.
6. Completely empty the water tank (A9) and remove the water softener filter (if present).
7. Pour the descaler into the tank up to the level **A** (corresponding to a 100 ml pack) marked on the back of the tank (fig. 29A), then add water up to level **B** (fig. 29B).
8. Place an empty container with a minimum capacity of 1.5 litres under the cappuccino maker (A19) (fig. 4).



**Important! Danger of burns**

Hot water containing acid flows from the cappuccino maker.

Avoid contact with splashes of water.

9. Press the button to confirm introduction of the solution. "Turn steam knob" is displayed.
10. Turn the steam knob to the **I** position (fig. 4). The descaling programme starts and the descaler liquid comes out of the cappuccino maker. The descale programme automatically performs a series of rinses and pauses to remove limescale deposits from inside the machine.

After about 30 minutes, the message "FILL TANK!" is displayed. The appliance is now ready for rinsing through with clean water.

11. Empty the container used to collect the descaler solution and replace it empty under the cappuccino maker.
12. Remove the water tank, empty, rinse under running water, fill with clean water and repla-

ce. "Rinsing" is displayed.

13. Hot water comes out of the cappuccino maker.
14. When the water tank is completely empty, "TURN STEAM KNOB" is displayed.
15. Turn the knob to the 0 position, insert the filter in the tank (if present), fill the water tank again and the appliance is ready for use.

## SETTING WATER HARDNESS

The DESCALE message is displayed after a period of time established according to water hardness. The machine is factory set for a hardness value of 4. The machine can also be programmed according to the hardness of the mains water in the various regions so that the machine needs to be descaled less often.

### Measuring water hardness

1. Remove the "TOTAL HARDNESS TEST" indicator paper attached to this manual from its pack.
2. Immerse the paper completely in a glass of water for one second.
3. Remove the paper from the water and shake lightly. After about a minute, 1, 2, 3, or 4 red squares form, depending on the hardness of the water. Each square corresponds to one level.

Level 1

Level 2

Level 3

Level 4

### Set water hardness

1. Press the P button to enter the menu.
2. Turn the selection knob to select "WATER HARDNESS".
3. Confirm the selection by pressing the button.
4. Turn the selection knob and set the level shown by the indicator paper (see previous paragraph).
5. Press the button to confirm the setting.
6. Press the button to exit the menu.

The machine is now reprogrammed with the new water hardness setting.

## **WATER SOFTENER FILTER**

Certain models are fitted with a water softener filter. If this is not the case with your model, you are recommended to purchase one from De'Longhi Customer Services.

To use the filter correctly, follow the instructions below.

### **Installing the filter**

1. Remove the filter from the packaging.
2. Turn the date indicator disk (see fig. 30) until the next 2 months of use are displayed.






*Please note:*

The filter lasts about two months if the appliance is used normally. If the coffee maker is left unused with the filter installed, it will last a maximum of three weeks.

3. Remove the tank from the appliance and fill with water.
4. Insert the filter in the water tank and immerse it completely for ten or so seconds, sloping it to enable the air bubbles to escape (fig. 31).
5. Insert the filter in the filter housing (fig. 32A) and press as far as it will go.
6. Close the tank with the lid (fig. 32B), then replace the tank in the machine.

When you install the filter, you must notify the appliance of its presence.




7. Press the **P** button to enter the menu;
8. Turn the selection knob (fig. 8) until "Install filter" is displayed;
9. Press the  button;
10. The message "Activate?" is displayed.
11. Press the  button to confirm the selection. "TURN STEAM KNOB" is displayed.
12. Place a container (min. capacity: 100 ml) under the cappuccino maker.
13. Turn the steam knob (fig. 4). "Hot water... Confirm?" is displayed;
14. Press the  button to confirm the selection. The appliance begins delivering hot water and the message "PLEASE WAIT..." is displayed.
15. After delivery, "TURN STEAM KNOB" is displayed.

16. Turn the steam knob (fig. 4) to the "0" position. The appliance returns automatically to the "ready for coffee" state.

The new filter is active and indicated by an asterisk displayed under "Install filter". You can now use the coffee maker.

### **Replacing the filter**

When "REPLACE FILTER!" is displayed, after two months (see date indicator) or when the appliance has not been used for 3 weeks, you should replace the filter:




1. Remove the exhausted filter;
2. Remove the new filter from the packaging;
3. Turn the date indicator disk (see fig. 30) until the next 2 months of use are displayed (the filter lasts about two months);
4. Refill the tank;
5. Insert the filter in the water tank and immerse it completely, sloping it to enable the air bubbles to escape (fig. 31);
6. Place the filter in the filter housing (fig. 32A) and press as far as it will go. Close the tank with the lid (fig. 32B), then replace the tank in the machine;
7. Place a container (min. capacity: 100 ml) under the cappuccino maker.
8. Press the **P** button to enter the menu;
9. Turn the selection knob until "Replace Filter" is displayed.
10. Press the  button.
11. The message "Confirm?" is displayed.
12. Press the  button to confirm the selection. "TURN STEAM KNOB" is displayed;
13. Turn the steam knob. "Hot Water... Confirm?" is displayed;
14. Press the  button to confirm the selection. The appliance begins delivering hot water and the message "Please Wait..." is displayed.
15. After delivery, "TURN STEAM KNOB" is displayed. Turn the steam knob to the 0 position and the appliance returns automatically to the "READY FOR COFFEE" position.

The new filter is now active and you can use the coffee maker.

### **Removing the filter**

If you want to continue using the appliance without a filter, you must remove it and notify the

appliance of its removal as follows:

1. Extract the tank and exhausted filter;
2. Press the **P** button to enter the menu;
3. Turn the selection knob (fig. 8) until "Install filter\*" is displayed;
4. Press the  button;
5. "Deactivate?" is displayed;
6. Press the  button to confirm and the  button to exit the menu.

## TECHNICAL SPECIFICATION

Voltage:	220-240 V~ 50/60 Hz max. 10A
Absorbed power:	1450W
Pressure:	15 bar
Water tank capacity:	1,8 L max
Size LxHxD:	238x345x430 mm
Cable length:	1,15 m
Weight:	9,1 Kg
Beans container capacity:	250 g max

**CE** The appliance complies with the following EC directives:

- European Stand-by Regulation 1275/2008;
- Low Voltage Directive 2006/95/EC and subsequent amendments;
- EMC Directive 2004/108/EC and subsequent amendments
- Materials and accessories coming into contact with food conform to EEC regulation 1935/2004.

## DISPOSAL



Important information for correct disposal of the product in accordance with EC Directive 2002/96/EC.

At the end of its working life, the product must not be disposed of as urban waste.

It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources.

As a reminder of the need to dispose of household appliances separately, the product is marked with a rubbish bin bearing a cross.


## DISPLAYED MESSAGES

DISPLAYED MESSAGE	POSSIBLE CAUSE	REMEDY
FILL TANK !	<ul style="list-style-type: none"> <li>Insufficient water in the tank.</li> </ul>	<ul style="list-style-type: none"> <li>Fill the tank with water and/or insert it correctly, pushing it as far as it will go until it clicks into place (fig. 3).</li> </ul>
EMPTY GROUNDS CONTAINER	<ul style="list-style-type: none"> <li>The grounds container (A13) is full.</li> </ul>	<ul style="list-style-type: none"> <li>Empty the grounds container and drip tray, clean and replace (fig. 23). Important: when removing the drip tray, the grounds container <b>MUST</b> be emptied, even if it contains few grounds. If this is not done, when you make the next coffees, the grounds container may fill up more than expected and clog the machine.</li> </ul>
GROUND TOO FINE ADJUST MILL! <i>alternating with...</i> TURN STEAM KNOB	<ul style="list-style-type: none"> <li>The grinding is too fine and the coffee is delivered too slowly or not at all.</li> </ul>	<ul style="list-style-type: none"> <li>Repeat coffee delivery and turn the grinding adjustment knob one click clockwise towards "7" while the coffee mill is in operation. If after making at least 2 coffees delivery is still too slow, repeat the correction procedure, turning the grinding adjustment knob another click (see the section "Adjusting the coffee mill" on page 12). If the problem persists, turn the steam knob to the I position and deliver water from the cappuccino maker.</li> </ul>
INSERT GROUNDS CONTAINER	<ul style="list-style-type: none"> <li>After cleaning, the grounds container has not been replaced.</li> </ul>	<ul style="list-style-type: none"> <li>Remove the drip tray and insert the grounds container.</li> </ul>
ADD PRE-GROUND COFFEE	<ul style="list-style-type: none"> <li>The "pre-ground coffee" function has been selected without placing any pre-ground coffee in the funnel.</li> </ul>	<ul style="list-style-type: none"> <li>Place pre-ground coffee in the funnel or deselect the "pre-ground" function.</li> </ul>
DESCALE!	<ul style="list-style-type: none"> <li>The machine must be descaled.</li> </ul>	<ul style="list-style-type: none"> <li>The descaling procedure described in the "Descaling" section needs to be performed as soon as possible.</li> </ul>
LESS COFFEE!	<ul style="list-style-type: none"> <li>Too much coffee has been used.</li> </ul>	<ul style="list-style-type: none"> <li>Select a milder taste or reduce the quantity of pre-ground coffee.</li> </ul>
FILL BEANS CONTAINER!	<ul style="list-style-type: none"> <li>The coffee beans have run out.</li> </ul>	<ul style="list-style-type: none"> <li>Fill the beans container</li> </ul>
	<ul style="list-style-type: none"> <li>The pre-ground coffee funnel is clogged.</li> </ul>	<ul style="list-style-type: none"> <li>Empty the funnel with the help of a brush as described in the section "Cleaning the pre-ground coffee funnel".</li> </ul>
INSERT INFUSER ASSEMBLY!	<ul style="list-style-type: none"> <li>The infuser has not been replaced after cleaning.</li> </ul>	<ul style="list-style-type: none"> <li>Insert the infuser as described in the section "Cleaning the infuser".</li> </ul>
INSERT TANK	<ul style="list-style-type: none"> <li>The tank is not correctly in place.</li> </ul>	<ul style="list-style-type: none"> <li>Insert the tank correctly and press as far as it will go.</li> </ul>
GENERAL ALARM!	<ul style="list-style-type: none"> <li>The inside of the appliance is very dirty.</li> </ul>	<ul style="list-style-type: none"> <li>Clean the inside of the appliance thoroughly, as described in the section "Cleaning and maintenance". If the message is still displayed after cleaning, contact a customer services.</li> </ul>

## TROUBLESHOOTING

Below is a list of some of the possible malfunctions.

If the problem cannot be resolved as described, contact Customer Services.

PROBLEM	POSSIBLE CAUSE	REMEDY
The coffee is not hot	• The cups were not preheated.	• Warm the cups by rinsing them with hot water (N.B. you can use the hot water function).
	• The infuser has cooled down because 2/3 minutes have elapsed since the last coffee was made.	• Before making the coffee, warm the infuser by pressing the  button (see section "Manual rinsing").
	• Low coffee temperature is set.	• In the menu, set a high coffee temperature.
The coffee is thin or not creamy enough.	• The coffee is ground too coarsely.	• Turn the grinding adjustment knob one click anticlockwise towards "1" while the coffee mill is in operation (fig. 10). Continue one click at a time until coffee delivery is satisfactory. The effect is only visible after delivering two coffees (see the section "Adjusting the coffee mill" on page 12).
	• Wrong type of coffee	• Use coffee for espresso coffee makers.
The coffee is delivered too slowly or a drop at a time.	• The coffee is ground too finely.	• Turn the grinding adjustment knob one click clockwise towards "7" while the coffee mill is in operation (fig. 10). Continue one click at a time until coffee delivery is satisfactory. The effect is only visible after delivering two coffees (see the section "Adjusting the coffee mill" on page 12).
Coffee does not come out of one of the spouts.	• The spouts are blocked.	• Clean the spouts with a toothpick.
The frothed milk has large bubbles	• The milk is not cold enough or is not semi-skimmed.	• You should ideally use skimmed or semi-skimmed milk at refrigerator temperature (about 5°C). If the result is still disappointing, try another brand of milk.
The milk is not frothed	• Cappuccino maker dirty.	• Clean as described in the section "Cleaning the cappuccino maker after use" on page 14.
	• The ring on the cappuccino maker is NOT in the cappuccino position.	• Place the ring in the CAPPUCCINO position.
Steam delivery stops	• A safety device stops steam delivery after 3 minutes.	• Wait, then activate the steam function again.
The appliance does not come on.	• It is not plugged into the mains socket.	• Plug into the mains socket.
	• The main switch (A8) is not turned on.	• Place the main switch in the I position (fig. 1).