



HOW TO GET THE BEST RESULTS FROM YOUR OVEN

What do I want to do?	What function should I choose?	Use Instr. page	Amt. & time chart page	
• Keep food warm	Microwave only Power 75W	27 28		
• Defrost	Microwave only Power 110W	27 28	29	
• Melt butter and soften cheese • Heat pastry goods	Microwave only Power 260W or 375W	27 28 33	31 33	
• Making boiled vegetables • Cooking fish • Cooking rice, making soup • Heating foods ready cooked • Cooking fruit	Microwave only Power 750W	27 32 33 30 33	32 31 33	
• Grill hamburgers, chops, frankfurters, sausages, toast, etc. in a "traditional" way	Grill only	35	35	
• Cooking vegetables au gratin • Making lasagne or pasta oven dishes • Making all types of roasts, poultry, skewered meats, etc.	Functions in microwave and grill sequence First stage Power or 525W or Second stage Grill only ▼▼▼	36 37	37	

TECHNICAL DATA

Outer measurements (LxDxH)	480x272x360		For additional data, consult the serial plate glued to the back of the equipment.
Inner measurements (LxDxH)	285x180x290		
Oven's net volume	17 lt.		This equipment is in compliance with EEC Directives 89/336 and 92/31 related to Electromagnetic Compatibility.
Approximate weight	14,6 kg.		
Turntable diameter	27,5 cm		
Oven light	25 W		

OUTPUT POWER

In this oven the maximum power yielded by the microwaves is 750W. This value is shown on the data plate placed on the back of the appliance, under the heading **MICRO OUTPUT**.








In some models the maximum power yielded in WATTS, is also indicated in the symbol on the side, shown on the door.

(ONLY FOR U.K.) The **letter** indicates the **heating category** to which your oven belongs: some chilled food pre-cooked frozen or chilled give heating instructions corresponding to the various categories. Follow those instructions related to the category indicated for your oven.

The levels of intermediate power available are shown on this page. This information will be useful for you to consult the prescription pads for microwaves currently on sale.

I M P O R T A N T S A F E G U A R D S

Before beginning to use this oven, read this important information to obtain the best possible result.

- 1) This oven has been designed to thaw, heat up and cook foods at home. It must not be used for other purposes and must not be altered or tampered with in any way.
- 2) Before connecting this oven to your electrical system, check to be certain that the door closes tightly. Also check to see that the metal frame is not warped and that the hinges and hooks have not loosened. In the event that these parts have been damaged, the microwave oven cannot be used until a qualified technician (trained by the manufacturer or by its Customer Service) has made the necessary repairs. 
- 3) Do not try to make the oven operate while the door is open by tampering with the safety devices.
- 4) Do not operate this oven if objects of any type whatsoever get caught between the front of the oven and the oven door. Also keep the **inside of the door (E)** completely clean by using a damp cloth and non-abrasive detergent. Do not let dirt or food residue build up between the front of the oven and the oven door. 
- 5) Do not operate the oven if its electrical power cable or plug are damaged (because there is the danger of electric shocks).
- 6) **Adjustments, repairs and replacement of the power cable must be carried out only by technicians trained by the manufacturer or by one of the latter's Technical Service Centres.** Repair work performed by non-professional or unqualified individuals can be inherently dangerous. 
- 7) If you should see smoke coming out of the oven, **DO NOT OPEN THE OVEN DOOR.** Instead, immediately turn the oven off or pull the plug from its electric socket.
- 8) This oven must be used only by adults. **Never allow small children to approach the oven when it is operating (because they may burn themselves).** 
- 9) When cooking "Only MICROWAVE", **you absolutely must not pre-heat the oven (without foodstuffs in it) and you must not operate it when it is empty, because you might cause sparking.**
- 10) **Never place the turntable in water after it has been heated for a long time. The high thermal shock resulting would break the turntable.**
- 11) Before using this oven, check to be certain that the utensils and containers chosen are suitable for microwave oven use (see the section on "Glassware and Similar Items").
- 12) Look at the oven from time to time when food is heated or cooked in disposable containers of plastic, paper or other combustible material. Also, small portion of food may become combustible if over heated.
- 13) **Do not use recycled kitchen paper as it may contain metal particles that could cause it to ignite.**
- 14) **Do not cook eggs still in their shell.** The pressure which might form inside the shell would make the egg itself explode (even after it has already been cooked). Never heat up eggs that have already been cooked (unless such eggs are scrambled). 
- 15) Always pierce sealed container or loosen the lid before heating or cooking food. Otherwise the pressure inside those containers might build up and cause an explosion, even after the food itself has been cooked.


- 16) When heating liquids (water, coffee, milk, etc.), you may find that, because of delayed boiling, the liquid in question may suddenly boil up and spill out when removing the container scalding to your hand in the process. To prevent such a situation, you must place a heat-resistant plastic spoon or a glass stirrer in the container before starting to heat that liquid.
- 17) Do not heat up liquor having a high alcohol content or large amounts of oil (because overheating could cause such substances to burst into flame).
- 18) Refer to the charts in this instruction manual for the correct heating and cooking times.
- 19) **ALWAYS check the temperature of heated infant food before serving it so as to prevent burning. Always mix or shake the food to distribute the heat.**
- When using commercially available bottle sterilisers, before turning the oven on, ALWAYS make sure the container is filled with the quantity of water indicated by the manufacturer.**



E L E C T R I C A L C O N N E C T I O N S

Connect this equipment only to electrical outlets having a capacity of at least 10A.

Before using this oven, check to make certain that the electrical network is the same as that indicated



on the equipment's data plate and that the electrical outlet is connected to an efficient grounding (earth) terminal. **The manufacturer shall not be responsible in any manner whatsoever for harm or damage caused by failure to observe this norm.**

- **Electrical Connection for UK only** see page 39

I N S T A L L A T I O N

- 1) After having removed the oven from its box, check to make certain that the turntable spindle (D) is correctly fitted into its housing. Place the turntable support (G) in the middle of the cooking chamber and set the turntable (F) on top of it. The spindle (D) must be inserted in the related turntable housing.
- 2) Check to make certain that this equipment has not been damaged in transport and check especially to see if the door opens and closes correctly.
- 3) Set the oven on a flat, steady surface **at least 85 cm.** above the floor and out of the reach of small children, because when the oven is operating its door can get very hot.
- 4) **After having placed the oven on its work level, make sure that there is still a free space of at least 5 cm. between the oven's surfaces and the side as well as back walls, and a free space of at least 20 cm. above the oven (see Fig. 1). Also check to make sure the feed cord is not touching the appliance's rear wall, because the wall itself can get very hot while the grill is being used.**




fig. 1

anything atop the oven and check to be certain that the air outlet slots (located above, under and in the back of the oven) are ALWAYS FREE from obstruction (see Figs. 2 and 3).

- 6) Place the support unit (G) in the middle of the circular housing and set the turntable (F) atop the support. The spindle (D) must match up perfectly with its housing in the middle of the turntable.
- 7) **When you turn the oven on for the first time, there may be an odour of "newness" and a bit of smoke for about ten minutes. This is completely normal, and it is caused by substances used to protect the heating elements.**




fig. 2




fig. 3

GLASSWARE AND SIMILAR ITEMS

You can make use of all types of containers made of glass (preferably Pyrex), ceramics, porcelain and glazed pottery as long as they do not have decorations or metal parts (gilded borders, handles, feet). You can also use containers made of heat-resistant plastic. For short heating periods, you may use paper napkins, cardboard trays and plastic "throwaway" plates as a base. As far as shape and size are concerned, it is absolutely essential that containers be such as to allow the turntable to rotate.

In order to use large-size rectangular containers (which may not be able to rotate inside the cooking cavity), you can remove the spindle (D) from its housing to prevent the turntable (F) moving. Bear in mind that to be assured of


good results when carrying this out you must stir the food and turn the container around several times during the cooking process. **Containers made of metal, wood, recycled kitchen paper, cane and plate glass are not suitable for use in microwave ovens.** The metal rack supplied with your microwave have been fully tested for safe use. You should remember, too, that since microwaves heat the food and not the glassware, earthenware or similar containers for that food, it is possible to cook such foods in the serving dish and thereby avoid the problem of having to clean pans later.

If the oven is used in its **grill only** functions, any type of oven container may be used (see chart).

	Glass	Ceramics	Porcelain	Earthenware	Plastic for microwaves	Paper cups*	Paper plates*	Pyrex	Cardboard*	Metal containers	Glassware with metal parts	Special roasting paper
Microwave only	YES	YES	YES	YES	YES	YES	YES	YES	YES	NO	NO	YES
Grill only	NO	YES	YES	YES	NO	NO	NO	YES	NO	YES	YES	YES


* If the cooking time required is too long, there is a possibility of fire.

DESCRIPTION OF CONTROLS




ACCESSORIES PROVIDED

WIRE RACK



Grill only:
For all types of grilling.

TURNTABLE



The turntable is used for **all the functions**.

ADVICE ON USING YOUR OVEN CORRECTLY

Microwaves consist of electromagnetic radiation found in nature under the form of light waves (e.g., sunlight). Inside the oven, these waves penetrate food from all directions and heat up the water, fatty and sugar molecules.

Heat is produced very quickly only in the food itself, whereas the container being used warms up indirectly by means of heat given off by the heated food. This prevents food from sticking to its container, so you can use very little fatty sub-

stance or in some cases, no fat at all during the cooking process.

Therefore the cooking in a microwave oven is considered to be healthy and good for one's diet.

And in contrast to traditional methods, cooking in a microwave foodstuffs are less dehydrated, lose less of their nutritional value, and retain more of their original flavour.

Basic rules for correct cooking with a microwave oven

- 1) In order to set cooking times correctly, remember (in referring to the charts on the following pages) that when you increase the amount of foodstuffs the cooking time must likewise be proportionately increased and vice-versa. It is important to respect the "standing" times: **standing time** means that period during which the food must be left to "rest" after being cooked so as to allow an even greater spreading of the temperature within. The temperature of meat, for example, will rise about 5°-8° C. (approx. 9°-15° F.) during the standing time. Standing times may be observed either inside or outside the oven.
- 2) One of the main things you must do is **stir** the food where appropriate several times while it is being cooked. This helps distribute the heat more uniformly and thus shortens the cooking time.
- 3) It is also advisable to **turn** the foodstuff **over** where appropriate during its cooking process: this applies especially for meat, whether it is in large pieces (roasts, whole chickens, etc.) or small (chicken breasts, etc.).
- 4) **Foods with a skin, shell or peel (e.g., apples, potatoes, tomatoes, frankfurters, fish) must be pierced with a fork or sharp knife in several points so as to allow steam to escape and prevent exploding (see fig. 4).**
- 5) If you are preparing a large number of portions of the same food item (e.g., boiled potatoes), **place** them in a large dish to allow uniform cooking (see fig.5).
- 6) The lower the temperature at which a foodstuff is placed in a microwave oven, the longer the cooking time required. Food having a room temperature will cook more quickly than food having a refrigerator temperature.
- 7) Always cook by placing the food container in the centre of the turntable.
- 8) It is perfectly normal for **condensation to form** inside the oven and near the air outlet. **To reduce such condensation, cover the foodstuffs with clear-film, wax paper, a glass lid or simply an overturned plate.** Foods having a water content (e.g., greens and vegetables) cook better when covered. The covering of food also helps keep the oven clean on the inside. Make sure when using clear films that they are suitable for microwave use.




fig. 4




fig. 5

M I C R O W A V E - O N L Y F U N C T I O N



This function is suitable for:


- Keeping food hotpage 28
- Defrostingpage 28
- Heatingpage 30
- Cooking stew, white meats, fruit, vegetables, rice, soup and fishpage 32
- To brown the foods, to bake pastry and fruitpage 34

TURNING THE OVEN ON USING ONLY THE MICROWAVE FUNCTION

1

Place the food in a container suitable for microwave cooking and place it in the centre of the turntable


N.B: You do not have to pre-heat the oven.



2


Select the power you want by turning the upper knob (microwave power / grill function)

N.B.: If the knob is turned to the ▼▼▼ symbol, the microwave function will not be activated (only the grill function will operate).




3

Set the cooking time you want by turning the lower knob (timer) in a clockwise direction.



4

Once the set cooking time has expired, a **buzzer** will sound to signal that your food is ready



You can interrupt operations any time you wish simply by turning the lower knob (timer) to the STOP position. You can also change the cooking time (while the foodstuff is being cooked) simply by turning this same knob forward or backward. You can check on the situation while the cooking is in progress by opening the door and examining the food. That move will interrupt the oven's operations, but they will begin again once the door has been closed.



USING THE MICROWAVE-ONLY FUNCTION TO KEEP FOOD HOT

This function enables you to keep food hot, whether that food be just cooked or re-heated, without it drying out or sticking to its container and is suitable for most foods.

By turning the to the power selector knob **KEEP WARM** setting and covering the food with a plate or plastic film, you will find that foods will remain warm up to serving time.

You can leave foods in their cooking container if they are covered.

USING THE MICROWAVE-ONLY FUNCTION FOR DEFROSTING

- Foods frozen in bags or plastic sheeting or in their packaging may be placed directly in the oven, as long as they have no metal parts (e.g., bands or closure rivets).
- Certain foods, such as greens, vegetables and fish, do not generally require defrosting before you begin cooking them.
- Stewed foods and meats as well as meat sauces defrost better and quicker if they are stirred from time to time, turned over or broken up.
- While defrosting, meat and fish lose their liquid content. It is recommended, therefore, that you defrost such items in a tray or basin.
- It is advisable to separate each individual piece of meat from its bag before putting it in the freezer. This will help you save valuable time will preparing foods.
- Be careful about following the timings printed on frozen products, because they are guideline and may not always be correct. It is best to use defrosting times slightly less than those indicated. The time needed for defrosting will vary in terms of the degree to which the food has been frozen.



Defrosting times

Type	Quantity	Upper knob	Lower knob (minutes)	Notes	Standing time (minutes)
MEAT					
• Roasts (pork, beef, veal, etc.)	1 kg	*	30 - 33	(*)	20
	200 gr	"	11 - 13		5
• Steaks, cutlets, meat slices	500 gr	"	19 - 21		10
• Stew, goulash	500 gr	"	15 - 17		15
• Ground meat	250 gr	"	12 - 14		10
"	200 gr	"	12 - 14		10
• Hamburger	300 gr	"	14 - 16		10
• Sausages					
POULTRY					
	1,5 kg	"	35 - 38	At the end of the rest period, wash under hot water to remove possible ice	20
• Duck, turkey	1,5 kg	"	35 - 38		20
• Whole chickens	500 gr	"	20 - 22		10
• Cut-up chicken	300 gr	"	19 - 21		10
• Chicken breasts					
VEGETABLES					
	500 gr	"	23 - 25	To make defrosting easier, stir the vegetables from time to time	5
• Cubed eggplant	500 gr	"	22 - 24		5
• Cut-up peppers	500 gr	"	19 - 21		5
• Shelled peas	300 gr	"	15 - 17		5
• Artichoke hearts	500 gr	"	20 - 22		5
• Pieces of asparagus	500 gr	"	22 - 24		5
• Cut-up green beans	500 gr	"	21 - 23		5
• Whole broccoli	500 gr	"	21 - 23		5
• Brussels sprouts	500 gr	"	20 - 22		5
• Cut-up carrots	450 gr	"	19 - 21		5
• Cauliflower tops	300 gr	"	14 - 16		5
• Mixed vegetables	300 gr	"	15 - 17		5
• Cut-up spinach					
FISH					
• Filleted fish	300 gr	"	15 - 17	Fish is better cook from frozen if it does not require further preparation.	7
• Cut-up fish	400 gr	"	16 - 18		7
• Whole fish	500 gr	"	19 - 21		7
• Prawn, shrimps	400 gr	"	16 - 18		7
DAIRY PRODUCTS					
• Butter	250 gr	"	11 - 13	Remove the aluminium paper and metal pieces.	10
• Cheese	250 gr	"	12 - 14	Partially defrosted. Needs the standing time.	15
• Cream	200 ml	"	14 - 16	Cream is to be removed from its container and put on a plate.	5
BREAD PRODUCTS					
• 2 average-size rolls	150 gr	"	3 - 4	Put the bread directly on the turntable	3
• 4 average-size rolls	300 gr	"	7 - 8		3
• Sliced home-style bread	250 gr	"	7 - 8		3
• Whole-wheat bread	250 gr	"	7 - 8		3
FRUIT					
• Strawberries, prunes, cherries, currants, apricots	500 gr	"	14 - 15	Mix 2 or 3 times	10
• Raspberries	300 gr	"	10 - 11	Mix 2 or 3 times	10
• Blackberries	250 gr	"	8 - 9	Mix 2 or 3 times	6


(*) These indications are suitable for carrying out the minced meat defrosting test in accordance with IEC regulation 705, par. 18.3. Turn the load upside-down halfway through the time set. The load should rest directly on the rotating plate. Further indications, also regarding other performance tests in accordance with IEC regulation 705, are shown in the table on page 2



USING THE MICROWAVE-ONLY FUNCTION FOR RE-HEATING

Heating food in a microwave oven is much quicker and energy efficient than traditional methods.


- We recommend that you heat foods (especially if they are frozen) to a temperature of at least 70° C. (it must be piping hot!). Leave to stand for a ten minutes as you will not be able to eat that food immediately because it will be too hot.
- This will ensure that any possible bacteria present in food will have been killed.
- To heat pre-cooked or frozen foods, follow these rules:
 - remove the food from any metal containers;
 - cover it with plastic wrap (the clear-film type suitable for microwave ovens) or wax paper; in this way, all the food's natural flavour will be preserved and the oven will stay cleaner; you may also cover the food with an up turned plate;
 - if possible, stir or turn the food over frequently so as to speed up the heating process and to keep the heat uniform;
 - follow the cooking times listed with caution; remember that under certain conditions the timings given must be lengthened
- Frozen foods must be defrosted before the heating process begins. The lower the food's initial temperature, the longer the time needed for heating.
- Foodstuffs and drinks may be heated briefly in paper or plastic containers. In any event, however, such containers may become misshapen if the heating time is too long.





Heating times

Type	Quantity	power level	times (minutes)	Notes
SOFTENING FOOD				
<ul style="list-style-type: none"> Chocolate/icing Butter 	100 gr 50 -70 gr		5 - 6 0'.7"-0'.12"	Put on a plate. Mix the icing once.
CHILLED FOOD (INITIAL TEMP. 5/8°C) UP TO 20/30°C				
<ul style="list-style-type: none"> Yoghurt Baby's bottle 	125 gr 240 gr	"	0'.12"-0'.17" 0'.35"-0'.40"	Remove metal foil. Heat the baby's bottle without the teat and mix it immediately after heating to make the temperature uniform. Check the temperature of the contents before use. With milk at room temperature the heating time is lower. To avoid risk of fire when using dried milk please stir evenly. Please use already sterilized milk.
CHILLED PRECOOKED FOOD (INITIAL TEMP. 5/8°C) UP TO APPROX. 70° C				
<ul style="list-style-type: none"> Packet of lasagne or of pasta with filling Packet of meat with and/or vegetables Packet of fish and/or vegetables Plate of meat and/or vegetables plate of pasta, cannelloni or lasagne Plate of fish and/or rice 	400 gr 400 gr 300 gr 400 gr 400 gr 300 gr	"	6 - 8 6 - 8 5 - 7 7 - 9 7 - 9 6 - 8	Packets of any kind of commercially available pre-cooked food, to be heated to a temp. of 70° C. Remove the food from any rice metal packets and put it directly onto the plate from which it is to be eaten. For best results, always cover the food. Portions of any kind of already cooked food, to heat to a temp. of 70°C. The food is placed directly onto the plate from which it is to be eaten and is always covered either with a transparent film or with an upturned plate.
FROZEN FOOD TO REHEAT/COOK (INITIAL TEMP. -18°/-20°C) UP TO APPROX. 70° C				
<ul style="list-style-type: none"> Packet of lasagne or of pasta with filling Packet of meat with rice and/or vegetables Packet of fish and/or pre-cooked vegetables Packet of fish and/or raw vegetables Portion of meat and/or vegetables Portion of pasta, cannelloni or lasagne Portion of fish and/or rice 	400 gr 400 gr 300 gr 300 gr 400 gr 400 gr 300 gr	"	8 - 10 7 - 9 5 - 7 10 - 12 8 - 10 9 - 11 6 - 8	Packets of any kind of commercially available pre-cooked frozen food, to be heated to a temp. of 70° C directly in its packet. Remove the food from any metal containers and put it directly onto the plate from which it is to be eaten, increasing cooking time by a few minutes. Remove the raw food from the packets and place it in a container suitable for microwaves and cover. Portions of any kind of already cooked frozen food, to be heated to a temperature of 70°C. Place the frozen food in the plate from which it is to be eaten and cover it with another upturned plate or pyrex dish. Check that it is hot in the centre; where possible, mix the food.
CHILLED DRINKS (INITIAL TEMP. 5°/8° C) UP TO APPROX. 70°C				
<ul style="list-style-type: none"> 1 cup of water 1 cup of milk 1 cup of coffee 1 plate of broth 	180 cc 150 cc 100 cc 300 cc	"	2'.30"-3" 2-2'.30" 2-2'.30" 5 - 6	All the drinks should be mixed after being heated to make the temperature uniform. For the broth we recommend covering it with an upturned plate.
DRINKS AT ROOM TEMPERATURE (INITIAL TEMP. 20°/30°C) UP TO APPROX. 70° C				
<ul style="list-style-type: none"> 1 cup of water 1 cup of milk 1 cup of coffee 1 plate of broth 	180 cc 150 cc 100 cc 300 cc	"	2-2'.30" 1'.30"-2 1'.30"-2 4 - 5	All the drinks should be mixed after being heated to make the temperature uniform. For the broth we recommend covering it with an upturned plate.



USING THE MICROWAVE-ONLY FUNCTION FOR COOKING

MEATS

When using the microwave-only function to cook meat, you should cover the meat with plastic wrap made for microwave oven use; in this way, the heat is distributed better and you will prevent the loss of juices that often leads to dried-up and stringy meat. This oven function is suitable for making stews, goulash, chicken breasts, etc. To prepare roasts and skewered meat dishes (among others), you must use the combined function.

FISH

In a microwave oven, fish can be prepared very quickly and with excellent results. You can season it with a little oil or butter (or not season it at all, if you so prefer). Cover the fish with clear-sheet. The skin is to be slit, of course, and filleted fish must be placed in a uniform fashion. We recommend that you not use this oven to cook fish which has been dipped in egg batter.

GREENS AND VEGETABLES

Greens and vegetables cooked in a microwave oven retain more of their colour and nutritional value than when cooked in traditional ovens. Before cooking greens and vegetables, wash and clean them.

Larger-sized varieties of this category are to be cut up into uniform pieces.

Per every 500 gr. of greens or vegetables add about 5 teaspoons of water (fibre-type vegetables need more water). Greens and vegetables must **always** be covered with plastic wrap.

Cooking times

Type	Quantity	Upper knob	Lower knob (minutes)	Notes	Standing time (minutes)
FISH					
• Filleted	300 gr		9 - 11	Cover with plastic wrap	2
• Slices	300 gr	"	11 - 13	Cover with plastic wrap	2
• Whole	500 gr	"	12 - 14	Cover with plastic wrap	2
• Whole	250 gr	"	9 - 11	Cover with plastic wrap	2
• Cut-up fish	400 gr	"	11 - 13	Cover with plastic wrap	2
• Crayfish	500 gr	"	11 - 13	Cover with plastic wrap	2
GREENS AND VEGETABLES					
• Asparagus	500 gr	"	11 - 12	Cut into 2-cm. pieces.	4
• Artichokes	300 gr	"	12 - 13	It would be better to use artichoke bottoms.	4
• Green beans	500 gr	"	13 - 14	Cut into pieces.	4
• Broccoli	500 gr	"	9 - 10	Separate into individual "florets".	4
• Brussels sprouts	500 gr	"	9 - 10	Leave whole.	4
• White cabbage	500 gr	"	9 - 10	Cut into strips.	4
• Red cabbage	500 gr	"	9 - 10	Cut into strips.	4
• Carrots	500 gr	"	11 - 12	Cut into same-size pieces.	4
• Cauliflower	500 gr	"	13 - 14	Separate into stalks.	4
• Celery	500 gr	"	9 - 10	Separate into pieces.	4
• Eggplant	500 gr	"	8 - 9	Cut into cubes.	4
• Leek	500 gr	"	8 - 9	Cut into strips.	4
• Mushrooms	500 gr	"	8 - 9	Leave whole. No water is needed.	4
• Onions	250 gr	"	7 - 8	Whole, but of the same size. No water is needed.	4
• Spinach	300 gr	"	8 - 9	Cover after having washed and drained the leaves.	4
• Peas	500 gr	"	12 - 13		4
• Fennel	500 gr	"	14 - 15	Cut into quarters.	4
• Peppers	500 gr	"	11 - 12	Cut into pieces.	4
• Potatoes	500 gr	"	10 - 11	Cut into same-size pieces.	4
• Zucchini	500 gr	"	9 - 10	Cut into slices.	4
MEATS					
• Stew	1,5 kg	"	42 - 47	Cook covered and stir 2 or 3 times.	10
• Chicken breasts	500 gr		20 - 22	Turn over at the halfway point	3
• Meat loaf	900 gr	"	22 - 24	(*)	5

(*) These indications are suitable for carrying out the minced meat cooking test in accordance with IEC regulation 705, test C. Cover the container with a transparent film for microwave oven, perforated in several places. Further instructions, also with regard to other performance tests in accordance with IEC regulation 705, are shown in the table on page 2.



SOUPS AND RICE

- Soups or broth usually require a smaller amount of liquid because the evaporation in microwave ovens is rather limited. Because it is a dehydrating agent, salt must be added only when the cooking is finished or during the standing time.
- It is correct to say that the temperature required for cooking rice in a microwave oven (as is true also for pasta) is more or less the same as that needed to cook this foodstuff over a burner on a regular stove. The advantage of preparing a risotto dish in a microwave oven lies in the fact that you do not have to stir the rice constantly (two or three times is enough).
The ingredients are placed in a container suitable for microwave ovens and covered with plastic wrap (for about 300 gr. of rice, you need 750 gr. of broth with the oven programmed at top power for about 12 to 15 minutes). In addition, the rice will not stick to the bottom of its container and, since it can be cooked in a tureen or some other such receptacle to be brought to the table, you will not have to transfer that rice to a serving plate.

FRUIT AND BAKED GOODS

Baked goods rise (at lower oven power) much more than then do with regular baking. Since no crust is formed, it is better to garnish the surface portions with cream or icing (e.g., chocolate); in addition, you must keep the item being baked fully covered, because such foodstuffs tend to dry out more quickly than those baked in a regular oven. Fruit is to be pierced if cooked with its peel on and is to be kept covered: it is essential that you adhere to the standing time (3 to 5 minutes).

Cooking times for baked goods and fruit

Type/quantity	Upper knob	Lower knob (minutes)	Standing time (minutes)	Observations and advice
Nut cake (700 gr)		18 - 23	5	May be used in combination with any cream whatsoever
Viennese torte (850 gr)	"	22 - 27	5	To be filled with jam or jelly.
Pineapple cake (800 gr)	"	20 - 25	5	The pineapple slices can be laid on the bottom of the pin plate or cut into pieces and mixed into the dough.
Apple cake (1000 gr)	"	22 - 27	5	The apples are spread on top as a decorative effect.
Coffee cake (750 gr)		18 - 23	5	Excellent when filled with cream.
Zabaione		4 - 6	3	Mix with a whisk every 30 seconds
Cooked pears (300 gr)		6 - 8	3	The pears are to be cut into quarters.
Cooked apples (300 gr)	"	7 - 10	3	The apples are to be cut into pieces.
Egg custard (750 gr)	"	14 - 16	5	These indications are suitable for carrying out the cooking test in accordance with IEC regulation 705, par. 17.3, test A and test B respectively. Further instructions, also with regard to other performance tests in accordance with IEC regulation 705, are shown in the table on page 2
Sponge cake (475 gr)	"	7 - 9	5	



GRILL - ONLY FUNCTION

This function is suitable for:

- All types of traditional grilling (e.g., chops, hamburgers, frankfurters, toast, etc.)pag. 35


TURNING THE OVEN ON WITH THE GRILL-ONLY FUNCTION

1

Preheat the grill as follows:


Turn the upper knob (microwave power / grill function) to the ▼▼▼ position.

POWER LEVEL/GRILL




2

Set the preheating time (5 to 8 minutes) by turning the lower knob (time) in a clockwise direction. **The oven door must be closed.**




3

After about 5 to 8 minutes put the foodstuff **on the wire rack** and then place the wire rack on the turntable; the turntable will collect the fat that drips during the cooking. Set the cooking time desired by turning the lower knob (timer). The foodstuff being grilled should be turned over when halfway cooked.



4

Once the set cooking time has expired, a **buzzer** will sound to signal that your food is ready.





USING THE OVEN-GRILL-ONLY FUNCTION FOR GRILLING

By using this function, you can make all kinds of delicious grilled dishes.


Always pre-heat the grill for 5 to 8 minutes before starting the cooking process.

All dishes being prepared must be turned over at the halfway point, to achieve even browning.

When you open the door to check the grilling process, the heating element continues to operate: always be careful to wear padded gloves made for oven use. You must always close the door again after checking the food.

Cooking times

Type	Quantity	Upper knob	Lower knob (minutes)	Notes
• Veal or pork chops	3	▼▼▼	20 - 24	Turn over after 10 minutes.
• Sausages	3	"	14 - 16	Must always be pierced. If particularly fatty, the sausages should be cut in half. Turn over after 9 minutes.
• Hamburger	3	"	14 - 16	Turn over after 8 minutes.
• Peppers	1	"	12 - 14	Cut in quarters. Turn over after 8 minutes
• Aubergine (eggplant)	4 fette	"	12 - 14	Slices one cm. thick. Turn over after 8 minutes.
• Zucchini	6 strisce	"	12 - 14	Slices one cm. thick. Turn over after 8 minutes.
• Toasted bread	4 fette	"	4	Trim the crusts carefully. Turn over after 2 minutes.



MICROWAVE-AND-GRILL SEQUENCE

This function is suitable for:


- Cooking lasagne or pasta oven dishes vegetables au gratin
- Cooking all types of roasts, poultry, skewered meats, etc.

pag. 37

OPERATING THE OVEN IN ITS MICROWAVE-AND-GRILL SEQUENCE

1


Put the foodstuff in a container made specially for microwave cooking and place it in the centre of the turntable.



2


Select the power you want by turning the upper knob (microwave power/grill function).

N.B.: If the knob is turned to the ▼▼▼ position, the microwave function will not be activated (only the grill function will operate).




3

Turn the lower knob (timer) to programme the length of the first part of the in-sequence cooking or (in other words) the microwave cooking.




4

Once the set time has expired, a beep will indicate that the microwave-cooking stage has finished: Check the foodstuff and, if necessary, mix or stir it.




5

Then turn the upper knob (microwave power/grill function) to the ▼▼▼ position.




6

Set the lower knob (timer) on the time pre-set to begin the second (coating) stage.



7

Once the set time has expired, a **beep** will indicate that the coating stage has been completed.





USING THE MICROWAVE-AND-GRILL SEQUENCE FUNCTION FOR COOKING

This setting is ideal for microwave cooking as well as for browning foodstuffs and giving them an au gratin coating. You must, however, keep the following in mind:

- the oven is never to be pre-heated;
- Do not spunkle with seasonings (just use 1/2 glass of water to keep the meat soft);
- turn roasts and large pieces of meat both halfway through the first stage (microwave cooking) and halfway through the second (browning or au gratin operations with the grill);
- to check on how the foodstuff is cooked, open the oven door. This will interrupt the microwave operations during the first cooking stage and the grill operations during the second stage: in this case, however, it is advisable to use oven gloves inasmuch as the heating element is very hot. To resume the cooking, simply close the oven door.

Cooking times

Type	Quantity	First phase: microwave cooking		Second phase: browning with grill		Notes	Standing time (minutes)
		Upper knob	Lower knob (minutes)	Upper knob	Lower knob (minutes)		
• Gnocchi alla romana	600 gr		10	▼▼▼	18	Avoid excessive melting.	5
• Lasagne	1100 gr	"	25	"	8	Times listed are for uncooked pasta.	5
• Well-seasoned macaroni	1500 gr	"	12	"	10	The pasta should first be partly boiled.	5
• Cauliflower in bechamel sauce	1000 gr	"	20	"	12	Times listed are for raw cauliflower.	5
• Tomatoes au gratin	800 gr		22	"	10	The tomatoes should all be of the same size.	5
• Stuffed peppers	1400 gr		20	"	10	Short wide peppers are best	5
• Aubergine alla parmigiana	1300 gr	"	16	"	12	The aubergine may first be fried or grilled.	5
• Potatoes au gratin	1100 gr	"	30	"	12	Times listed are for uncooked potatoes. (*)	
• Roasts (pork, beef)	1000 gr		37	"	20	Leave a little fat around the meat to keep it moist	10
• Meat loaf <small>These instructions do not refer to test C of IEC regulation 705 which is represented in the table on page 2 and 32</small>	800 gr	"	20	"	15	Turn at the halfway point	10
• Whole chicken	1200 gr	"	40	"	30	Puncture the skin with a fork (**)	10
• Skewered meat	600 gr	"	20	"	15	Turn at the halfway point	10
• Lamb	1000 gr	"	37	"	20	Turn at the halfway point	10
• Turkey (pieces)	1000 gr	"	40	"	20	Turn at the halfway point	10
• Duck	1000 gr	"	37	"	20	Turn at the halfway point.	10

(*) Times listed are for uncooked potatoes. These indications are suitable for carrying out the cooking test in accordance with IEC regulation 705, par. 17.3 Test D. Further indications, also regarding other performance tests in accordance with IEC regulation 705, are shown in the table on page 2

(**) Puncture the skin with a fork. Turn at the halfway point. These indications are suitable for carrying out the cooking test in accordance with IEC regulation 705, par. 17.3 Test F. Further indications, also regarding other performance tests in accordance with IEC regulation 705, are shown in the table on page 2

C L E A N I N G A N D M A I N T E N A N C E

Before beginning any cleaning or maintenance, always pull this oven's plug from the electrical outlet and wait for the oven itself to cool down completely


Cleaning

Thanks to the special enamel coating on your oven's inner compartment, enamel which does not retain the fatty splashes and food particles which normally build up inside an oven, it is extremely easy to clean this appliance. Always keep the microwave outlet cover (C) free of fat or splashed grease.


Never use abrasive detergents, steel wool or sharp metal utensils when cleaning the outside of the oven. In addition, be careful **not to let water or liquid detergent seep into the air outlet and steam slots located atop the appliance.**

We likewise recommend that you do not use alcohol, abrasive detergents or ammonia-based detergents to clean the inside and outside door surfaces.

To ensure perfect closing, always keep the inside of the door clean, and do not let dirt and food residue get caught between the door and the oven's façade.



Clean the air inlet holes located on the back of the oven regularly so that no dust or dirt will build up over time to obstruct those holes.



From time to time, it will be necessary to remove the turntable (H) and its support (I) and clean them, just as it will be necessary to clean the bottom of the oven.

Wash the turntable and its support in warm soapy water with neutral soap. These parts may also be cleaned in a dishwasher.

Do not place the turntable in cold water after the oven has been hot for a long time. The strong thermal shock could cause the turntable to break.

The turntable's motor is sealed tight. When you are cleaning the bottom of the oven, however, be careful not to let water seep under the turntable spindle (D).

If something seems not to be working just right

If you should discover a flaw or defect, contact a Service Centre authorised by the manufacturer. In any case, before calling our technicians, you should carry out the following simple checks:

p r o b l e m	c a u s e / r e m e d y
<ul style="list-style-type: none"> The oven is not working 	<ul style="list-style-type: none"> The door is not properly closed. The plug is not properly inserted in the electric outlet. The outlet is not supplying power (check the building's fuse box). The knobs are not set correctly.
<ul style="list-style-type: none"> Condensation on the cooking rack and inside the oven. 	<ul style="list-style-type: none"> When foods containing water are being cooked, it is completely normal for the steam generated within the oven to escape and to condense either inside the oven or on the cooking rack.
<ul style="list-style-type: none"> Sparks inside the oven. 	<ul style="list-style-type: none"> When using the microwave-only and combined functions, do not turn the oven on unless there is already food inside it. When cooking by microwaves, do not use metal containers, bags, or packages with metal clips.
<ul style="list-style-type: none"> The food is not heating sufficiently 	<ul style="list-style-type: none"> Select the correct power level or increase the cooking time. The food was not completely defrosted before being cooked. Use the correct cooking method or lower the cooking time.
<ul style="list-style-type: none"> The food is burning 	<ul style="list-style-type: none"> Stir the food while it is being cooked. Remember that foodstuffs cook better when cut into uniform pieces.
<ul style="list-style-type: none"> The food is not cooking evenly 	<ul style="list-style-type: none"> The turntable is not spinning.

In case oven-light is burned, you may continue to use the oven anyway. To replace the light, contact authorised Assistance.

ELECTRICAL CONNECTION (U.K. ONLY)

A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below.

WARNING: Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard.

With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse.

WARNING - THIS APPLIANCE MUST BE EARTHED **IMPORTANT**

The wires in the mains lead are coloured in accordance with the following code:

Green and yellow:
Blue:
Brown:


Earth
Neutral
Live



If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.

B) If your appliance is not fitted with a plug, please follow the instructions provided below:

As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The green and yellow wire must be connected to the terminal in the plug marked with the letter E or the earth symbol  or coloured green or green and yellow.

The blue wire must be connected to the terminal marked with the letter N or coloured black.

The brown wire must be connected to the terminal marked with the letter L or coloured red.

