

IMPORTANT WARNINGS

- **To avoid errors and obtain the best possible results, read the warnings carefully before using the steak grill.**
- This appliance is designed to cook food. It must never be used for other purposes, modified or tampered with in any way.
- Make sure the power cable is not in contact with hot parts of the appliance when in operation.
- Before use, wash the two non-stick grill plates thoroughly.
- Ensure the grill plates are completely dry before replacing.
- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- Unplug from the mains socket:
 - before putting away or removing the plates.
 - before cleaning or maintenance
 - immediately after use
- Use extensions conforming to current safety regulations only.
- Do not use the appliance outdoors. The power cable of this appliance must not be replaced by the user as this requires the use of special tools. If it is damaged, contact a Customer Service Centre appointed by the manufacturer.
- Never unplug the appliance by pulling the power cable.
- Never use the appliance without the grill plates.
- Never use the appliance without the drip tray L.
- Never immerse the appliance in water.
- Wait until the appliance is completely cool before putting away.
- Never touch the plates with sharp utensils to avoid damaging the coating.
- Important: when in operation, external surfaces could become very hot.

This appliance complies with directive EN 55014 on radio interference suppression. Materials and accessories coming into contact with food conform to EC regulation 1935/2004.

IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH EC DIRECTIVE 2002/96/EC.



At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service. Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.

DESCRIPTION

- | | |
|--|---|
| A Cool touch handgrip | G Grill plate removal catches |
| B Indicator light | H Base |
| C Adjustable thermostat | I Removable non-stick bottom grill plate |
| D Display | L Drip tray |
| E Grill closure catch | |
| F Removable non-stick top grill plate | |

INSTALLATION

- Before use, make sure the appliance has not been damaged during transport.
- Install the appliance on a horizontal surface out of reach of children as certain parts of the grill become extremely hot during use.
- Before plugging into the mains, make sure that:
 - the mains voltage corresponds to the value V indicated on the rating plate on the bottom of the appliance;
 - the mains socket has a minimum rating of 10A;
 - the plug is suitable for the socket. If this is not the case, have the plug replaced.
 - **the plug is efficiently earthed.** The manufacturer declines all liability for damage deriving from failure to observe this safety rule.
- To eliminate the "new" smell when using the appliance for the first time, operate it open in the barbecue position (see page 3, position 3) without food for at least five minutes. During this operation, ventilate the room.

WORKING POSITIONS

Your appliance is designed for use in one of three positions:

C O N T A C T

Ideal for meat, vegetables, polenta and sandwiches (**position one**, page 3).

T O B R O W N

Ideal for fish and pizza (**position 2**, page 3). To use the grill in this position, **lift** the top section of the appliance upwards with one hand and **rotate** towards you, while holding the appliance still by gripping the drip tray handle with the other hand.

GRILL - BARBECUE

Use this position for all types of cooking with the exception of pizza (**position 3**, page 3). To obtain this position open the steak grill completely.

USE

- Plug into the mains socket and adjust the thermostat (C) to the required position (MIN/MED/MAX). The indicator light (B) comes on. Pre-heat the appliance with the grill plates closed.
- When the appliance has reached the required temperature, the indicator light goes out.
- Place the food to be grilled on the grill plates.
- Place the appliance in one of the three available positions: 1, 2 or 3.
- To turn the appliance off, rotate the thermostat knob anticlockwise as far as it will go.
- After cooking, unplug the appliance and leave to cool.

Never touch the plates with sharp utensils to avoid damaging the coating.

COOKING TIPS

- Dry defrosted or marinated food before placing on the grill plates.
- Add herbs and spices to the meat before cooking, salt on serving.
- When using the "contact" position, the pieces to be grilled should be of the same thickness to ensure more even cooking.
- When cooking fish, the plate the fish rests on (I) must always be oiled.
- Some examples of how to use your steak grill are given below.

The times given in the following table are indicative only. They may vary according to the characteristics of the food (initial temperature, water content) and individual tastes.

CLEANING

- Before cleaning the appliance, always unplug from the mains socket and allow to cool.
- Cleaning the grill every time you use it avoids smoke and unpleasant smell the next time you cook.
- Using the catches (G), the grill plates can be removed and washed in hot water or a dishwasher.
- Leave the grill plates to soak in hot water for a few minutes to soften any solid residues left after cooking.
- Never use utensils or abrasive cleaning products as these could damage or scratch the special non-stick coating.
- Replace the grill plates in the appliance only when clean and perfectly dry, making sure they are firmly fixed in place.
- To empty or clean the drip tray, remove by pulling the handle outwards. To replace, perform this operation in reverse, pushing it in as far as it will go.

FOOD (quantity)	THERMO-STAT POSITION	GRILL POSITION	TIME	NOTES AND TIPS
Chops (1)	max	1	6'-8'	The chops must be of an even thickness
Hamburgers (2)	max	1	3'-5'	Cook with the plate closed for the first 2 to 3 minutes to avoid the burgers breaking up
Beef steak (1)	med	1	2'-3'	Cooking time for rare steak
Spare ribs (3)	max	1	15'-18'	Turn the spare ribs over after 10 minutes
Chicken (1kg)	med	1	75'-80'	Open out in half. Do not turn
fillet fish(1)	med	2	16'-20'	Oil the plate and turn halfway through cooking
Vegetables	med	1	6'-8'	Cut into even pieces
Polenta (slices)	med	1	20'-25'	Cut to a thickness of 1.5 cm. Cook with plate closed for the first 15 mins
Filled rolls	med	1	3'-9'	Use soft rolls
Toast	med	1	2'-3'	Use half a cheese slice only for each sandwich
Pizza	med	2	40'-45'	Remove the bottom grill plate and cover with the pizza dough. Reposition the plate and add your preferred topping.