

KENWOOD

English


2 - 7

عربي


١٣ - ٨

TYPE: TFP09
TYPE: TFP30

instructions



TFP09



TFP30


Kenwood Ltd

New Lane
Havant
Hampshire
PO9 2NH

kenwoodworld.com




English



Safety

- Read these instructions carefully and retain for future reference.
- Remove all packaging and any labels.
- If the plug or cord is damaged it must, for safety reasons, be replaced by Kenwood or an authorised Kenwood repairer in order to avoid a hazard.
- Burnt food can catch fire, so:
 - never leave your toaster on unattended;
 - the bread may burn, therefore do not use the toaster near or below combustible material, such as curtains;
 - set the browning control lower for thin or dry bread;
 - never warm food with a topping or filling (e.g. pizza): if it drips into the toaster, it could catch fire.
 - Clean the crumb tray regularly: crumbs can smoke or burn.
- To avoid electric shocks, **never**:
 - let the toaster, cord or plug get wet; or
 - put **your hand** or anything metal, e.g. a knife or foil, into the toaster.
- Always unplug the toaster when not in use, before cleaning or attempting to clear jammed bread.
- Never cover your toaster with a plate or anything else - it could overheat and catch fire.
- Never let the cord hang down where a child could grab it.



- We recommend that you do not use your toaster directly under wall cupboards.
- Do not move the toaster whilst it is in operation.
- External metal surfaces are liable to get hot especially the top area.
- **Never touch hot surfaces especially the metal top area.**
- Never use an unauthorised attachment or accessory.
- We do not recommend using the toaster for non bread items. For non bread items that are specifically recommended for use in a toaster follow the manufacturer's guidelines and cooking instructions. Remove loose crumbs and clean the crumb tray before and after use.
- Never use a damaged toaster. Get it checked or repaired: see 'Service and Customer Care'.
- This appliance is not intended to be operated by means of an external timer or separate remote-control system.
- Misuse of your appliance can result in injury.
- This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved. Cleaning and user maintenance shall not be made by children unless they are older than 8 years and are supervised. Keep the appliance and its

cord out of reach of children aged less than 8 years.

- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Wipe the outside of the toaster with a damp cloth, then dry. Do not use abrasives.
- Only use the appliance for its intended domestic use. Kenwood will not accept any liability if the appliance is subject to improper use, or failure to comply with these instructions.

Before plugging in

- Make sure your electricity supply is the same as the one shown on the underside of your appliance.

Important - Plug and Fuse Information

- The wires in the cord are coloured as follows:
Green and Yellow = Earth
Blue = Neutral
Brown = Live.
- If the plug supplied with your appliance has a fuse fitted and the fuse fails it must be replaced with one of the same rating.
- If the plug or cord requires replacing a new cord set should be fitted by an Authorised Kenwood Repairer.
- **WARNING: THIS APPLIANCE MUST BE EARTHED.**

Note:

- For non-rewireable plugs the fuse cover **MUST** be refitted when replacing the fuse. If the fuse cover is lost then the plug must not be used until a replacement can be obtained. The correct fuse cover is identified by colour and a replacement may be obtained from your Kenwood Authorised Repairer (see Service).
- If a non-rewireable plug is cut off it must be **DESTROYED IMMEDIATELY**. An electric shock hazard may arise if an unwanted non-rewireable plug is inadvertently inserted into a socket outlet.
- This appliance conforms to EC Regulation 1935/2004 on materials and articles intended to come into contact with food.

Before using for the first time

- **(A)** - Clip excess cord into the cord storage clips in the base **(6)**.
- Operate the toaster three times on a max setting without bread. (The lever will not stay down unless the toaster is plugged in).
- As with all new heating elements, your toaster may emit a slight burning smell when it is first switched on. This is normal and not a cause for concern.







Key

- ① Carriage levers (with 'Hi-Rise™' for extra lift)
- ② Browning control
- ③ Cancel button with indicator light
- ④ Defrost button with indicator light
- ⑤ Crumb trays
- ⑥ Cord storage

To Use Your Toaster

- 1 Plug the toaster into the power supply.
- 2 Turn the browning control until the line up mark aligns with the desired setting. Use a lower setting for light toasting and for thin or dry bread.
- 3 Insert the bread, muffins, bagels etc. **Do not place or leave bread on top of the toaster as this part is not intended for cooking purposes.**
- 4 Lower the lever **(1)** until it locks. (The lever will not stay down unless the toaster is plugged in). The 'cancel' **(3)** button will illuminate.
- 5 **Your toast will pop up automatically**, to raise it higher, lift the lever.

Toaster Functions


Symbol	Button and Control Function	
	Cancel Button (3)	<ul style="list-style-type: none">• Press the  to stop toasting during the cycle, the toast will pop up and the  button light will go off. Note: Pressing the cancel button will stop the toasting process in all four slots.
	Defrost Button (4)	<ul style="list-style-type: none">• To toast frozen bread – select the desired setting.• Then lower the bread.• Press the  button and the button will illuminate.• Set the browning control to setting 1 if you want to defrost the bread without browning. Note: Pressing the defrost button will affect all four slots even if the two levers have been lowered at different times.
	Reheat Function	<ul style="list-style-type: none">• To warm toast that has popped up but gone cold, select the re-heat position on the browning control.

Hints on Using Your Toaster

- Select a lower setting for light browning or for dry bread.
- When toasting a single slice of bread, you may notice a variation in toast colour from one side to the other - this is normal.
- Dry/stale bread toasts more quickly than fresh bread and thinly sliced bread toasts more quickly than thickly sliced bread. Therefore the browning control should be set at a lower setting than usual.
- For best results ensure that the bread slices are of an even thickness, freshness and size.

- In order to achieve uniform browning we recommend you wait a minimum of 30 seconds between each toasting so that the control can automatically reset. Alternatively select a lower setting when additional toasting is carried out.
- For best results larger slices of bread are best positioned long ways in the slot.



Care and Cleaning

- 1 Before cleaning, unplug your toaster and let it cool down.
- 2 **(B)** - Slide out the crumb tray . Clean, then replace. Do this regularly: crumbs can smoke or even burn. **Do not dishwash the crumb tray.**
- 3 Wipe the outside of the toaster with a damp cloth, then dry. Do not use abrasives.

Service and Customer Care

If you experience any problems with the operation of your appliance, before calling for assistance refer to the troubleshooting guide or visit www.kenwoodworld.com.

If you need help with:

- using your toaster or
 - servicing or repairs (in or out of guarantee)
-  call Kenwood customer care on **0345 222 0458. Have your model number ready (e.g. TYPE: TFP09 or TYPE: TFP30) and date code (5 digit code e.g. 22T01) ready.** They are on the underside of your toaster.
- **spares and attachments**
-  call 0844 557 3653.

Other countries

- If you experience any problems with the operation of your appliance, before requesting assistance refer to the 'Troubleshooting Guide' section in the manual or visit www.kenwoodworld.com.
- Please note that your product is covered by a warranty, which complies with all legal provisions concerning any existing warranty and consumer rights in the country where the product was purchased.
- If your Kenwood product malfunctions or you find any defects, please send it or bring it to an authorised KENWOOD Service Centre. To find up to date details of your nearest authorised KENWOOD Service centre visit www.kenwoodworld.com or the website specific to your Country.
- Made in China.



IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH THE EUROPEAN DIRECTIVE ON WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT (WEEE)

At the end of its working life, the product must not be disposed of as urban waste.

It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Guarantee (UK only)

If your toaster goes wrong within one year from the date you bought it, we will repair or replace it free of charge provided:

- you have not misused, neglected or damaged it;
- it has not been modified (unless by Kenwood);
- it is not second-hand;

- it has not been used commercially;
- you have not fitted a plug incorrectly; and
- **you supply your receipt to show when you bought it.**

This guarantee does not affect your statutory rights.

Troubleshooting Guide

Problem	Cause	Solution
Toaster does not operate.	No power.	Check toaster is plugged in. Check the fuse/circuit breaker in your home.
Carriage lever not staying down	Toaster not plugged in.	The lever will not stay down unless the toaster is plugged in.
Uneven Browning.	1 Slice of bread being toasted. Bread slices of different size, freshness or thickness being toasted at same time.	For best results ensure that the bread slices are of an even thickness, freshness and size. In order to achieve uniform browning we recommend you wait a minimum of 30 seconds between each toasting so that the control can automatically reset. Alternatively select a lower setting when additional toasting is carried out.
Toast colour too light or too dark.	Wrong browning setting used.	Select a higher or lower browning setting. Refer to 'Hint' section.
Burning smell or smoke from slots.	Crumb tray full. Food particles stuck to element or loose in toasting slots.	Unplug before checking the slots. Remove any loose food particles. Remove and clean the crumb tray.

If none of the above see 'Service and Customer Care'.

المشكلة	السبب المحتمل	الحل
محمصة الخبز لا تعمل.	لا توجد طاقة.	تأكد من توصيل محمصة الخبز بمصدر التيار الكهربائي. تأكد من سلامة المنصهرات/قاطع الدائرة الكهربائية في منزلك.
ذراع الحمل لا يبقى في الوضع المنخفض	محمصة الخبز غير موصلة بمصدر التيار الكهربائي.	لن يبقى ذراع الحمل في هذا الوضع المنخفض ما لم يتم توصيل محمصة الخبز بمصدر التيار الكهربائي.
تحميص غير متساو.	شريحة خبز واحدة فقط يتم تحميصها. شرائح الخبز التي يتم تحميصها في نفس الوقت من أحجام مختلفة، كما أنها ليست طازجة ومن نفس السمك بشكل متساوي.	للحصول على أفضل النتائج، تأكد من تساوي شرائح الخبز المراد تحميصها في نفس درجة السمك والحجم والنوع سواء كان الخبز طازجاً أو قديماً. للحصول على درجة تحميص متساوية، نوصي بالانتظار فترة زمنية 30 ثانية على الأقل بين كل مرة تحميص بحيث يتم إعادة تعيين تحكم درجة التحميص تلقائياً. أو بطريقة أخرى، اختاري إعداد درجة تحميص منخفض في حالة قيامك بتحميص مزيد من الخبز.
درجة التحميص غامقة جداً أو فاتحة جداً.	استخدام إعداد تحميص غير صحيح.	اختاري إعداد تحميص منخفض أو مرتفع. راجعي قسم "التلميحات".
رائحة احتراق أو تصاعد أدخنة من الفتحات.	صينية الكسرات ممتلئة. مكونات الغذاء ملتصقة بعنصر التسخين أو متبقية في فتحات التحميص.	افصلي الجهاز عن مصدر التيار الكهربائي قبل فحص الفتحات. أزيل أي مكونات ملتصقة. أزيل صينية الكسرات ونظفها.
في حالة عدم حل المشكلة من خلال التلميحات السابقة، راجعي قسم «الصيانة وخدمة العملاء».		

تلميحات متعلقة باستخدام محمصة الخبز

- حددى الإعداد المنخفض للتحميص الخفيف أو مع الخبز الجاف.
- عند تحميص شريحة واحدة من الخبز، قد تلاحظين تفاوتاً في درجة لون تحميص الخبز على كلا جانبي الخبز - هذا أمر طبيعي.
- الخبز الجاف/اليابس يحمص بصورة أسرع من الخبز الطازج كما تحمص شرائح الخبز الرقيقة بصورة أسرع من شرائح الخبز السمكة. ولهذا السبب يجب وضع مفتاح التحكم في درجة التحميص على درجة أقل انخفاضاً من الموضع المعتاد.
- للحصول على أفضل النتائج، تأكدي من تساوي شرائح الخبز المراد تحميصها في نفس درجة السمك والحجم والنوع سواء كان الخبز طازجاً أو قديماً.
- للحصول على درجة تحميص متساوية، نوصي بالانتظار فترة زمنية ٣٠ ثانية على الأقل بين كل مرة تحميص بحيث يتم للحصول على أفضل النتائج ضعى شرائح الخبز الطويلة طويلاً في فتحة إدخال الخبز.

إعادة تعيين تحكم درجة التحميص تلقائياً.
أو بطريقة أخرى، اختاري إعداد درجة تحميص منخفض في حالة قيامك بتحميص مزيد من الخبز.

العناية والتنظيف

- ١ قبل التنظيف، افصلي محمصة الخبز عند مصدر التيار الكهربى واتركيها لكي تبرد.
- ٢ (B) اسحبي صينية تجميع الكسرات للخارج ⑤.
- نظفيها ثم أعيدوها إلى موضعها مرة أخرى. نفذي هذه العملية بشكل منتظم.
- قد يصدر دخاناً عن الكسرات وقد تحترق أيضاً.
- لا تغسلي صينية الكسرات في غسالة الأطباق.
- ٣ امسحي السطح الخارجى لمحمصة الخبز بقطعة قماش رطبة ثم جففيها. لا تستخدمى مواد كاشطة.

• صنع في الصين.



**معلومات هامة هو الكيفية الصحيحة
للتخلص من المنتج وفقاً لتوجيهات
الاتحاد الأوروبي المتعلقة بنفايات
المعدات الكهربائية والإلكترونية
(WEEE)**

في نهاية العمر التشغيلي للجهاز، يجب عدم التخلص من الجهاز في نفايات المناطق الحضرية.
بل يجب أخذه إلى مركز تجميع خاص بجهة محلية متخصصة في التخلص من هذه النفايات أو إلى تاجر يقدم هذه الخدمة.

الصيانة ورعاية العملاء

- في حالة مواجهة أية مشكلة متعلقة بتشغيل الجهاز، قبل الاتصال بطلب المساعدة، يرجى مراجعة قسم «دليل اكتشاف المشكلات وحلها» في الدليل أو زيارة موقع الويب www.kenwoodworld.com.
- يرجى الملاحظة بأن جهازك مشمول بضمان، هذا الضمان يتوافق مع كافة الأحكام القانونية المعمول بها والمتعلقة بحقوق الضمان والمستهلك في البلد التي تم شراء المنتج منها.
- في حالة تعطل منتج Kenwood عن العمل أو في حالة وجود أي عيوب، فيرجى إرساله أو إحضاره إلى مركز خدمة معتمد من KENWOOD. للحصول على معلومات محدثة حول أقرب مركز خدمة معتمد من KENWOOD، يرجى زيارة موقع الويب www.kenwoodworld.com، أو موقع الويب المخصص لبلدك.







قبل استخدام الجهاز للمرة الأولى

- (A) - اشبكي السلك الكهربى الزائد في مشابك تخزين السلك الكهربى الموجودة في قاعدة الجهاز ⑥.
- قومي بتشغيل المحمصة ثلاث مرات على أقصى إعداد بدون خبز. (لن يظل ذراع الرفع لأسفل ما لم يتم توصيل المحمصة بالتيار الكهربائي).
- كما هو الحال مع جميع أسطح التسخين الجديدة، قد يصدر عن محمصة الخبز رائحة دخان طفيفة عند المرة الأولى لتشغيل المحمصة. هذا أمر عادي وطبيعي ولا يدعو إلى القلق.


الدليل

- ① ذراع الحمل مع خاصية «Hi-Rise™» (لمزيد من الرفع).
- ② مفتاح التحكم في درجة التخميص
- ③ زر الإلغاء، مزود بمؤشر ضوئي
- ④ زر «Defrost» (إذابة الثلج) مزود بمؤشر ضوئي
- ⑤ صينية تجميع الكسرات
- ⑥ مكان تخزين السلك

وظائف محمصة الخبز

الرمز	الزر ومفتاح الوظيفة	
	زر «Cancel» (إلغاء) ③	• اضغطي على الرمز  لإيقاف عملية التخميص خلال دورة التشغيل، عندئذ يرتفع الخبز المحمص لأعلى وينطفئ ضوء زر المؤشر الضوئي  . ملاحظة: يؤدي الضغط على زر الإلغاء إلى إيقاف تشغيل المحمصة في فتحات التخميص الأربعة.
	زر "Defrost" (إذابة الثلج) ④	• لتخميص الخبز المجمد - اختاري الإعداد المطلوب. • ثم اخفضي الخبز. • اضغطي على زر  عندئذ يضيء الزر. • ضعي مفتاح التحكم في درجة التخمير على الإعداد ١ إذا أردتي إذابة الثلج عن الخبز المجمد دون تخميصه. ملاحظة: يؤثر الضغط على زر إذابة الثلج على فتحات التخميص الأربعة حتى مع خفض ذراعي التخميص في أوقات مختلفة.
	وظيفة إعادة التسخين	• لتسخين الخبز المحمص في حالة برودته، حددي موضع إعداد إعادة التسخين في مفتاح التحكم في درجة التخميص.

استخدام محمصة الخبز

- ١ وصلي محمصة الخبز مع مصدر التيار الكهربى.
- ٢ لفى مفتاح التحكم في درجة التخميص إلى أن تتحاذى العلامة مع إعداد التخميص المطلوب. استخدمى الإعداد المنخفض للتخميص الخفيف أو مع الخبز الرقيق أو الجاف.
- ٣ أدخل الخبز أو كعك المافين أو خبز الباجلز وغيرها من أنواع المعجنات. **لا نضعي الخبز أو تتركه فوق المحمصة لأن هذا الجزء غير مخصص لأغراض الطهي.**
- ٤ أخفضي الذراع ① حتى يستقر في موضعه محدثاً لصوت طقطقة. (لن يبقى الذراع في هذا الوضع المنخفض ما لم يتم توصيل محمصة الخبز بمصدر التيار الكهربى). سيضيء زر «Cancel»  (إلغاء).
- ٥ سيخرج الخبز المحمص تلقائياً، لرفعه إلى مستوى أعلى ارفعي الذراع.

- يمكن استخدام الأجهزة من قبل أشخاص من ذوي القدرات البدنية أو الحسية أو العقلية المحدودة أو من ليست لديهم خبرة أو معرفة في حال قيام شخص بتقديم الإشراف أو التعليمات المتعلقة باستخدام الجهاز لهم بطريقة آمنة وفهموا المخاطر المتعلقة به.
- لا يجوز لعب الأطفال بالجهاز.
- امسحي السطح الخارجي لمحمصة الخبز بقطعة قماش رطبة ثم جففيها. لا تستخدم مواد كاشطة.
- استخدممي الجهاز فقط في الاستخدامات المنزلية المخصص لها. لن تتحمل شركة Kenwood أية مسؤولية في حالة استخدام الجهاز بطريقة غير صحيحة أو عدم الامتثال للتعليمات المذكورة.

قبل التوصيل بمصدر التيار الكهربائي

- تأكدي من تطابق مواصفات التيار الكهربائي لديك مع المواصفات الموضحة على الجانب السفلي للجهاز.

هام - المقبس والمنصهر الكهربائي

- اللون الأسلاك الموجودة في السلك الكهربائي هي كالتالي:

أخضر بخط أصفر = الأرضي

أزرق = متعادل

بنّي = كهرباء حية

- إذا كان القابس المزود في جهازك به مصهر مُركب وتعطل هذا المصهر، فيجب استبداله بمصهر مماثل له بنفس تقدير الأمبيرية.

- في حالة الحاجة إلى استبدال المقبس أو السلك الكهربائي، فيجب استبدالهما وتركيبهما من قبل مركز صيانة متخصص معتمد لدى Kenwood.

- تحذير: يجب توصيل هذا الجهاز بطرف أرضي.

ملاحظة:

- بالنسبة إلى المقابس غير القابلة لإعادة تركيب الأسلاك الجديدة بها،، يجب إعادة تثبيت غطاء المنصهر الكهربائي عند استبداله. في حالة فقد غطاء المنصهر الكهربائي، يجب عدم استخدام المقبس إلا أن يتم الحصول على بديل. يتم تحديد غطاء المنصهر الكهربائي الصحيح حسب اللون ويمكن الحصول على بديل من مركز صيانة متخصص معتمد لدى Kenwood (يرجى مراجعة قسم الخدمة).
- إذا تم قطع مقبس غير قابل لإعادة تركيب الأسلاك الجديدة به، فيجب تدميره على الفور. إذا تم إدخال قابس غير قابل لإعادة التمديد عن غير قصد في مخرج المقبس، فقد ينشأ خطر حدوث صدمة كهربائية.
- يتوافق هذا الجهاز مع تنظيمات الاتحاد الأوروبي 2004/1935 المتعلقة بالمواد والأجسام المتلامسة مع الأطعمة.

- يحذر تغطية محمصة الخبز بطبق أو أي جسم آخر - حيث قد ترتفع درجة حرارته مما قد يؤدي إلى إحداث حرائق.
- يحذر ترك السلك الكهربائي متدلياً في حالة وجود طفل فقد ينتزعه.
- نوصي بعدم استخدام محمصة الخبز مباشرة أسفل خزانة المطبخ المعلقة على الحائط.
- لا تحركي محمصة الخبز أثناء تشغيلها.
- لأسطح المعدنية الخارجية عرضة لارتفاع درجة حرارتها وخاصة المنطقة العلوية.
- يحذر لمس الأسطح الساخنة وخاصة المنطقة المعدنية العلوية.
- يحذر استخدام أي ملحقات وكماليات غير معتمدة.
- لا ننصح باستخدام المحمصة مع مكونات غير الخبز. بالنسبة للمكونات التي يوصى على وجه التحديد استخدام المحمصة معها، يرجى مراجعة إرشادات الشركة المصنعة وتعليمات الطهي. أزيلتي كسرات وفتات الخبز ونظفي صينية تجميع الكسرات قبل وبعد الاستخدام.
- يحذر استخدام محمصة الخبز في حالة تلفها. في مثل هذه الحالة يجب فحص الجهاز أو إصلاحه: راجعي قسم "الصيانة ورعاية العملاء".
- هذا الجهاز غير مخصص ليتم تشغيله بواسطة مؤقت زمني خارجي أو جهاز تحكم عن بعد خارجي.
- قد يؤدي سوء استخدام الجهاز إلى حدوث إصابات.
- يمكن استخدام هذا الجهاز من قبل الأطفال من عُمر ٨ أعوام فأكثر إذا تم الإشراف عليهم أو حصلوا على الإرشادات المتعلقة باستخدام الجهاز بطريقة آمنة وفهموا المخاطر المتعلقة به. لا يجوز للأطفال إجراء التنظيف والصيانة إلا إذا كان عمرهم أكبر من ٨ أعوام وكانوا خاضعين للإشراف. يرجى الاحتفاظ بالجهاز وسلوكه الخاص بعيداً عن متناول الأطفال الذين تقل أعمارهم عن ٨ أعوام.

السلامة

- أقرئي التعليمات التالية واحتفظي بها في المتناول للاستخدامات المستقبلية المرجعية.
- أزيل مكونات التغليف وأية ملصقات.
- لأسباب متعلقة بالسلامة ولتجنب حدوث أية مخاطر، في حالة تلف السلك الكهربائي أو القابس، يجب استبداله بواسطة Kenwood أو مركز خدمة معتمد من قبل Kenwood.
- قد تتسبب الأطعمة المحروقة في إحداث حرائق، لذلك:
- يحذر ترك محمصة الخبز أثناء تشغيلها دون ملاحظتها
- قد يحترق الخبز، لذلك لا تستخدم المحمصة بالقرب من المواد القابلة للاحتراق أو تحتها، مثل الستائر؛
- ضعي مفتاح التحكم في درجة التحمير على الموضع الأدنى (المنخفض) عن الاستخدام مع الخبز الرقيق أو الجاف
- يحذر تسخين أطعمة محشوة أو بإضافات خارجية (البيتزا على سبيل المثال) في حالة سقوط الحشوة أو الإضافات داخل المحمصة فقد تتسبب في إحداث حرائق.
- نظفي صينية الكسرات بصورة منتظمة: قد يصدر دخاناً عن الكسرات أو قد تحترق.
- لتجنب الإصابة بصدمات كهربائية، يحذر:
- السماح بتعرض المحمصة أو السلك الكهربائي أو القابس الكهربائي للبلل؛ أو
- إدخال يديك أو أي جسم معدني مثل السكين أو رقائق الألومنيوم داخل محمصة الخبز.
- افصلي محمصة الخبز دائماً عن مصدر التيار الكهربائي في حالة عدم استخدامها أو قبل التنظيف أو عند إزالة خبز محشور.