


KENWOOD

Important Safety



GB Important Safety

2-4

AR تعليمات أمان هامة

٦-٥

Safety

- Read these instructions carefully and retain for future reference.
- Remove all packaging and any labels.
- If the cord is damaged it must, for safety reasons, be replaced by KENWOOD or an authorised KENWOOD repairer.
- **Do not** immerse appliance, cord or plug in water or other liquid.
- **Never** use a damaged appliance. Get it checked or repaired: see 'Service and Customer Care'.
- Unplug the appliance from the mains supply after use and before cleaning.
- When using the knife sharpener the following precautions should be taken:
 - ensure that the supply cord is positioned away from the sharpener;
 - keep hands etc. and utensils well away from the cutting edge of the blade;
 - direct the blade being sharpened away from the user.
- To reduce the risk of personal injury, keep hair and loose clothing away from moving parts whilst in operation.
- **Never** try to open cans that are under pressure (e.g. aerosol cans).
- This appliance should only be used on a stable, flat surface or table.
- **Do not** let the cord hang over the edge of the work surface or touch hot surfaces.
- Children should be supervised to ensure that they do not play with the appliance.
- Misuse of your appliance can result in injury.
- This appliance shall not be used by children.
- Keep the appliance and its cord out of reach of children.
- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- Only use the appliance for its intended domestic use. Kenwood will not accept any liability if the appliance is subject to improper use, or failure to comply with these instructions.

Care and Cleaning

- Unplug the appliance from the power supply before cleaning.
- Push any excess cord into the cord storage at the back of the unit.
- Lift the lever and remove.
- Wash the lever in hot soapy water and dry thoroughly.
Dishwashing is not advised.
- Wipe over the body with a damp cloth and dry thoroughly.
- Replace the lever.

Before plugging in

- Make sure your electricity supply is the same as the one shown on the underside of the power unit.

Important - Plug and Fuse Information

- The wires in the cord are coloured as follows:
Blue = Neutral, Brown = Live.
- If the plug is cut off it must be DESTROYED IMMEDIATELY. An electric shock hazard may arise if an unwanted non-rewireable plug is inadvertently inserted into a socket outlet.
- If the plug supplied with your appliance has a fuse fitted and the fuse fails it must be replaced with one of the same rating.

Note:

- For non-rewireable Plug Type G the fuse cover MUST be refitted when replacing the fuse. If the fuse cover is lost then the plug must not be used until a replacement can be obtained. The correct fuse cover is identified by colour and a replacement may be obtained from your Kenwood Authorised Repairer (see Service).



Plug Type G

- This appliance conforms to EC Regulation 1935/2004 on materials and articles intended to come into contact with food.

Service and Customer Care

If you experience any problems with the operation of your appliance, before calling for assistance refer to the Troubleshooting guide or visit www.kenwoodworld.com.

If you need help with:

- Using your appliance or
- Servicing, spare parts or repairs (in or out of guarantee)
- ☎ Call Kenwood Customer Care on **0345 222 0458** or visit www.kenwoodworld.com. **Have your model number (e.g. TYPE: CAP80) and date code (5 digit code e.g. 23T04) ready.** They are located on the underside of the power unit.
- **Spares and attachments**
- ☎ call 0844 557 3653.
- **Other countries**
- If you experience any problems with the operation of your appliance, before requesting assistance refer to the “Troubleshooting guide” section in the manual or visit www.kenwoodworld.com.
- Please note that your product is covered by a warranty, which complies with all legal provisions concerning any existing warranty and consumer rights in the country where the product was purchased.
- If your Kenwood product malfunctions or you find any defects, please send it or bring it to an authorised KENWOOD Service Centre. To find up to date details of your nearest authorised KENWOOD Service centre visit www.kenwoodworld.com or the website specific to your Country.
- Made in China.



IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH THE EUROPEAN DIRECTIVE ON WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT (WEEE)

At the end of its working life, the product must not be disposed of as urban waste.

It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

العناية والتنظيف

- افصلي الجهاز عن مصدر التيار الكهربائي قبل التنظيف.
- ادفعي أي سلك زائد في منطقة التخزين في الجزء الخلفي من الوحدة.
- ارفعي الذراع وأزيليه.
- اغسلي الذراع في محلول صابوني ساخن ثم جففيه تماماً. لا ننصح بغسل الذراع داخل غسالة الأطباق.
- أعيدي تركيب الذراع.
- امسحي الجسم الخارجي للجهاز بقطعة قماش رطبة ثم جففيه تماماً.

قبل توصيل الجهاز بمصدر التيار الكهربائي

- تأكدي من تماثل مواصفات المصدر الكهربائي مع المواصفات الموضحة على الجانب السفلي لوحدة الطاقة .
- يتوافق هذا الجهاز مع تنظيمات الاتحاد الأوروبي 2004/1935 المتعلقة بالمواد والأجسام المتلامسة مع الأطعمة.

الصيانة ورعاية العملاء

- في حالة مواجهة أية مشكلة متعلقة بتشغيل الجهاز، قبل الاتصال لطلب المساعدة، يرجى مراجعة قسم «دليل اكتشاف المشكلات وحلها» في الدليل أو زيارة موقع الويب www.kenwoodworld.com.
- يرجى الملاحظة بأن جهازك مشمول بضمان، هذا الضمان يتوافق مع كافة الأحكام القانونية المعمول بها والمتعلقة بحقوق الضمان والمستهلك في البلد التي تم شراء المنتج منها.
- في حالة تعطل منتج Kenwood عن العمل أو في حالة وجود أي عيوب، فيرجى إرساله أو إحضاره إلى مركز خدمة معتمد من KENWOOD. للحصول على معلومات محدثة حول أقرب مركز خدمة معتمد من KENWOOD، يرجى زيارة موقع الويب www.kenwoodworld.com، أو موقع الويب المخصص لبلدك.
- صنع في الصين.



معلومات هامة هو الكيفية الصحيحة للتخلص من المنتج وفقاً لتوجيهات الاتحاد الأوروبي المتعلقة بنفايات المعدات الكهربائية والإلكترونية (WEEE)

في نهاية العمر التشغيلي للجهاز، يجب عدم التخلص من الجهاز في نفايات المناطق الحضرية. بل يجب أخذه إلى مركز تجميع خاص بجهة محلية متخصصة في التخلص من هذه النفايات أو إلى تاجر يقدم هذه الخدمة.

لسلامتك

- اقرئي التعليمات التالية واحتفظي بها في المتناول للاستخدامات المستقبلية المرجعية.
- أزيلتي مكونات التغليف وأية ملصقات.
- لأسباب متعلقة بالسلامة ولتجنب حدوث أية مخاطر، في حالة تلف السلك الكهربائي أو القابس، يجب استبداله بواسطة Kenwood أو مركز خدمة معتمد من قبل Kenwood.
- لا تغمري الجهاز أو السلك الكهربائي أو القابس في الماء أو أي سائل آخر.
- يحذر استخدام الجهاز في حالة تلفه. في مثل هذه الحالة يجب فحص الجهاز أو إصلاحه: راجعي قسم «الصيانة ورعاية العملاء».
- افصلي الجهاز عن مصدر التيار الكهربائي بعد الاستخدام وقبل التنظيف.
- عند استخدام مسن السكاكين، يجب اتباع الإجراءات الوقائية التالية:
 - تأكدي من توجيه السلك الكهربائي بعيداً عن المسن؛
 - أبعدي الأيدي وأدوات المائدة بعيداً عن حافة القطع الخاصة بنصل السكين؛
 - وجهي السكين التي يجري سنها بعيداً عن المستخدم؛
- للحد من الإصابات العرضية، أبعدي الشعر والملابس الفضفاضة عن الأجزاء المتحركة أثناء التشغيل.
- يحذر محاولة فتح أي ملعب معدني مضغوط (على سبيل المثال، مغربات الأيروسول).
- يجب استخدام هذا الجهاز فقط على الأسطح الأفقية المستوية.
- لا تسمححي بتدلي الجزء الزائد من السلك الكهربائي عن سطح العمل وأيضاً لا تسمححي بملامسته لأسطح ساخنة.
- يجب الإشراف على الأطفال للتأكد من عدم عبثهم بالجهاز.
- قد يؤدي سوء استخدام الجهاز إلى حدوث إصابات.
- لا يجوز استخدام هذا الجهاز من قبل الأطفال.
- أبعدي الجهاز والسلك الكهربائي عن متناول يد الأطفال.
- يمكن استخدام الأجهزة من قبل أشخاص ذوي قدرات جسدية أو حسية أو عقلية منخفضة وممن هم دون خبرة أو معرفة باستخدام الأجهزة في حالة منحهم التعليمات الخاصة بالاستخدام أو الإشراف عليهم بحيث يمكنهم استخدامه بطريقة آمنة مع إدراك المخاطر التي تنطوي على استخدام الجهاز.
- استخدمتي الجهاز فقط في الاستخدامات المنزلية المخصص لها.
- لن تتحمل شركة Kenwood أية مسؤولية في حالة استخدام الجهاز بطريقة غير صحيحة أو عدم الامتثال للتعليمات المذكورة.

Kenwood Ltd

New Lane
Havant
Hampshire
PO9 2NH

kenwoodworld.com

