
















首次开机设置

Setting up the machine



确保蒸汽/热水旋钮始终保持在0位置，直到完成首次开机。

Make sure the steam knob is on 0 pos. for the whole operation.



57132C8066_00_0822

