

DH 25 UL DEHUMIDIFIER

572576/05.92

Instructions for use

Description



- 1. *Panel cover*
- 2. *Control panel*
- 3. *Air outlet grille*
- 4. *Canister*
- 5. *Lifting handle*
- 6. *Air intake grille*
- 7. *Air filter*
- 8. *Canister access panel*

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- *Read all instructions.*
- *This appliance is designed to dehumidify domestic living areas, and must not be used for other purposes.*
- *The appliance must not be modified in any way, as any modifications may be extremely dangerous.*
- *If the appliance requires repair, always contact a Service Centre authorized by the manufacturer. Always insist on original spare parts. Repairs carried out by non-qualified personnel may be dangerous and render the warranty null and void.*
- *This appliance must be used by adults only. Do not allow children to play with the appliance.*
- *The appliance must be adequately grounded. Have your electrical circuit checked by a qualified electrician.*
- *Do not use extension power cables.*
- *Always remove the plug from the socket before performing cleaning or maintenance operations.*
- *Do not move the appliance by pulling the power cable.*
- *Do not install the appliance in areas containing gas, oil or sulphur. Do not install the appliance near sources of heat.*
- *After switching off the appliance, always wait at least three minutes before switching it on again.*
- *Do not place heavy or hot objects on the top of the appliance.*
- *Clean the air filter at least once weekly.*
- *The appliance must always remain upright or laid on one side during transportation. Remember to drain the canister before transporting the appliance.*

After transporting the appliance, wait at least one hour before using it.

THIS PRODUCT IS FOR HOUSEHOLD USE ONLY

SAVE THESE INSTRUCTIONS

Read this instruction booklet carefully before installing and using the appliance. In this way, you will obtain the best possible results and maximum operating safety.

Presentation

The DH 25 UL Dehumidifier removes humidity from the air in the areas in which it is installed. The appliance is compact and fitted with wheels and handles which facilitate its movement.

This appliance is recommended for all rooms in which excessive humidity is liable to build up, e.g. kitchens, bathrooms, laundry rooms, cellars etc.


Technical characteristics

<i>Power supply</i>	<i>115 V (60 Hz)</i>
<i>Absorbed power</i>	<i>420 W</i>
<i>Absorbed current</i>	<i>4,6 A</i>
<i>Maximum humidity removed per 24 hours</i>	<i>12 litres</i>
<i>Volume of air dehumidified</i>	<i>260 m³/h</i>
<i>Coolant*</i>	<i>R22</i>
<i>Defrosting device</i>	<i>yes</i>
<i>Humidostat</i>	<i>yes</i>
<i>Dimensions (W x H x D)</i>	<i>570x550x300 mm</i>
<i>Weight (net)</i>	<i>26 Kg.</i>
<i>Capacity of canister</i>	<i>6 litres</i>
<i>Operating limits:</i>	
• <i>temperature</i>	<i>8° - 32 °C</i>
• <i>relative humidity</i>	<i>30 - 95 %</i>

Standard operating conditions: 27°C - 60% RH

** R22 is a coolant which conforms to EEC environmental safety regulations.*

Accessories

	Description	Quantity
	<i>outlet pipe</i>	<i>1</i>
	<i>$\frac{3}{4}$" ring nut</i>	<i>1</i>
	<i>washer</i>	<i>1</i>
	<i>condensation discharge tube</i>	<i>1 (2 m.)</i>
	<i>rubber cap</i>	<i>1</i>
	<i>blanking seal</i>	<i>1</i>

Important

A warranty certificate is attached to the machine. If you have not done so already, have your dealer stamp the certificate, then send the right-hand section to us. Only in this way will you be covered by our warranty. It's in your interest!

Installation

Place the appliance in the room that you wish to dehumidify.

It is essential to leave a space of at least 50 cm. around the appliance in order to ensure adequate ventilation.

The condensation can be discharged in one of two ways:


A) Discharge into the canister

The condensation generated by the dehumidifier can be discharged directly into the canister which is located inside the appliance (fig. 1).

When the canister is full, a warning lamp lights and a special safety device switches off the appliance.

The canister can be easily removed for emptying.

Fig. 1



B) External discharge

The condensation can be continually drained out of the tank by fitting a drain outlet pipe and hose to the canister.

If this is desired, proceed as follows:

- 1) *Drill a hole in the area marked on the union so that the condensation water in the tank can drain out.*
- 2) *Fit the seal ring, outlet pipe and ring nut to the tank union (see fig. 2).*
- 3) *Position the canister inside the combined dehumidifier housing.*
- 4) *The housing door features a pre-marked hole for the condensation drain hose (fig. 3). Remove the centre disk and pass the hose through the hole.*

N.B. If you want to go back to collecting the condensation in the tank, remove the outlet pipe, fit the blanking seal and fix it in place using the ring nut.




Fig. 2

1. Canister
2. Seal ring
3. Ring nut
4. Outlet pipe
5. Union
6. Blanking seal
7. Drain hose




Fig. 3

Electrical connections


Before connecting the appliance to the power supply, check the following:

- *The mains power supply must correspond to the power supply shown on the rating plate.*
- *The power socket and the electrical circuit must be adequate to supply the appliance.*
- *The power socket must match the plug. If not, have the plug replaced by qualified personnel.*
- *The power socket must be adequately earthed.*

The manufacturer accepts no responsibility if these safety regulations are not complied with.

This appliance is manufactured in compliance with EEC directive 87/308 relative to the suppression of radio interference.

Description of the controls



Using the dehumidifier

- 1) *Plug the appliance into the power socket. The pilot lamp lights to show that the appliance is switched on.*
- 2) *Check that the "Canister Full/No Canister" pilot lamp is off.*
- 3) *Turn the humidity control knob to "CONTINUOUS" for continuous operation.*
- 4) *To switch off the appliance, turn the humidity control knob anti-clockwise to the "OFF" position.*

Note:

For technical reasons, the humidity is expressed in levels rather than in degrees.

We recommend starting with the humidity control knob set to "CONTINUOUS". When the humidity in the room reaches the desired level, turn the knob slowly anti-clockwise until the appliance switches off. In this way, the appliance is programmed to maintain the exact humidity level that you desire.

When the appliance is in operation, as well as dehumidifying, it also heats the room with a power of 460W.

The control panel shows a number of examples:

- • *To dehumidify an area that is not lived in, such as a cellar.*
- • • *To dehumidify the living area.*
- • • • *To dehumidify rooms where low humidity is desired, such as the laundry room.*

Maintenance

*Always remove the plug from the power socket before performing any cleaning or maintenance operations.
For safety, never use a jet of water to wash the appliance.*

Cleaning the cabinet

- *Clean the appliance using a damp cloth and dry using a dry cloth.*
- *Never use petrol, methylated spirits or solvents to clean the appliance.*
- *Never spray the appliance with insecticides or similar products. These may cause the paint to flake or the plastic parts to become mis-shapen.*

Cleaning the air filter

- *The filter should be cleaned weekly.*
- *To remove the filter, open the canister access panel, remove the canister and remove the filter by pulling downwards (fig. 4).*
- *Use a vacuum cleaner to remove the dust that builds up on the filter. If the filter is very dirty, wash it in warm water and rinse several times.
The temperature of the water should not exceed 40°C.
After washing the filter, allow it to dry completely before replacing it in the appliance.*




Fig. 4

If the appliance is not used for long periods

- *Disconnect the plug from the power socket and empty the canister.*
- *Clean and replace the filter.*
- *Protect the appliance from dust by covering with a large plastic bag.*

Troubleshooting

Before calling your local authorized Service Centre, check the following:

Problem	Cause	Solution
<i>The dehumidifier does not switch on</i>	• <i>the appliance is not plugged in</i> • <i>the humidostat is set to the minimum position</i> • <i>the canister is full</i> • <i>the canister is not in position</i>	• <i>insert the plug into the socket</i> • <i>adjust the humidostat to the desired position</i> • <i>empty the canister</i> • <i>position the canister correctly</i>
<i>The appliance does not dehumidify</i>	• <i>the filter is dirty</i> • <i>the temperature or humidity in the room is too low</i>	• <i>clean the filter</i> • <i>in certain conditions, the appliance will not dehumidify the room (see "Technical Characteristics")</i>
<i>The appliance works but the humidity in the room is not reduced</i>	• <i>the room is too big</i> • <i>too many sources of humidity in the room (e.g. boiling saucepans)</i>	

Limited Warranty

What Does This Warranty Cover? We warrant each appliance to be free from defects in material and workmanship. Our obligation under this warranty is limited to replacement or repair, free of charge at our factory or authorized service centers, of any defective part or parts thereof other than parts damaged in transit, which shall be returned to us, transportation prepaid. This warranty shall apply only if the appliance is used in accordance with the factory directions which accompany it, and on an Alternating Current (AC) circuit.

How Long Does The Coverage Last? This warranty runs for one year from the date of delivery and applies only to the original purchaser for use.

What Does This Warranty Not Cover? This warranty does not cover defects or damage of the appliance which result from repairs or alterations to the appliance outside our factory or authorized service centers, nor shall it apply to any appliance which has been subject to abuse, misuse, negligence or accidents. Also, consequential and incidental damages resulting from the use of this product or arising out of any breach of contract or breach of this warranty are not recoverable under this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

How Do You Get Service? If repairs become necessary or spare parts are needed, please write to:

De' Longhi America Inc.
625, Washington Avenue
Carlstadt N.J. 07072

or call Service Tel. No. **1-800-322-3848**

The above warranty is in lieu of all other express warranties and representations. All implied warranties are limited to the applicable warranty period set forth above. This limitation does apply if you enter into an extended warranty with De' Longhi. Some states do not allow limitations on how long an implied warranty lasts, so the above exclusions may not apply to you. De' Longhi does not authorize any other person or company to assume for it any liability in connection with the sale or use of its appliance.

How Does State Law Apply? This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

FOR U.S. ONLY:

IMPORTANT!

PLEASE COMPLETE THIS CARD AND RETURN WITHIN THE NEXT 10 DAYS TO ESTABLISH PROPER REGISTRATION OF YOUR NEW DE' LONGHI PRODUCT

☐ Mr. ☐ Mrs. ☐ Miss _____

Street _____

City _____ State _____ ZIP _____

Ph. _____ Marital status: ☐ Single ☐ Married ☐ Divorced

Date of Purchase: _____ Month _____ Day _____ Year _____

DE' LONGHI Model: _____ Purchased from: _____

This product was ☐ a planned purchase ☐ gift ☐ impulse purchase

The product was selected by ☐ Male ☐ Female ☐ Both

Selection of this product was prompted by:

☐ Advertising ☐ Appearance ☐ In store display
☐ Brand Name ☐ Features ☐ Previous ownership
☐ Price ☐ Referral ☐ Packaging

Age group ☐ 16-24 ☐ 25-34 ☐ 35-44 ☐ 45 and over

Type of residence ☐ house ☐ apartment ☐ other

Room where the product will be used _____

572576/05.92

PLACE
STAMP
HERE

DE' LONGHI AMERICA, INC.
625 WASHINGTON AVENUE
CARLSTADT, N.J. 07072


ATTN. CONSUMER RELATIONS MANAGER

DH 25 UL

DESHUMIDIFICATEUR

Mode d'emploi

Description



- 1. *Couvercle du panneau de commande*
- 2. *Panneau de commande*
- 3. *Grille de refoulement*
- 4. *Réservoir*
- 5. *Poignée*
- 6. *Grille d'aspiration*
- 7. *Filtre à air*
- 8. *Porte d'accès au réservoir*

PRECAUTIONS IMPORTANTES

L'utilisation de n'importe quel appareil électrique implique l'observation de certaines règles fondamentales:

- *Lisez toutes les instructions.*
- *Cet appareil a été construit pour déshumidifier les pièces à usage d'habitation. Aussi, il ne doit pas être utilisé à d'autres fins.*
- *Il est dangereux de modifier ou d'altérer de quelque façon que ce soit les caractéristiques de l'appareil.*
- *Pour d'éventuelles réparations, s'adresser toujours et exclusivement aux centres de service après-vente autorisés par le constructeur. Exiger toujours l'utilisation de pièces de rechange d'origine. Les réparations effectuées par des personnes non qualifiées peuvent être dangereuses et ne permettent pas de bénéficier de la garantie.*
- *Cet appareil doit être exclusivement utilisé par des adultes. Ne pas permettre que les enfants jouent avec l'appareil.*
- *L'appareil doit être raccordé à une installation de terre efficace. Faire contrôler l'installation électrique par un électricien qualifié.*
- *Eviter d'utiliser des rallonges pour le câble d'alimentation électrique.*
- *Avant d'entreprendre une quelconque opération de nettoyage ou d'entretien, enlever toujours la fiche de la prise de courant.*
- *Ne pas tirer le câble d'alimentation électrique pour déplacer l'appareil.*
- *Ne pas installer l'appareil dans des pièces où l'air peut contenir des gaz, de l'huile, du soufre. De même, ne pas l'installer à proximité de sources de chaleur.*
- *Attendre toujours trois minutes au moins avant de remettre l'appareil en marche après l'avoir arrêté.*
- *Ne pas poser des objets lourds ou chauds sur l'appareil.*
- *Nettoyer le filtre à air chaque semaine.*
- *En cas de transport, l'appareil doit rester dans la position verticale ou bien il doit être couché sur un côté. Avant de le transporter, vider l'eau de condensation présente à l'intérieur du réservoir.*

Après avoir transporté l'appareil, attendre au moins une heure avant de le remettre en marche.

USAGE DOMESTIQUE SEULEMENT

**CONSERVEZ LES PRESENTES
INSTRUCTIONS**

Lire attentivement ce mode d'emploi avant d'installer et d'utiliser l'appareil. Cela vous permettra d'obtenir les meilleurs résultats et le maximum de sécurité.

Présentation

Le déshumidificateur DH 25 UL est un appareil qui enlève l'humidité présente dans les pièces où il est installé. C'est un appareil compact, doté de roues et de poignées, ce qui permet de le transporter facilement.

Son emploi est conseillé dans toutes les pièces où il existe des problèmes d'humidité excessive telles que les cuisines, les salles de bains, les buanderies, les caves, etc.



Caractéristiques techniques

<i>Tension d'alimentation</i>	115	V (60 Hz)
<i>Puissance absorbée</i>	420	W
<i>Courant absorbé</i>	4,6	A
<i>Humidité maximum enlevée en 24 heures</i>	12	litres
<i>Air traité</i>	260	m ³ /h
<i>Réfrigérant*</i>	R22	
<i>Dispositif de dégivrage</i>	oui	
<i>Indicateur d'humidité</i>	oui	
<i>Dimensions LxHxP</i>	570x550x300	mm
<i>Poids (net)</i>	26	kg
<i>Capacité réservoir</i>	6	litres
<i>Limites de fonctionnement :</i>		
• <i>température</i>	8 - 32	°C
• <i>humidité relative</i>	30 - 95	%

Conditions standard 27°C - 60% Humidité relative

** R22 est un réfrigérant qui répond aux exigences de la Directive Communautaire sur le respect de l'environnement.*

Accessoires

	Description	Nbre de pièces fournies avec l'appareil
	<i>Raccord 1</i>	
	<i>Bague de $\frac{3}{4}$ "</i>	<i>1</i>
	<i>Joint d'étanchéité</i>	<i>1</i>
	<i>Tuyau pour évacuation eau de condensation</i>	<i>1 (2 m.)</i>
	<i>Bouchon en caoutchouc</i>	<i>1</i>
	<i>joint borgne</i>	<i>1</i>

Important

Le certificat de garantie est joint à l'appareil. Demander à votre revendeur de valider le certificat si cela n'a pas encore été fait. Expédier ensuite la partie droite du certificat : cette formalité vous permettra de bénéficier de la garantie. Il est donc dans votre intérêt d'accomplir cette formalité !

Instructions pour l'installation

Placer l'appareil dans la pièce qui doit être déshumidifiée.

Il est nécessaire de laisser tout autour de l'appareil un espace d'au moins 50 cm pour ne pas gêner la circulation de l'air.

Il est possible d'évacuer l'eau de condensation de deux façons différentes :


A) Evacuation dans le réservoir

L'eau de condensation peut être recueillie directement dans le réservoir à l'intérieur de l'appareil (fig. 1).

Lorsque le réservoir est plein, un voyant s'allume et un dispositif de sécurité arrête l'appareil.

Le réservoir s'enlève facilement pour permettre de vider son contenu.

Fig. 1



B) Evacuation vers l'extérieur

L'eau de condensation peut être évacuée hors de l'appareil au moyen du raccord + tuyau d'évacuation à relier au réservoir. Dans ce cas, procéder comme suit:

- 1) *Percer l'endroit prédisposé de façon à permettre l'évacuation par l'embout.*
 - 2) *Monter le joint d'étanchéité, le tuyau et la bague sur l'embout du réservoir (voir fig. 2).*
 - 3) *Positionner le réservoir à l'intérieur de l'appareil.*
 - 4) *Un orifice pour le passage du tuyau d'évacuation de l'eau de condensation (fig. 3) est prévu sur la porte de l'appareil. Avant de faire passer le tuyau à travers cet orifice, il est nécessaire d'enlever la partie centrale.*
- N.B. : Si l'on désire avoir une évacuation en réservoir, ôter le tuyau, appliquer le joint borgne et le fixer avec la bague.*




Fig. 2

1. Réservoir
2. Joint d'étanchéité
3. Bague
4. Raccord
5. Embout
6. Joint borgne
7. Tuyau pour l'évacuation vers l'extérieur




Fig. 3


Branchement électrique

Avant d'enfoncer la fiche dans la prise de courant, vérifier que :

- La tension de réseau corresponde bien à celle qui est indiquée sur la plaque des données.
- La prise et la ligne d'alimentation électrique soient dimensionnées pour supporter la charge demandée.
- Le type de prise convienne à la fiche, sinon faire remplacer la fiche par des spécialistes.
- La prise soit raccordée à une installation de terre efficace.

Le constructeur décline toute responsabilité si cette norme pour la prévention des accidents n'est pas respectée. Cet appareil répond aux exigences de la directive communautaire antiparasitage 87/308/CEE.

Description des commandes



Comment déshumidifier

- 1) Brancher l'appareil sur une prise de courant. Le voyant alimentation s'allumera signalant ainsi que l'appareil est alimenté.
- 2) Vérifier que le voyant "réservoir plein/absence de réservoir" soit éteint.
- 3) Tourner le bouton de contrôle de l'humidité sur la position "CONTINUOUS" (fonctionnement continu).
- 4) Pour arrêter l'appareil, tourner le bouton dans le sens inverse à celui des aiguilles d'une montre jusqu'à ce que l'on atteigne la position "OFF".

Remarque :

Pour des raisons techniques, l'humidité n'est pas exprimée en degrés mais en niveaux.

On suggère de commencer en positionnant le bouton sur la position "CONTINUOUS" (fonctionnement continu). Lorsque l'humidité de la pièce sera celle désirée, tourner lentement le bouton de contrôle de l'humidité dans le sens inverse à celui des aiguilles d'une montre jusqu'à ce que l'appareil s'arrête. En procédant ainsi, on aura programmé l'appareil sur le degré de confort exact que l'indicateur d'humidité maintiendra automatiquement.

Quand l'appareil fonctionne, non seulement il déshumidifie mais il chauffe également la pièce avec une puissance de 460 W.

Quelques exemples d'utilisation sont indiqués sur le panneau de commande de l'appareil :

- Pour déshumidifier une pièce non habitée, ex. une cave
- • • Pour déshumidifier des pièces à usage d'habitation
- • • • Pour déshumidifier une pièce dans laquelle on désire un faible degré d'humidité, ex. une buanderie.

Entretien

Enlever toujours la fiche de la prise de courant avant d'entreprendre toute opération de nettoyage ou d'entretien. Pour des motifs de sécurité, ne pas laver le déshumidificateur avec un jet d'eau.

Nettoyage de la carrosserie extérieure

- Nettoyer la carrosserie extérieure uniquement avec un chiffon humide et la sécher avec un chiffon sec.
- Ne jamais utiliser d'essence, d'alcool ou de solvants pour le nettoyage.
- Ne jamais vaporiser de liquide insecticide ou d'autres produits similaires. Le vernis peut s'enlever et le plastique risque de se déformer.

Nettoyage du filtre à air

- Il est de règle de nettoyer le filtre chaque semaine.
- Pour ôter ce filtre, ouvrir la porte d'accès au réservoir, extraire le réservoir et extraire le filtre en le tirant vers le bas (fig. 4).
- Utiliser un aspirateur pour enlever la poussière qui s'est déposée sur le filtre. Si le filtre est très sale, le laver à l'eau tiède et le rincer plusieurs fois de suite.

La température de l'eau ne doit pas dépasser 40°C.

Après avoir lavé le filtre, laisser ce dernier sécher complètement avant de le réintroduire dans l'appareil.




Fig. 4

Longues périodes de non utilisation

- Après avoir enlevé la fiche de la prise de courant, évacuer l'eau du réservoir.
- Nettoyer le filtre et le réintroduire dans l'appareil.
- Couvrir l'appareil avec un sachet en plastique pour le protéger de la poussière.

En cas de panne :

Contrôler les points suivants avant de contacter le centre de service après-vente agréé de votre région.

Problèmes	Causes	Solutions
Le déshumidificateur ne fonctionne pas	• la fiche est débranchée • l'indicateur d'humidité est réglé sur le minimum • le réservoir est plein d'eau • le réservoir n'est pas positionné correctement	• enfoncer la fiche dans la prise • régler l'indicateur d'humidité sur la position désirée • vider le réservoir • positionner le réservoir correctement
Le déshumidificateur ne déshumidifie pas	• le filtre est sale • la température ou l'humidité dans la pièce sont trop basses	• nettoyer le filtre • dans certaines conditions, il est normal que l'appareil ne déshumidifie pas (voir le paragraphe "Caractéristiques techniques")
Le déshumidificateur fonctionne mais il ne réduit pas l'humidité présente dans la pièce	• la pièce est trop grande • les sources d'humidité (casserole en ébullition) présentes dans la pièce sont trop nombreuses	

POUR LE CANADA SEULEMENT :

GARANTIE

Nous garantissons que tous les APPAREILS ELECTRIQUES DE'LONGHI sont exempts de tout défaut de matériaux et de fabrication. Notre obligation vis-à-vis de cette garantie est limitée au remplacement ou à la réparation, gratuite dans notre usine, de toutes les pièces défectueuses autres que les pièces endommagées durant le transport, qui nous seront retournées - transport payé d'avance - endéans un an après la livraison à l'acheteur-utilisateur. Cette garantie ne sera applicable que si l'appareil a été utilisé selon les instructions du fabricant, lesquelles accompagnent l'appareil, et si l'appareil a été utilisé sur courant alternatif (AC). Cette garantie remplace toutes les autres garanties et représentations, exprimées ou implicites, et toutes autres obligations ou responsabilités de notre part. Nous n'autorisons aucune autre personne ou compagnie à assumer pour nous une quelconque responsabilité pour la vente ou l'utilisation de notre appareil.

Cette garantie ne s'appliquera ni aux appareils qui seront réparés ou endommagés hors de notre usine, ni aux appareils qui auront fait l'objet d'une mauvaise utilisation, d'une négligence ou d'un accident.

Si des réparations ou des pièces de rechange sont nécessaires, veuillez écrire à :

**DE'LONGHI CANADA
5610 TIMBERLEA BLDV
MISSISSAUGA, ONTARIO
L4W4M6 CANADA**

WARRANTY

All DE' LONGHI electrical appliances are guaranteed to be free from defects in material and workmanship. Our obligation under this warranty is limited to the replacement or repair, free of charge, at our factory or authorized Service Centers, of any defective part or parts thereof other than parts damaged in transit, which shall be returned to us, transportation pre-paid, within one year from the date of delivery to the purchaser/user. This warranty shall apply only if the appliance is used in accordance with the factory directions which accompany it, and on an alternating current (AC) circuit. This warranty is in lieu of all other express or implied warranties and representations and any other obligation or responsibility of the manufacturer. No other person or company is authorized to assume for us any liability in connection with the sale or use of our products.

This warranty does not cover appliances that have been repaired or modified outside our factory, nor to appliances which have been subject to misuse, negligence or accidents.

If repairs become necessary or spare parts are needed, please write to:

**DE' LONGHI CANADA
5610 TIMBERLEA BLVD.
MISSISSAUGA, ONTARIO
L4W 4M6 CANADA**