




## HOW TO USE YOUR COOKIES SHEET

Your oven is provided with an unique cookies sheet.



.....

The cookies sheet shall be placed directly on the wire rack inserted in the upper position.



.....

For baking cookies, biscuits, rolls, buns, or small cakes, follow the instruction booklets in the chapter instructions for baking. The only difference is that instead of using the bake/broil provided, we suggest you use the convenient cookies sheet.


Remember to pre-heat the oven before placing the cookies sheet with the food, on the wire rack.

## F UTILISATION DE VOTRE PLAQUE A BISCUIT

Votre four est doté de plaque à biscuit.



Placer la plaque à biscuit directement sur la grille, insérer la grille dans la position supérieure.



Pour cuire des biscuits, petits pains, petits gateaux, etc. suivre les instructions données dans votre mode d'emploi dans le paragraphe "Instructions pour cuire au four". La seule différence est que à la place d'utiliser le plateau de cuisson nous vous conseillons d'utiliser la plaque à biscuit.

Rappelez vous de préchauffer le four avant de placer la plaque à biscuit, avec les aliments à cuire sur la grille.