


FRIGGITRICE ELETTRICA  
ELECTRIC DEEP FRYER  
FRITEUSE ELECTRIQUE  
ELEKTRISCHE FRITEUSE  
ELEKTRISCHE FRITEUSE  
FREIDORA ELECTRICA  
FRITADEIRA ELECTRICA

**ΗΛΕΚΤΡΙΚΗ ΦΡΙΤΕΖΑ**  
**ЭЛЕКТРИЧЕСКАЯ ФРИТЮРНИЦА**  
**ELEKTROMOS OLAJSÜTŐ**  
**ELEKTRICKÝ FRITOVACÍ HRNEC**  
**FRYTKOWNICA ELEKTRYCZNA**  
ELEKTRISK FRITÖS  
ELEKTRISK FRITYRGRYTE  
ELEKTRISK FRITUREGRYDE  
SÄHKÖRASVAKEITIN



Istruzioni per l'uso  
Instructions for use  
Mode d'emploi  
Bedienungsanleitung  
Gebruiksaanwijzingen  
Instruccioones para el uso  
Instruções

**Οδηγίες χρήσης**  
**Инструкции по эксплуатации**  
**Használati utasítás**  
**Návod k použití**  
**Instrukcja obsługi**  
Bruksanvisning  
Bruksanvisning  
Brugsanvisninger  
Käyttöohjeet

## ELECTRICAL CONNECTION (U.K. ONLY)

- A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below. **warning:** Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard. With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse. If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.
- B) If your appliance is not fitted with a plug, please follow the instructions provided below:

**WARNING - THIS APPLIANCE MUST BE EARTHED**

### IMPORTANT

The wires in the mains lead are coloured in accordance with the following code:

|                  |         |
|------------------|---------|
| Green and yellow | Earth   |
| Blue             | Neutral |
| Brown            | Live    |



As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The green and yellow wire must be connected to the terminal in the plug marked with the letter E or the earth symbol  or coloured green or green and yellow.

The blue wire must be connected to the terminal marked with the letter N or coloured black.

The brown wire must be connected to the terminal marked with the letter L or coloured red.

