

De'Longhi Appliances via Seitz, 47 31100 Treviso Italia



GRIGLIA A CONTATTO

CONTACT-GRILL

GRILL A CONTACT

TISCHGRILL

KONTAKGRILL

PARILLA A CONTACTO

GREHLA DE CONTACTO

TOΣΤΙΕΡΑ

ΓΡИЛЬ

KONTAKTRENDSZERŰ GRILLSÜTŐ

Istruzioni per l'uso Instructions for use Mode d'emploi Bedienungsanleitung Gebruiksaanwijzingen Instrucciones para el uso Instruções de utilização Οδηγίες χρήσης Инструкции по эксплуатации Használati utasítás











KONTAKTNÍ GRIL KONTAKTN GRIL OPIEKACZ KONTAKTGRILL KONTAKGRILL KONTAKGRILL MONITOIMIPARILA ROŠTILJ SA KONTAKTOM KONTAKTNI ŽAR KOHTAKTHA CKAPA GRĂTAR CU CONTACT Návod k použití Návod na použitie Instrukcja obsługi Bruksanvisning Bruksanvisning Vejledning til brug Käyttöohjeet Upute za uporabu Navodila za uporabo Указания за употреба Instrucțiuni de folosire

أتعليمات الاستخدام

ELECTRICAL CONNECTION (UK ONLY)

A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below.

WARNING: Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard.

With alternative plugs not incorporating a fuse, the circuit

B) If your appliance is not fitted with a plug, please follow the instructions provided below:

WARNING - THIS APPLIANCE MUST BE EARTHED IMPORTANT

The wires in the mains lead are coloured in accordance with the following code:

Green and yellow: Earth
Blue: Neutral
Brown: Live



must be protected by a 15 Amp fuse.


If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.

As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The green and yellow wire must be connected to the terminal in the plug marked with the letter E or the earth symbol \clubsuit or coloured green or green and yellow.

The blue wire must be connected to the terminal marked with the letter N or coloured black.

The brown wire must be connected to the terminal marked with the letter L or coloured red.



Ė





POS. 3

