

**PLANCHA DE ASAR
PIASTRA DI COTTURA
GRIDDLE
PLAQUE DE CUISSON
GRIDDLE-GARPLATTE
ELEKTRISCHE BAKPLAAT
PLACA DE COZEDURA
ΨΗΣΤΙΕΡΑ
STEGEPLADE
STEKEOVERFLATE
STEKPLATTA
PAISTOLEVY
ЖАРОЧНАЯ ПОВЕРХНОСТЬ
SÜTŐLAP
PŁYTA DO SMAŻENIA
GRILOVACÍ PLOTÝNKA
GRILOVACIA PLATŇA**

De'Longhi

De'Longhi Appliances
via Seitz, 47
31100 Treviso Italia

Instrucciones para el uso

Istruzioni per l'uso

Instructions for use

Mode d'emploi

Gebrauchsanweisung

Gebruiksaanwijzing

Instruções de uso

ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ

Bruksveiledning

Bruksanvisning

Käyttöohje

ИНСТРУКЦИИ ПО ЭКСПЛУАТАЦИИ

Kezelési utasítás

NÁVOD K POUŽITÍ

INSTRUKCJA OBSŁUGI

Návod na použitie



ELECTRICAL CONNECTION (UK ONLY)

- A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below.

WARNING: Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard.

With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse.

If the plug is a moulded-on type, the fuse cover must be re-fitted when

The wires in the mains lead are coloured in accordance with the following code:

Green and yellow:	Earth
Blue:	Neutral
Brown:	Live



As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as

changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.

- B) If your appliance is not fitted with a plug, please follow the instructions provided below:

**WARNING - THIS APPLIANCE MUST BE EARTHED
IMPORTANT**

follows:

The green and yellow wire must be connected to the terminal in the plug marked with the letter E or the earth symbol  or coloured green or green and yellow.

The blue wire must be connected to the terminal marked with the letter N or coloured black.

The brown wire must be connected to the terminal marked with the letter L or coloured red.

