



www.delonghi.com

Register Now

www.delonghi.com/register



Instructions for use. Keep these instructions
Mode d'emploi. Conservez cette notice
Instrucciones para el uso. Repase y guarde estas
instrucciones. Lea cuidadosamente este instructivo antes
de usar su aparato

COFFEE MAKER MACHINE À CAFÉ CAFETERA

EC702



Register this product on-line and receive a free trial issue of
Cook's Illustrated. Visit www.delonghi.com for a list of service
centers near you.

Registre este producto en línea y reciba un ejemplar gratis de
Cook's Illustrated. Visite www.delonghi.com para ver la lista de
centros de servicios cercanos a usted.

Enregistrez ce produit en ligne et recevez un numéro gratuit de
Cook's Illustrated. Visitez www.delonghi.com pour y voir une
liste des centres de réparation proches de chez vous.

ELECTRONIC CHARACTERISTICS: CARACTÉRISTIQUES ÉLECTRIQUES: CARACTERISTICAS ELECTRICAS:

120V-60Hz - 1 100 W







