

**Register Now**   
[www.delonghi.com/register](http://www.delonghi.com/register)

---

CGH920

GRIGLIA A CONTATTO

CONTACT-GRILL

GRIL CONTACT

KONTAKTGRILL

CONTACTGRILL

GRILL DOBLE

GRELHADOR DE PLACAS

ТОСТІЕРА

ГРИЛЬ

ТИГІЗІП ПІСІРУ ПЛИТАСЫ

КОНТАКТНИЙ ГРИЛЬ



---

**De'Longhi**

**IT**

pág. 4

**EN**

page 18

**FR**

page 32

**DE**

S. 46

**NL**

pag. 60

**ES**

pág. 74

**PT**

pág. 88

**EL**

σελ. 102

**RU**

стр. 116

**KZ**

Бет. 132

**UK**

стр.151



MultiGrill



www.delonghi.com

## ELECTRICAL CONNECTION

- A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below. **WARNING:** Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard. With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse. If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.
- B) If your appliance is not fitted with a plug, please follow the instructions provided below:

**WARNING - THIS APPLIANCE MUST BE EARTHED**

### IMPORTANT

The wires in the mains lead are coloured in accordance with the following code:

|                   |         |
|-------------------|---------|
| Green and yellow: | Earth   |
| Blue:             | Neutral |
| Brown:            | Live    |



As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows: The green and yellow wire must be connected to the terminal in the plug marked with the letter E or the earth symbol  or coloured green or green and yellow. The blue wire must be connected to the terminal marked with the letter N or coloured black. The brown wire must be connected to the terminal marked with the letter L or coloured red.

