

ELECTRIC FRYER

FRITEUSE ELECTRIQUE

ELEKTRISCHE FRITEUSE

FRIGGITRICE ELETTRICA

ELEKTRISCHE FRITEUSE

FREIDORA ELECTRICA

FRITADEIRA ELECTRICA

ΗΛΕΚΤΡΙΚΗ ΦΡΥΤΕΖΑ

ELEKTRISK FRITUREGRYDE

ELEKTRISK FRITYRKOKER

ELEKTRISK FRITÖS

SÄHKÖRASVAKEITIN

ЭЛЕКТРИЧЕСКАЯ ФРИТЮРНИЦА

ELEKTROMOS OLAJSÜTŐ

ELEKTRICKÝ FRITOVACÍ HRNEC

FRYTKOWNICA ELEKTRYCZNA



INSTRUCTIONS FOR USE

MODE D'EMPLOI

BEDIENUNGSANLEITUNG

ISTRUZIONI PER L'USO

GEBRUIKSAANWIJZINGEN

INSTRUCCIONES PARA EL USO

INSTRUÇÕES

ΟΔΗΓΙΕΣ ΧΡΗΣΕΩΣ

BRUGSANVISNINGER

BRUKSANVISING

BRUKSANVISINGAR

KÄYTTÖOHJEET


ИНСТРУКЦИИ ПО ЭКСПЛУАТАЦИИ

HASZNÁLATI UTASÍTÁS

NÁVOD K POUŽITÍ

INSTRUKCJA OBSŁUGI





ELECTRICAL CONNECTION (U.K. ONLY)

- A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below. **Warning:** Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard. With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse. If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.
- B) If your appliance is not fitted with a plug, please follow the instructions provided below:

WARNING - THIS APPLIANCE MUST BE EARTHED


IMPORTANT

The wires in the mains lead are coloured in accordance with the following code:

| | |
|------------------|---------|
| Green and yellow | Earth |
| Blue | Neutral |
| Brown | Live |



As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The green and yellow wire must be connected to the terminal in the plug marked with the letter E or the earth symbol  or coloured green or green and yellow.

The blue wire must be connected to the terminal marked with the letter N or coloured black.

The brown wire must be connected to the terminal marked with the letter L or coloured red.

