


MACCHINA DA CAFFÉ  
COFFEE MACHINE  
MACHINE A CAFE  
ESPRESSOMACHINE  
ESPRESSO-APPARAAT  
CAFETERA ELÉCTRICA  
MÁQUINA DE CAFÉ  
ΜΗΧΑΝΗ ΚΑΦΕ  
ΚΟΦΕΒΑΡΚΑ  
EKS PRES DO KAWY  
ΚÁVOVAR  
KÁVÉFŐZŐGÉP  
KAHVINKEITIN  
ESPRESSOMASKIN  
KAFFEMASKINE  
ESPRESSOMASKIN



  
**ME 10**

Istruzioni per l'uso  
Instructions for use  
Mode d'emploi  
Bedienungsanleitung  
Gebruiksaanwijzingen  
Instrucciones para el uso  
Instruções  
Οδηγίες χρήσεως  
Kezelési utasítás  
Návod k použití  
Instrukcja użytkowania  
Инструкция по эксплуатации  
Käyttöohjeet  
Bruksanvisning  
Brugervejledning  
Bruksanvisning

## ELECTRICAL CONNECTION (UK ONLY)

- A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below.

**WARNING:** Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard.

With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse.

If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.

- B) If your appliance is not fitted with a plug, please follow the instructions provided below:

### **WARNING - THIS APPLIANCE MUST BE EARTHED**


#### **IMPORTANT**

The wires in the mains lead are coloured in accordance with the following code:

Green and yellow:	Earth
Blue:	Neutral
Brown:	Live



As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The green and yellow wire must be connected to the terminal in the plug marked with the letter E or the earth symbol  or coloured green or green and yellow.

The blue wire must be connected to the terminal marked with the letter N or coloured black.

The brown wire must be connected to the terminal marked with the letter L or coloured red.

