

NESCAFÉ
Dolce
Gusto

DēLonghi



- NO** Brukerhåndbok
- SV** Användarmanual
- FI** Käyttöopas
- DA** Brugervejledning
- ES** Manual de usuario
- IT** Istruzioni per l'uso
- FR** Mode d'emploi
- DE** Bedienungsanleitung
- EN** User manual





NO Oversikt
SV Översikt
FI Yleiskatsaus

DA Oversigt
ES Vista general
IT Vista d'insieme

FR Vue d'ensemble
DE Übersicht
EN Overview



4




NO Produktutvalg
SV Produktöversikt
FI Tuotevalikoima

DA Produktprogram
ES Gama de producto
IT Gamma di prodotti

FR Gamme de produits
DE Produktübersicht
EN Product range



5



NO Første gangs bruk
SV Första användning
FI Käyttö ensimmäistä kertaa

DA Første anvendelse
ES Primera puesta en funciona-
miento
IT Prima messa in funzione

FR Première mise en service
DE Erste Inbetriebnahme
EN First use



7




NO Fremstille en drikk
SV Förbereda dryck
FI Juoman valmistus

DA Tilberedning af drik
ES Preparación de una bebida
IT Preparazione delle bevande

FR Préparation d'une boisson
DE Getränkezubereitung
EN Preparing a beverage



8



NO Strømsparemodus
SV Energisparläge
FI Ekonominen tila

DA Økonomi-mode
ES Modo Económico
IT Modalità Eco

FR Mode Eco
DE Stromsparmmodus
EN Economy mode



10



NO Rengjøring
SV Rengöring
FI Puhdistus

DA Rengøring
ES Limpieza
IT Pulizia

FR Nettoyage
DE Reinigung
EN Cleaning



11



NO Avkalking hver 3.-4. måned
SV Avkalkning var 3-4 månad
FI Kalkinpoisto 3-4 kuukauden
välein

DA Afkalkning hver 3.-4. måned
ES Descalcificación cada 3-4 meses
IT Decalcificazione ogni 3-4 mesi

FR Détartrage tous les 3-4 mois
DE Entkalkung alle 3-4 Monate
EN Descaling every 3-4 months



12



NO Feilsøking
SV Felsökning
FI Vianmäärittäminen

DA Problemløsning
ES Resolución de problemas
IT Guasti

FR Dépannage
DE Störungsbehebung
EN Troubleshooting



14



NO Sikkerhetsregler
SV Säkerhetsanvisningar
FI Turvallisuuteen liittyvät
varotoimet

DA Sikkerhedsforskrifter
ES Indicaciones de seguridad
IT Indicazioni di sicurezza

FR Consignes de sécurité
DE Sicherheitshinweise
EN Safety precautions



15-23


NESCAFÉ
Dolce
Gusto



NO Oversikt
SV Översikt
FI Yleiskatsaus

DA Oversigt
ES Vista general
IT Vista d'insieme

FR Vue d'ensemble
DE Übersicht
EN Overview



~	NO, SV, FI, DA, ES, IT, FR, CH, DE, AT, UK	230 V 50 Hz	max./máx./maks. 1500 W
---	---	----------------	---------------------------


P	max./máx./maks. 15 bar/baria	1.5 l	3 kg	5 °C - 45 °C 41 °F - 113 °F	A = 21.0 cm B = 30.1 cm C = 30.5 cm
---	---------------------------------	-------	------	--------------------------------	---




NO Produktutvalg
SV Produktöversikt
FI Tuotevalikoima

DA Produktprogram
ES Gama de producto
IT Gamma di prodotti

FR Gamme de produits
DE Produktübersicht
EN Product range




ESPRESSO



Espresso Intenso
40 ml

Espresso
60 ml

CAFFÈ LUNGO




Caffè Lungo
120 ml

CAPPUCCINO



① 200 ml + ② 40 ml = Cappuccino 240 ml


CHOCOCINO



LATTE MACCHIATO



AROMA / CAFFÈ CREMA GRANDE



CAPPUCCINO ICE

