


COFFEE MACHINE
 MACHINE A CAFE
 ESPRESSOMASCHINEN
 MACCHINA PER CAFFÉ
 ESPRESSO-APPARAAT
 CAFETERA ELÉCTRICA
 MÁQUINA DE CAFÉ
 MHCANH KAFE
 EKS PRES DO KAWY
KÁVÉFŐZŐGÉP
KÁVOVAR
 ΚΟΦΕΒΑΡΚΑ
 KAFFEMASKINE
 KAFFEBRYGGARE
 KAFFEMASKIN
 KAHVINKEITIN




OPERATING INSTRUCTIONS
 MODE D'EMPLOI
 BEDIENUNGSANLEITUNG
 ISTRUZIONI PER L'USO
 GEBRUIKSAANWIJZINGEN
 INSTRUCCIONES PARA EL USO
 INSTRUÇÕES
 ODHGIE CRHSEW
INSTRUKCJA OBSŁUGI
KEZELÉSI UTASÍTÁS
NÁVOD K POUŽITÍ









ИНСТРУКЦИИ ПО ЭКСПЛУАТАЦИИ
 BRUGSANVISNING
 BRUKSANVISNING
 BRUKSANVISNING
 KÄYTTÖOHJEET

De'Longhi

De'Longhi S.p.A.
 via Seitz, 47
 31100 Treviso Italia

PG
ME 10





ELECTRICAL CONNECTION (UK ONLY)

- A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below.

WARNING: Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard.

With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse.

- If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.
- B) If your appliance is not fitted with a plug, please follow the instructions provided below:

WARNING - THIS APPLIANCE MUST BE EARTHED **IMPORTANT**

The wires in the mains lead are coloured in accordance with the following code:

Green and yellow:	Earth
Blue:	Neutral
Brown:	Live



As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The green and yellow wire must be connected to the terminal in the plug marked with the letter E or the earth symbol  or coloured green or green and yellow.

The blue wire must be connected to the terminal marked with the letter N or coloured black.

The brown wire must be connected to the terminal marked with the letter L or coloured red.