




- A1. Water tank lip and filter storage
- A2. Cup warmer/storage tray
- A3. Control panel dial
- A4. Boiler outlet
- A5. Steam dial
- A6. Steam spout / frother
- A7. High glass tray
- A8. Drip tray
- A9. Water tank



- B1. Filter holder with 3 filter cups
- B2. Tamper/dispenser measure scoop



Get Started & Owner's Instructions Booklets




# MACHINE SET UP



5713235621\_00\_0817




Remove tank, fill with water and replace.





Place containers under boiler outlet and cappuccino maker.



Turn dial to ON position, red light is on and unit is heating up.



When READY light is green, turn dial to position, let about half the tank discharge from the boiler outlet.



Then turn the steam dial to the position and discharge all the water remaining in the tank from the cappuccino maker. Turn the steam dial back to and the selector dial to ON position to stop the flow.

Note: This operation can take a few minutes. The machine may vibrate.

**Machine is now ready to work!**