

Warranty

We grant a **three-year warranty** from the date of purchase.

This product was manufactured using the latest production techniques and has undergone thorough quality control inspection. We guarantee that the product is in perfect condition.

We will remedy all defects in workmanship or materials within the warranty period. In order for the warranty to be granted, all warranty claims must be accompanied by proof of purchase from Tchibo or from an authorised Tchibo distribution partner.

If, contrary to our expectations, a defect is found, please contact our customer care service at the following e-mail address:

service@tchibo.de

Our customer consultants will be pleased to advise you on further procedure.

Damage due to improper use, as well as worn parts and consumables, are not covered by the warranty.


Please have the product number at hand in case of any queries.

This warranty does not restrict statutory warranty rights.

Product number: 366 949



Car Vacuum Cleaner



Dear Customer

Your new car vacuum cleaner is ideal for vacuuming up dust, dirt and crumbs in the footwell, on car seats, etc. The connection cable is long enough to enable you to vacuum the boot, for example. Hard-to-reach places can be easily accessed using the handy crevice nozzle.

We hope you enjoy using your new car vacuum cleaner.

Your Tchibo Team



www.tchibo.de/instructions

(Please enter the product number in the box labelled "Bedienungsanleitungssuche" and click on "Suchen".)

Contents

3 About these instructions	11 Cleaning
4 Safety warnings	11 Cleaning the attachments
7 At a glance (features)	11 Releasing the dust collector
8 Use	12 Removing and cleaning the filter
8 Connecting the car vacuum cleaner to the cigarette lighter socket	13 Cleaning the casing
9 Switching the car vacuum cleaner on and off	13 Replacing the fuse
9 Attaching the suction nozzle	14 Problems / solutions
	15 Technical specifications
	16 Warranty

4. Reconnect the car battery and/or reinsert the fuse.

Poor suction

- Is the dust collector full or not attached correctly?
- Is the filter very dirty?

Dust escapes from the dust collector

- Is the dust collector full or not attached correctly?
- Is the filter not inserted correctly?

Technical specifications

Model:	366 949
Power supply:	cigarette lighter 12 V DC
Fuse:	safety fuse 15 A / 250 V
Motor output:	75 W
Made exclusively for:	Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany

In the course of product improvement, we reserve the right to make technical and optical modifications to the product.



3. Then reassemble the parts in the order shown.

Problems / solutions

The vacuum cleaner does not work

- Is the connector plug of the car vacuum cleaner completely plugged into the cigarette lighter socket?
- Is the cigarette lighter socket supplied with power? It may be necessary to switch on the ignition first.
- Is the fuse in the connector plug of the car vacuum cleaner and the corresponding vehicle fuse for the cigarette lighter socket OK?

Part of the connection plug came loose when it was unplugged and is stuck in the cigarette lighter socket



DANGER - risk of fatal electric shock

- If any part of the connector plug should get stuck in the cigarette lighter socket, it can only be removed using insulated pliers or a similar tool. Always disconnect the vehicle battery first or switch off the fuse before reaching into the cigarette lighter socket. Otherwise there is a risk of electric shock and short-circuiting the car's electronics.

1. Disconnect the car battery and/or remove the fuse.
2. Remove the part of the connector plug which had got stuck from the cigarette lighter plug socket carefully using insulated pliers or a similar tool.
3. Attach the part to the connector plug again.

About these instructions

This product is equipped with safety features. Nevertheless, read the safety warnings carefully and only use the product as described in these instructions to avoid accidental injury or damage.

Keep these instructions for future reference. If you pass this product on to another person, remember to give them these instructions.

Symbols in these instructions:



This symbol warns you of the danger of injury.



This symbol warns you of the danger of injury caused by electricity.

The term **DANGER** warns you of potential severe injury and danger to life.

The term **WARNING** warns you of injury and severe material damage.

The term **CAUTION** warns of minor injury or material damage.



This indicates additional information.

Safety warnings



Intended use

- The car vacuum cleaner is suitable for vehicles with a cigarette lighter socket. The vacuum cleaner has been designed to vacuum dust, dirt, crumbs, etc. in vehicles. It is not suitable for cleaning larger areas or for continuous operation. The car vacuum cleaner is suitable for a 12 V power supply.
- The product is designed for home use and is not suitable for commercial purposes.

DANGER to children and people with restricted capabilities of operating appliances

- This appliance must not be used by children or by people who are unable to use it safely due to reduced physical, sensory or mental capabilities or lack of experience and/or knowledge. Children must be supervised to ensure that they do not play with the appliance.
- Keep the packaging material out of the reach of children. There is a risk of suffocation!

WARNING - hazards resulting from misuse

- Never vacuum up the following:
 - glowing ash, cigarette butts, matchsticks, etc.: fire hazard!
 - toner for printers: fire or explosion hazard!
 - caustic or toxic substances (e.g. acid, asbestos or asbestos dust, etc.): danger to health!
 - liquids (in particular liquid carpet cleaners): danger of short circuit!
 - pointed, hard objects (splinters of glass, nails, etc.): these can destroy the filter.

Cleaning the casing

CAUTION - material damage

- Do not use any caustic, aggressive or abrasive products for cleaning.


► Use a slightly dampened, lint-free cloth to clean the casing.

Replacing the fuse

If the car vacuum cleaner is no longer working, although the connector plug is fully connected to the cigarette lighter plug socket, the fuse in the connector plug may be faulty and must be replaced with a new one.




Some cigarette lighter sockets will only receive power when the ignition is turned on. Check this first.



1. Loosen the nut (using pliers if necessary) and remove all the parts in the order illustrated. **Caution: the fuse is spring-loaded!**
2. Replace the fuse with a new one of the same type (see "Technical specifications"). Replacement fuses are available in car parts shops.

Removing and cleaning the filter



1. Remove the filter from the dust collector.
2. Empty the dust collector. If necessary, wipe it out with a damp cloth.
3. Tap the filter to knock any dirt out.
4. Use a slightly dampened, lint-free cloth or a brush to clean the filter.
If it is dirty, clean it with a conventional vacuum cleaner. If the filter has become very dirty, it can be cleaned in lukewarm, clear water. In this case, ensure it is allowed to dry thoroughly before putting it back in. If the filter can no longer be cleaned satisfactorily or if the suction power decreases due to the filter, you can purchase a new one from our customer care service (see "Warranty" section).
5. To replace the dust collector, first attach it to the bottom of the vacuum cleaner (in the opposite order as illustrated in "Releasing the dust collector"). Then raise the dust collector over the motor section as far as it will go. You should be able to feel and hear the release button click into place.

- plaster, cement, dust from drilling, construction waste, make-up, etc.: these substances could block the filter and damage the appliance.
- cables, wiring, etc.: this may damage the insulation.

DANGER due to electricity

- Never immerse the appliance or connecting cord in water or other liquids as there is otherwise a risk of electric shock. Do not touch the appliance with wet hands.
- If any part of the connector plug should get stuck in the cigarette lighter socket, it can only be removed using insulated pliers or a similar tool. Always disconnect the vehicle battery first or switch off the fuse before reaching into the cigarette lighter socket. Otherwise there is a risk of electric shock and short-circuiting the car's electronics.
- Do not insert any pins or other metal objects into the openings on the appliance.
- Do not operate the appliance if the vacuum cleaner itself, its connector plug or connecting cord show any sign of damage or if the vacuum cleaner has been dropped.
- Do not disassemble the appliance any more than instructed in this manual. Do not make any modifications to the product. Only have repairs to the appliance, connector plug or connecting cord carried out by a specialist workshop, or contact the customer care service.

WARNING - risk of injury

- Do not leave the car vacuum cleaner lying around in the car after using it. Fix it in the boot, for example, or keep it stored in your home.

- Make sure that no one can trip over the connecting cord.
- Never use the vacuum cleaner on people or animals. Always keep hair, parts of the body and items of clothing such as shoe laces and scarves well away from the suction opening. Never attempt to remove a blockage when the vacuum cleaner is operating.

CAUTION - material damage

- Only insert the connecting plug into a cigarette lighter socket that complies with its "Technical specifications".
- Do not overheat the car vacuum cleaner. Switch it off after max. 15 minutes and leave it to cool down for approx. 30 minutes. Ensure that the airing vents on the appliance are not covered by dust or similar substances.
- Only carry the car vacuum cleaner by the handle, not by the connecting cord.
- Always use the filter.
- Only use the original parts.
- To protect the car battery, remove the connector plug from the cigarette lighter plug socket when you are not using it. Always pull on the connector plug, not the connecting cord.
- Do not expose the car vacuum cleaner to extreme temperatures. Protect the product from direct sunlight, moisture and dust.
- Never use scouring, abrasive or caustic cleaning products.
- Before operating the car vacuum cleaner, read the operating instructions for the vehicle (especially hybrid or electric vehicles) in which you intend to connect the car vacuum cleaner, or ask your car dealer.

Cleaning


Cleaning the attachments

- ▷ Remove hair and threads from the brush attachment.
- ▷ Wipe off the attachments with a slightly dampened lint-free cloth.

Releasing the dust collector


CAUTION - material damage

- The vacuum cleaner must not be switched on while you remove the dust collector.




1. Disconnect the power plug from the cigarette lighter socket.
2. Hold the car vacuum cleaner so that the dust collector is pointing downwards.
3. Press and hold the release button and remove the dust collector from the motor section.

Crevice nozzle



Use the crevice nozzle to reach corners and awkward places that cannot be reached with the large nozzle.




For places that are difficult to access, you can also use the flexible hose.

10

10

At a glance (features)



7


7


Use



- The car vacuum cleaner will warm up during use. This is normal and not a malfunction.
- Some cigarette lighter sockets will only receive power when the ignition is turned on. Check this first.


Connecting the car vacuum cleaner to the cigarette lighter socket


1.  Make sure the on/off switch is in the **OFF** position.



Insert the connecting plug on the connecting cord into the socket on the car vacuum cleaner and the connector plug into the cigarette lighter socket. The indicator light shows that the unit is ready for operation.


Switching the car vacuum cleaner on and off

- ▷  To switch the product on, slide the switch to the **ON** position.

- ▷  To switch the product off, slide the switch to the **OFF** position.

Attaching the suction nozzle

Brush attachment



Use the brush attachment for vacuuming car seats and sensitive surfaces, such as the dashboard etc.