

# Important safeguards

GB

- This appliance is designed for home air conditioning and must not be used for other purposes.
- It is dangerous to modify or alter the characteristics of the appliance in any way.
- The appliance must be installed in conformity with legislation in force in the country concerned.
- If the appliance requires repair, contact a Service Centre authorised by the manufacturer only. Repairs carried out by unauthorised personnel may be dangerous.
- If the power cable is damaged, it must be replaced by the manufacturer, an authorised service centre or a qualified electrician in order to eliminate all risk.
- This appliance must be used exclusively by adults.
- Do not allow children or unfit persons to use the appliance without adequate supervision.
- Do not allow children to play with the appliance.
- The appliance must be connected to an efficient earth system.
- Have your electrical circuit checked by a qualified electrician.
- Do not use extension cables.
- Before cleaning or maintenance operations, always unplug the appliance from the mains socket.
- Do not move the appliance by pulling the power cable.
- Do not install the appliance in rooms containing gas, oil or sulphur. Do not install near sources of heat.
- Do not rest heavy or hot objects on top of the appliance.
- Clean the anti-microbial filters at least once a week.
- Avoid using heating appliances near the air conditioner.
- Always transport the appliance upright or resting on one side.
- Use the appliance as described in this instruction manual only.
- As with all electrical equipment, whilst the instructions aim to cover as many eventualities as possible, caution and common sense should be applied when operating and installing this appliance.
- At the end of its working life, take the appliance to a special collection centre.
- The materials used for packaging can be recycled.
- You are therefore recommended to dispose of them in special differentiated waste collection containers.
- The refrigerant gas R407c conforms to EC regulations on the environment.
- Avoid perforating the refrigerant circuit of the appliance.
- Keep the appliance at least 50 cm away from flammable substances (alcohol etc) or pressurised containers (e.g. aerosol cans).

## DESCRIPTION

- |   |                              |    |                           |
|---|------------------------------|----|---------------------------|
| 1 | air outlet grille            | 10 | drainage hose             |
| 2 | control panel                | 11 | Flange                    |
| 3 | castors                      | 12 | flange cap                |
| 4 | handles                      | 13 | air exhaust hose          |
| 5 | filter                       | 14 | air exhaust hose coupling |
| 6 | evaporator air intake grille | 15 | window outlet             |
| 7 | air exhaust hose housing     | 16 | remote control unit       |
| 8 | condenser air intake grille  |    |                           |
| 9 | power cable                  |    |                           |

# Preparing for use

## ELECTRICAL CONNECTIONS

Before plugging the appliance into the mains socket, check that:

- The mains power supply corresponds to the value indicated on the rating plate on the back of the appliance;
- The mains socket and electrical circuit are adequate for the appliance;
- The mains socket matches the plug. If this is not the case, have the plug replaced;
- The mains socket is adequately earthed. **Failure to follow these important safety instructions absolves the manufacturer of all liability.**

**The power cable must be replaced by a qualified professional only.**

The instructions below will enable you to prepare your air conditioner for operation as efficiently as possible.


**Before use, make sure the air intake and outlet grilles are unobstructed.**

## AIR-CONDITIONING WITHOUT INSTALLATION

Just a few simple steps and your comfort is ensured with your air conditioner:

- Fit the air exhaust hose coupling **14** onto the air exhaust hose **13**.
- Fit the air exhaust hose **13** in the housing **7** at the back of the appliance.


Insert it as shown in figure **A**.



- Fit the window outlet **13** to the end of the hose **15**.
- Place the air conditioner near a window or French window.
- Make sure the air exhaust hose is unobstructed.

- Open the window or French window slightly and position the outlet as shown in figure **B** **15**.


Keep the air hoses as short and free of curves as possible to avoid constrictions.



# Preparing for use


## AIR-CONDITIONING WITH INSTALLATION

If required, your appliance can also be installed semi-permanently (Fig. C).



Proceed as follows:

- Drill a hole in an outside wall or through a window pane. Respect the height and dimensions of the hole given in figure D.




in the window pane

in the wooden kick-board of a French window

in the wall: you are recommended to insulate the section of wall using suitable insulation.

D

- Fit the flange accessory [10] provided in the hole.
- Fit the hose [13] in the housing at the back of the appliance (fig. A page 16).
- Fit the end of the hose [13] to the flange [11] as shown in fig. E.



When the hose [13] is not fitted, the hole can be closed with the flange cap [12].


### NOTE.

When installing the air conditioner semi-permanently, you should leave a door slightly open (as little as 1 cm) to guarantee correct ventilation.

Keep the air hoses as short and free of curves as possible to avoid constrictions.

# Control panel

## THE CONTROL PANEL



## DESCRIPTION OF THE CONTROL PANEL

**A** ON/OFF button

**B** MODE selection button

Air conditioning, dehumidifying, fan.

**C** Fan speed selection button (HIGH/MED/LOW)

**D** Timer button

**E** Programmed operation increase temperature/time button

**F** Programmed operation decrease temperature/time button

**G** Display Displays the temperature values set and the programmed operating time

**H** Timer in operation indicator light

**I/L/M** Fan speed lights

**N** Fan mode light

**O** Air-conditioning mode light

**P** Dehumidifying mode light

**Q** Alarm light

## TURNING THE APPLIANCE ON

Plug the appliance into the mains.

Press the **ON/OFF** button (**A**) (when turned on, the air conditioner starts operating in the same mode as when it was turned off).

The display shows the room temperature.

Press the **MODE** button (**B**) until the indicator light corresponding to the required mode lights up:

Light (**O**): air-conditioning mode

Light (**N**): fan mode

Light (**P**): dehumidifying mode

## AIR-CONDITIONING MODE

Ideal for hot humid weather when you need to cool and dehumidify the room.

To set operation of the appliance correctly, press the + (**E**) or - (**F**) buttons until the desired temperature is displayed.

Then select the fan speed by pressing the FAN button (**C**) until the indicator light corresponding to the required fan speed lights up:

HIGH: the air conditioner operates at maximum to reach the required temperature as rapidly as possible

MED: reduces noise levels but still maintains a good level of comfort

LOW: for silent operation

*The most suitable temperature for the room during the summer varies from 24 to 27°C. You are recommended, however, not to set a temperature much below the outdoor temperature.*

# Operation

## FAN MODE

Adjust fan speed by pressing the FAN button (**C**) as described for the air-conditioning mode. Remember that the higher the speed, the more air is filtered. If you select "**LOW**" speed, less air is filtered but the appliance is also less noisy.

## DEHUMIDIFYING MODE

Ideal for reducing the humidity in a room without lowering or raising the temperature (spring or autumn, damp rooms, rainy spells, etc).

When the dehumidifying mode is selected, the light (**P**) comes on.

At the same time, the "**LOW**" fan speed light (**M**) comes on. In this mode, other speeds cannot be selected.

## PROGRAMMING THE TIMER

The timer can be used to delay appliance start up or shut down. This avoids wasting electricity by optimising operating periods.

### How to programme delayed start up

- Plug the appliance into a mains socket and press the ON/OFF button (**A**), then select the required operating mode and other settings (temperature, fan speed, etc).
- Press the ON/OFF button (**A**) again to place the appliance in standby mode.
- Press the timer button (**D**). The timer light "**H**" flashes.
- Use the + (**E**) or - (**F**) buttons to set the number of hours delay before the appliance comes on.
- The time increases or decreases in steps of one hour.

The indicator light (**H**) flashes until the appliance starts up.

You can set the appliance to come on with a delay of up to 12 hours.

To cancel the timer programme, press the timer button (**D**) again.

Light (**H**) stops flashing.

### How to programme delayed shut down

- Delayed shut down can be programmed in any operating mode (air conditioning / fan/ dehumidifying).
- Press the timer button (**D**). The timer light "**H**" flashes.
- Use the + (**E**) or - (**F**) buttons to set the number of hours delay before the appliance goes off.

The time increases or decreases in steps of one hour.

The light (**H**) flashes until the appliance turns off as programmed.

At the set time, the air conditioner shuts down and remains in standby.

To cancel the timer programme, press the timer button (**D**) again.


Light (**H**) stops flashing.

# Using the remote control unit (Certain models only)

GB

## MODELS WITH REMOTE CONTROL

- Point the remote control at the receiver on the air-conditioner.
- The remote control should be handled with **extreme care and respect**. Do not drop it, expose it to direct sunlight, or leave it near sources of heat.




## DESCRIPTION OF THE REMOTE CONTROL

- 17) "ON/OFF" button
- 18) "MODE" button
- 19) Programmed operation temperature increase button
- 20) Programmed operation temperature decrease button
- 21) "TIMER" button
- 22) Fan speed selection button (HIGH/MED/LOW).

## Replacing the batteries

- Remove the cover on the rear of the remote control;
- Replace the old batteries with two new LR03 "AAA" 1.5V batteries, inserting them correctly (see the instructions inside the battery compartment);
- Replace the cover.



**If the remote control unit is replaced or discarded, the batteries must be removed and disposed of in accordance with current legislation as they are harmful to the environment.**

## TURNING THE APPLIANCE ON

Plug the appliance into the mains.

Press the **ON/OFF** button (17) (when turned on, the air conditioner starts operating in the same mode as when it was turned off).

Press the **MODE** button (18) to select the required mode

**COOLING**

**DEHUMIDIFYING**

**FAN ONLY**

On the control panel, the light corresponding to the selected mode comes on.

For air conditioning/dehumidifying/fan only settings and programming the timer, see page.19-20


# Tips

To get the best from your air conditioner, follow these recommendations:

- close the windows and doors in the room to be air conditioned.


The only exception is when the appliance is installed through a hole in the wall.

In this case, you are recommended to leave a slight draught through a door or window to guarantee correct ventilation.




*close doors and windows*

- Protect the room from direct exposure to the sun by partially closing curtains and/or blinds to make the appliance much more economical to run;
- Never rest objects of any kind on the air conditioner;
- Never obstruct the air intake **6** or outlet **1** grilles;
- Make sure there are no heat sources in the room.



*do not cover the appliance*



*close blinds or curtains*

- Make sure the air conditioner is on a **level** floor.



# Cleaning

Before cleaning or maintenance, turn the appliance off by pressing the ON/OFF button (A) or in models with remote control unit, by pressing the ON/OFF button **17**, then always unplug the appliance from the mains socket.

## CLEANING THE CABINET

You should clean the appliance with a slightly damp cloth then dry with a dry cloth. For safety reasons, never wash the air conditioner with water.

## Precautions

Never use petrol, alcohol or solvents to clean the appliance. Never spray insecticide liquids or similar.


## CLEANING THE AIR FILTERS

To keep your air conditioner working efficiently, you should clean the dust filter every week of operation.

The filter is housed in the intake grille.

To clean the filters, proceed as follows:

1. Remove the filter as shown in figure **F**



Use a vacuum cleaner to remove the dust collected on the filter.

If it is very dirty, immerse in warm water and rinse a number of times.

The water should never be hotter than 40°C.

After washing, leave the filter to dry.

Put the filter back in its housing.

## START OF SEASON CHECKS

Make sure the power cable and plug are undamaged and the earth system is efficient. Follow the installation instructions precisely.


## END OF SEASON OPERATIONS

To empty water from the appliance circuit completely, remove the hose on the back of the appliance and remove the cap.

Run off any water left completely (figure **G**).

When all the water has been drained, put the hose back in its housing.

Clean the filter and dry thoroughly before putting back.



# Troubleshooting

PROBLEM	CAUSE	REMEDY
<b>The air conditioner does not come on</b>	<ul style="list-style-type: none"> <li>• no electricity</li> <li>• it is not plugged into the mains</li> <li>• the safety device has tripped</li> </ul>	<ul style="list-style-type: none"> <li>• wait</li> <li>• plug into the mains</li> <li>• contact your service centre</li> </ul>
<b>The air conditioner works for a short time only</b>	<ul style="list-style-type: none"> <li>• the air exhaust hose has a constriction</li> <li>• the air exhaust hose is blocked</li> <li>• there are bends in the air exhaust hose</li> </ul>	<ul style="list-style-type: none"> <li>• position the exhaust hose correctly</li> <li>• check there are no obstacles obstructing air discharge</li> <li>• eliminate the bends</li> </ul>
<b>The air conditioner works, but does not cool the room</b>	<ul style="list-style-type: none"> <li>• window open</li> <li>• there are heat sources in the room (burner, lamp, etc)</li> <li>• the exhaust hose is detached</li> <li>• air filter clogged</li> <li>• the air conditioner is not powerful enough for the conditions or size of the room</li> </ul>	<ul style="list-style-type: none"> <li>• close the window</li> <li>• eliminate the heat source</li> <li>• connect the exhaust hose</li> <li>• clean or replace the filter</li> </ul>
<b>Particular odour in the room</b>	<ul style="list-style-type: none"> <li>• il filtro dell'aria è intasato</li> </ul>	<ul style="list-style-type: none"> <li>• pulire il filtro o sostituirlo</li> </ul>
<b>The air conditioner does not operate for about three minutes after turning it on</b>	<ul style="list-style-type: none"> <li>• the safety device has tripped</li> </ul>	<ul style="list-style-type: none"> <li>• wait for three minutes</li> </ul>
<b>The alarm light Q comes on</b>	<ul style="list-style-type: none"> <li>• the tank inside the appliance is full.</li> </ul>	<ul style="list-style-type: none"> <li>• empty the tank by means of the hose on the back of the appliance (see "End of season operations on page 23).</li> </ul>

# Guarantee/technical specification

## **GUARANTEE AND TECHNICAL ASSISTANCE**

The conditions of the guarantee and technical assistance are given on the certificate supplied with your appliance.

LIMIT CONDITIONS	
Room temperature for air conditioning	21 ÷ 35°C

## **TECHNICAL SPECIFICATION**

Power supply voltage	see rating plate
Max. absorbed power during air conditioning	"
Refrigerant	"
Cooling capacity	"

**GB**

Appliance dimensions:	
• width	460 mm
• height	840 mm
• depth	320 mm
• weight	36 kg

Transport, filling, cleaning, recovery and disposal of refrigerant should be performed by a technical service centre appointed by the manufacturer only.  
The appliance should be disposed of by a specialist centre appointed by the manufacturer only.