

ASPIRAPOLVERE-ASPIRASOLIDI
DRY VACUUM CLEANER
ASPIRATEUR
STAUBSAUGER UND FESTKÖRPERSAUGER
STOFZUIGER - VASTE STOFFENZUIGER
ASPIRADOR-ASPIRASÓLIDOS
ASPIRADOR DE PÓ - ASPIRADOR DE
SOLIDOS

HLEKTRIKH SKOUPA ANARROFHSHS SKONHS-
ANARROFHSHS STEREWN OUSIWN
ПЫЛЕСОС - СБОРНИК

MANUALE DI ISTRUZIONI
OPERATING INSTRUCTIONS
MODE D'EMPLOI
GEBRAUCHSANWEISUNG
GEbruikSAANWIJZING
MANUAL DE INSTRUCCIONES
MANUAL DE INSTRUÇÕES
Expeirivdio Odhgiwn
ИНСТРУКЦИИ ПО ЭКСПЛУАТАЦИИ



ELECTRICAL CONNECTION (U.K. ONLY)

- A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below.
WARNING: Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard. With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse. If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer.
The colour of the correct replacement fuse cover is that as marked on the base of the plug.
- B) If your appliance is not fitted with a plug, please follow the instructions provided below:

IMPORTANT

The wires in the mains lead are coloured in accordance with the following code:

Blue:	Neutral
Brown:	Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

