
De'Longhi Appliances via Seitz, 47 31100 Treviso Italia www.delonghi.com

CGH1012D

GRIGLIA A CONTATTO CONTACT-GRILL **GRIL CONTACT KONTAKTGRILL** CONTACTGRILL **GRILL DOBLE GRELHADOR DE PLACAS** ΤΟΣΤΙΕΡΑ ГРИЛЬ ТИГІЗІП ПІСІРУ ПЛИТАСЫ KONTAKT GRILLSÜTŐ KONTAKTNÍ GRIL KONTAKTNÝ GRIL **OPIEKACZ KONTAKTGRILL** KONTAKTGRILL KONTAKTGRILL KONTAKTIGRILLI









ELECTRICAL CONNECTION

- A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below. WARNING: Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard. With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse. If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.
- B) If your appliance is not fitted with a plug, please follow the instructions provided below:

WARNING - THIS APPLIANCE MUST BE EARTHED IMPORTANT

The wires in the mains lead are coloured in accordance with the following code:

Green and yellow:	Earth
Blue:	Neutral
Brown:	Live



As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows: The green and yellow wire must be connected to the terminal in the plug marked with the letter E or the earth symbol \pm or coloured green or green and yellow. The blue wire must be connected to the terminal marked with the letter L or coloured black. The brown wire must be connected to the terminal marked with the letter L or coloured red.

