

MACCHINA DA CAFFÈ

COFFEE MAKER

MACHINE A CAFE

KAFFEEAUTOMATEN

KOFFIEZETTER

CAFETERA

CAFETEIRA

ΜΗΧΑΝΗ ΚΑΦΕ

ESPRESSOMASKIN

KAFFEMASKINE

ESPRESSOMASKIN

KAHVINKEITIN


EKSPRES DO KAWY

ΚΑΝΕΦΟΖΟΓΕΡ

ΚΑΝΟVAR

ΚΟΦΕΒΑΡΚΑ

إرشادات للاستعمال



Istruzioni per l'uso

Owner's instructions

Mode d'emploi

Bedienungsanleitung

Gebruiksaanwijzingen

Instrucciones para el uso

Manual de instruções

Οδηγες χρήσης

Bruksanvisning

Brugervejledning

Bruksanvisning

Käyttöohjeet

Instrukcja użytkowania

Kezelési utasítás

Návod k použití

Инструкция по эксплуатации

ماكينة قهوة

ELECTRICAL CONNECTION (UK ONLY)

- A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below.
WARNING: Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard.
With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse.

WARNING - THIS APPLIANCE MUST BE EARTHED **IMPORTANT**


The wires in the mains lead are coloured in accordance with the following code:

Green and yellow:	Earth
Blue:	Neutral
Brown:	Live



- If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.
- B) If your appliance is not fitted with a plug, please follow the instructions provided below:

As the colours of the wires in the mains lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The green and yellow wire must be connected to the terminal in the plug marked with the letter E or the earth symbol  or coloured green or green and yellow.

The blue wire must be connected to the terminal marked with the letter N or coloured black.

The brown wire must be connected to the terminal marked with the letter L or coloured red.

