
FAN HEATER
RADIATEUR SOUFFLANT
HEIZLÜFTER
TERMOVENTILATORE
TERMOVENTILATOR
TERMOVENTILADOR
TERMOVENTILADOR
AEROQERMO
VARMLUFTSBÆSER
VÄRMEFLÄKT
VIFTE OVN
TUULETINLÄMMITIN



MODE D'EMPLOI
BEDIENUNGSANLEITUNG
ISTRUZIONI D'USO
GEBRUIKSVOORSCHRIFTEN
INSTRUCCIONES DE USO
INSTRUÇÕES PARA O USO
OLHGIES CRHSHS
BRUGSVEJLEDNING
BRUKSANVISNING
BRUKS ANVISNING
KÄYTTÖOHJEET



## **Electrical connection (U.K. only)**

A) If your appliance comes fitted with a plug, it will incorporate a 13 Amp fuse. If it does not fit your socket, the plug should be cut off from the mains lead, and an appropriate plug fitted, as below.

WARNING: Very carefully dispose of the cut off plug after removing the fuse: do not insert in a 13 Amp socket elsewhere in the house as this could cause a shock hazard.

With alternative plugs not incorporating a fuse, the circuit must be protected by a 15 Amp fuse

If the plug is a moulded-on type, the fuse cover must be re-fitted when changing the fuse using a 13 Amp Asta approved fuse to BS 1362. In the event of losing the fuse cover, the plug must NOT be used until a replacement fuse cover can be obtained from your nearest electrical dealer. The colour of the correct replacement fuse cover is that as marked on the base of the plug.

B) If your appliance is not fitted with a plug, please follow the instructions provided below:

## **IMPORTANT**

The wires in the mains lead are coloured in accordance with the following code:

Blue: Neutral Brown: Live

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.