

DESCRIPTION

- A** Function selector (certain models only)
- B** Room thermostat
- C** Indicator light (certain models only)

USE

Installation

The appliance must be used in the portable configuration only. This is a household appliance only.


The appliance must not be positioned directly underneath a fixed power point.

Electrical connection


Before plugging into the mains, make sure the voltage of your mains supply corresponds to the value V indicated on the appliance and that the socket and power line are appropriate for the load required.

Operation and use

Models with function selector and room thermostat

- Turn the thermostat (if present) clockwise as far as it will go to the maximum position.
- **Summer use (fan only):** turn the function selector to position . (if present, the indicator light comes on)
- **Low power heating:** turn the function selector to "1". (if present, the indicator light is on)
- **Maximum power heating:** turn the function selector to "2". (if present, the indicator light is on)
- **Turning off:** turn the function selector to "0".
You are recommended to unplug the appliance when not in use.


Models with thermostat only

To turn the appliance on, turn the thermostat clockwise as far as it will go to the maximum position. (if present, the indicator light comes on). To turn the appliance off completely, turn the thermostat to minimum  and unplug from the mains.

Adjusting the thermostat

When the room has reached the required temperature, turn the thermostat slowly anticlockwise until the appliance goes off and no further. The thermostat will then keep room temperature at the selected level automatically.

Freeze protection

Turn the function selector to "2" and the thermostat to .
The appliance is set to maintain a temperature of about 5°C in the room with minimum energy consumption.

MAINTENANCE

- Always unplug from the mains socket before cleaning.
- Clean the air intake and output grilles frequently, if necessary using a vacuum cleaner to remove accumulated dirt.
- Never use abrasive powders or solvents.

TECHNICAL CHARACTERISTICS

Supply voltage	See rating plate
Absorbed power	"